

OWNER'S MANUAL & OPERATING INSTRUCTIONS



3100 Starting Watts / 2800 Running Watts PORTABLE INVERTER GENERATOR



MODEL NUMBER **75531**i

FCC Statement

- 1. This device complies with Part 15 of the FCC Rules.

 Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Have questions or need assistance?

Do not return this product to the store!

WE ARE HERE TO HELP!

Visit our website: www.championpowerequipment.com for more info:

- Product Info & Updates
- Tech Bulletins
- Frequently Asked Questions
- Product Registration

– or –

Call our Customer Care Team Toll-Free at:


1-877-338-0999

For residents of California:

WARNING: This product contains chemicals known to the State of California to cause cancer or birth defects and other reproductive harm.

WARNING: The engine exhaust from this product contains chemicals known to the State of California to cause cancer and birth defects and other reproductive harm.

*We are always working to improve our products. Therefore, the enclosed product may differ slightly from the image on the cover.



3100 Starting Watts / 2800 Running Watts PORTABLE INVERTER GENERATOR

TABLE OF CONTENTS

Introduction		
Portable Power Generator 1 Oil 13 Accessories 1 Spark Plugs 13 This Booklet 1 Air Filter 14 Manual Conventions 2 Cleaning 14 Safety Rules 3 Spark Arrester Cleaning 14 Controls and Features 5 Adjustments 14 Generator 5 Maintenance Schedule 14 Parts Included 5 Generator Maintenance 15 Power Panel 6 Storage 15 Assembly 7 Generator Storage 15 Remove the Generator from the Shipping Carton 7 Specifications 16 Add Engine Oil 7 Engine Specifications 16 Grounding 8 Generator Specifications 16 Grounding 9 Oil 16 Generator Location 9 Spark Plugs 16 Grounding 9 Maintenance Valve Clearance 16 Starting the Engine 9	Introduction	Maintenance and Storage
Accessories 1 Spark Plugs 13 This Booklet 1 Air Filter 14 Manual Conventions 2 Cleaning 14 Safety Rules 3 Spark Arrester Cleaning 14 Controls and Features 5 Adjustments 14 Generator 5 Maintenance Schedule 14 Parts Included 5 Generator Maintenance 15 Power Panel 6 Storage 15 Assembly 7 Generator Storage 15 Remove the Generator from the Shipping Carton 7 Specifications 16 Add Engine Oil 7 Engine Specifications 16 Grounding 8 Generator Specifications 16 Grounding 8 Fuel 16 Operation 9 Oil 16 Generator Location 9 Spark Plugs 16 Grounding 9 Maintenance Valve Clearance 16 Starting the Engine 9 An		Engine Maintenance
This Booklet 1 Air Filter 14 Manual Conventions 2 Cleaning 14 Safety Rules 3 Spark Arrester Cleaning 14 Controls and Features 5 Adjustments 14 Generator 5 Maintenance Schedule 14 Parts Included 5 Generator Maintenance 15 Power Panel 6 Storage 15 Assembly 7 Generator Storage 15 Remove the Generator from the Shipping Carton 7 Specifications 16 Add Engine Oil 7 Engine Specifications 16 Add Fuel 8 Generator Specifications 16 Grounding 8 Fuel 16 Operation 9 Oil 16 Generator Location 9 Spark Plugs 16 Grounding 9 Maintenance Valve Clearance 16 Starting the Engine 9 An Important Message About Temperature 16 Connecting Electrical Lo	Portable Power Generator	Oil
Manual Conventions 2 Cleaning 14 Safety Rules 3 Spark Arrester Cleaning 14 Controls and Features 5 Adjustments 14 Generator 5 Maintenance Schedule 14 Parts Included 5 Generator Maintenance 15 Power Panel 6 Storage 15 Assembly 7 Generator Storage 15 Remove the Generator from the Shipping Carton 7 Specifications 16 Add Engine Oil 7 Engine Specifications 16 Add Fuel 8 Generator Specifications 16 Grounding 8 Fuel 16 Operation 9 Oil 16 Generator Location 9 Spark Plugs 16 Grounding 9 Maintenance Valve Clearance 16 Starting the Engine 9 An Important Message About Temperature 16 Economy Control Switch 10 Parts Diagram 17 Converting	Accessories	Spark Plugs
Safety Rules3Spark Arrester Cleaning14Controls and Features5Adjustments14Generator5Maintenance Schedule14Parts Included5Generator Maintenance15Power Panel6Storage15Assembly7Generator Storage15Remove the Generator from the Shipping Carton7Specifications16Add Engine Oil7Engine Specifications16Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	This Booklet	Air Filter
Controls and Features5Adjustments14Generator5Maintenance Schedule14Parts Included5Generator Maintenance15Power Panel6Storage15Assembly7Generator Storage15Remove the Generator from the Shipping Carton7Specifications16Add Engine Oil7Engine Specifications16Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Manual Conventions	Cleaning
Controls and Features5Adjustments14Generator5Maintenance Schedule14Parts Included5Generator Maintenance15Power Panel6Storage15Assembly7Generator Storage15Remove the Generator from the Shipping Carton7Specifications16Add Engine Oil7Engine Specifications16Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Safety Rules	Spark Arrester Cleaning
Generator5Maintenance Schedule14Parts Included5Generator Maintenance15Power Panel6Storage15Assembly7Generator Storage15Remove the Generator from the Shipping Carton7Specifications16Add Engine Oil7Engine Specifications16Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Controls and Features	
Power Panel6Storage15Assembly7Generator Storage15Remove the Generator from the Shipping Carton7Specifications16Add Engine Oil7Engine Specifications16Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Generator	
Assembly7Generator Storage15Remove the Generator from the Shipping Carton7Specifications16Add Engine Oil7Engine Specifications16Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Parts Included	Generator Maintenance
Assembly7Generator Storage15Remove the Generator from the Shipping Carton7Specifications16Add Engine Oil7Engine Specifications16Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Power Panel	Storage
Remove the Generator from the Shipping Carton 7 Add Engine Oil 7 Engine Specifications 16 Grounding 8 Grounding 9 Generator Location 9 Grounding 9 Spark Plugs 16 Starting the Engine 9 Economy Control Switch 10 Economy Control Switch 10 Connecting Electrical Loads 10 Parts Diagram 17 Parts List 18 Engine Parts Diagram 19	Assembly	
Add Engine Oil7Engine Specifications16Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Remove the Generator from the Shipping Carton . 7	<u> </u>
Add Fuel8Generator Specifications16Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19		•
Grounding8Fuel16Operation9Oil16Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Add Fuel	· ·
Generator Location9Spark Plugs16Grounding9Maintenance Valve Clearance16Starting the Engine9An Important Message About Temperature16Economy Control Switch10Parts Diagram17Connecting Electrical Loads10Parts List1812V DC Outlet11Engine Parts Diagram19	Grounding	
Grounding 9 Maintenance Valve Clearance 16 Starting the Engine 9 An Important Message About Temperature 16 Economy Control Switch 10 Parts Diagram 17 Connecting Electrical Loads 10 Parts List 18 12V DC Outlet 11 Engine Parts Diagram 19	Operation	Oil
Grounding 9 Maintenance Valve Clearance 16 Starting the Engine 9 An Important Message About Temperature 16 Economy Control Switch 10 Parts Diagram 17 Connecting Electrical Loads 10 Parts List 18 12V DC Outlet 11 Engine Parts Diagram 19	Generator Location	Spark Plugs
Economy Control Switch 10 Parts Diagram 17 Connecting Electrical Loads 10 Parts List 18 12V DC Outlet 11 Engine Parts Diagram 19	Grounding	Maintenance Valve Clearance
Economy Control Switch 10 Parts Diagram 17 Connecting Electrical Loads 10 Parts List 18 12V DC Outlet 11 Engine Parts Diagram 19	Starting the Engine	An Important Message About Temperature 16
Connecting Electrical Loads 10 Parts List 18 12V DC Outlet 11 Engine Parts Diagram 19	Economy Control Switch	
12V DC Outlet	Connecting Electrical Loads 10	3
Otalia de la Francia de Constante de Constan	12V DC Outlet	
	Stopping the Engine	Engine Parts List
Do Not Overload Generator		<u> </u>
Capacity	Capacity	
Power Management		Troubleshooting
Overload Operation		
Operation at High Altitude	Operation at High Altitude	

INTRODUCTION

Introduction

Congratulations on your purchase of a Champion Power Equipment inverter generator. CPE designs and builds generators to strict specifications. With proper use and maintenance, this generator will bring years of satisfying service.

Portable Power Generator

This unit is a gasoline engine driven, alternating current (AC) generator. It is designed to supply electrical power for lighting, appliances, tools and similar equipment.

Accessories

Champion Power Equipment manufactures and sells accessories designed to help you get the most from your purchase. To find out more about our covers, power cables and storm kits, please visit our web site at:

→ www.championpowerequipment.com

This Booklet

Every effort has been made to ensure the accuracy and completeness of the information in this manual. We reserve the right to change, alter and/or improve the product and this document at any time without prior notice.

Record the model and serial numbers as well as date and place of purchase for future reference. Have this information available when ordering parts and when making technical or warranty inquiries.



1

MANUAL CONVENTIONS

This manual uses the following symbols to help differentiate between different kinds of information. The safety symbol is used with a key word to alert you to potential hazards in operating and owning power equipment. Follow all safety messages to avoid or reduce the risk of serious injury or death.



DANGER indicates an imminently hazardous situation which, if not avoided, **will** result in death or serious injury.

⚠WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, *could* result in death or serious injury.

! CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, *may* result in minor or moderate injury.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, *may* result in property damage.

→ NOTE

If you have questions regarding your generator, we can help. Please call our help line at **1-877-338-0999**

⚠ WARNING

Read this manual thoroughly before operating your generator. Failure to follow instructions could result in serious injury or death.

AWARNING

The engine exhaust from this product contains chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm.

A DANGER

Generator exhaust contains carbon monoxide, a colourless, odourless, poison gas. Breathing carbon monoxide will cause nausea, dizziness, fainting or death. If you start to feel dizzy or weak, get to fresh air immediately.

Operate generator outdoors only in a well ventilated area.

DO NOT operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. DO NOT allow exhaust fumes to enter a confined area through windows, doors, vents or other openings

DANGER CARBON MONOXIDE: using a generator indoors **CAN KILL YOU IN MINUTES**.

A DANGER

Rotating parts can entangle hands, feet, hair, clothing and/or accessories.

Traumatic amputation or severe laceration can result.

Keep hands and feet away from rotating parts. Tie up long hair and remove jewelry.

Operate equipment with guards in place.

DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught.

A DANGER

Generator produces powerful voltage.

DO NOT touch bare wires or receptacles.

DO NOT use electrical cords that are worn, damaged or frayed.

DO NOT operate generator in wet weather.

DO NOT allow children or unqualified persons to operate or service the generator

Use a ground fault circuit interrupter (GFCI) in damp areas and areas containing conductive material such as metal decking.

Use approved transfer equipment to isolate generator from your electric utility and notify your utility company before connecting your generator to your power system.

↑ WARNING

Sparks can result in fire or electrical shock.

When servicing the generator:

Disconnect the spark plug wire and place it where it cannot contact the plug.

DO NOT check for spark with the plug removed. Use only approved spark plug testers.

MARNING

Running engines produce heat. Severe burns can occur on contact.

Combustible material can catch fire on contact.

DO NOT touch hot surfaces.

Avoid contact with hot exhaust gases. Allow equipment to cool before touching. Maintain at least 3 ft. (91.4 cm) of clearance on all sides to ensure adequate cooling.

Maintain at least 5 ft. (1.5 m) of clearance from combustible materials.

⚠ WARNING

Medical and Life Support Uses.

In case of emergency, call 911 immediately. NEVER use this product to power life support devices or life support appliances.

NEVER use this product to power medical devices or medical appliances.

Inform your electricity provider immediately if you or anyone in your household depends on electrical equipment to live.

Inform your electrical provider immediately if a loss of power would cause you or anyone in your household to experience a medical emergency.

A DANGER

Fuel and fuel vapours are highly flammable and extremely explosive.

Fire or explosion can cause severe burns or death. Unintentional startup can result in entanglement, traumatic amputation or laceration.

When adding or removing fuel:

Turn the generator off and let it cool for at least two minutes before removing the fuel cap. Loosen the cap slowly to relieve pressure in the tank.

Only fill or drain fuel outdoors in a well-ventilated area. DO NOT pump gas directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT overfill the fuel tank.

Always keep fuel away from sparks, open flames, pilot lights, heat and other sources of ignition. DO NOT light or smoke cigarettes.

When starting the generator:

DO NOT attempt to start a damaged generator. Make certain that the gas cap, air filter, spark plug, fuel lines and exhaust system are properly in place. Allow spilled fuel to evaporate fully before attempting to start the engine.

Make certain that the generator is resting firmly on level ground.

When operating the generator:

DO NOT move or tip the generator during operation. DO NOT tip the generator or allow fuel or oil to spill.

When transporting or servicing the generator:

Make certain that the fuel shutoff valve is in the off position and the fuel tank is empty.

Disconnect the spark plug wire.

When storing the generator:

Store away from sparks, open flames, pilot lights, heat and other sources of ignition.

Operation of this equipment may create sparks that can start fires around dry vegetation.

A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

⚠ WARNING

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go. Unintentional startup can result in entanglement, traumatic amputation or laceration.

Broken bones, fractures, bruises or sprains could result.

When starting engine, pull the starter cord slowly until resistance is felt and then pull rapidly to avoid kickback.

DO NOT start or stop the engine with electrical devices plugged in.

① CAUTION

Exceeding the generator's running capacity can damage the generator and/or electrical devices connected to it.

DO NOT overload the generator.

Start the generator and allow the engine to stabilize before connecting electrical loads.

Connect electrical equipment in the off position, and then turn them on for operation.

Turn electrical equipment off before stopping the generator.

DO NOT tamper with the governed speed.

DO NOT modify the generator in any way.

! CAUTION

Improper treatment or use of the generator can damage it, shorten its life and void your warranty.

Use the generator only for intended uses.

Operate only on level surfaces.

DO NOT expose generator to excessive moisture, dust, or dirt.

DO NOT allow any material to block the cooling slots. If connected devices overheat, turn them off and disconnect them from the generator.


DO NOT use the generator if:


- Electrical output is lost
- Equipment sparks, smokes or emits flames
- Equipment vibrates excessively

CONTROLS AND FEATURES

Read this owner's manual before operating your generator. Familiarize yourself with the location and function of the controls and features. Save this manual for future reference.

Inverter






- (1) Fuel Cap Remove to add fuel.
- (2) Recoil Starter Used to start the engine.
- (3) Power Panel
- (4) Muffler

- (5) Maintenance Cover
- (6) Never Flat Wheels
- (7) Carrying Handle


Parts Included

Your 75531i Gasoline Powered Generator ships with the following parts:

_	12V DC Battery Cables 6.6 ft. (2 m)	1
_	Oil funnel	1
_	Snark nlug socket	1



Power Panel



- (1) Fuel Valve Knob
- (2) Choke
- (3) Economy Control Switch
- **(4) Ground Terminal** Consult an electrician for local grounding regulations.
- (5) 12V DC Outlet*
- (6) Circuit Breaker (Push button) Protects the generator against electrical overload.
- (7) 120 Volt AC, 20 Amp Duplex (NEMA 5-20R) May be used to supply electrical power for the operation of 120 Volt AC, 20 Amp, single phase 60 Hz electrical loads.

- (8) 120 Volt AC, 30 Amp Receptacle (NEMA TT-30R)
 May be used to supply electrical power for the operation of 120 Volt AC, 30 Amp, single phase
- (9) Oil Warning Light Check oil level when this light turns on. Engine will not run when indicator is lit.
- (10) Overload Indicator Light This light turns ON when the generator is overloaded and will cut power to the receptacles.

60 Hz electrical loads.

- (11) Output Light Remains ON during normal operating conditions. Shuts OFF when generator is overloaded.
- (12) Engine Switch

^{*}Warning: Do not operate a device while it is plugged into the 12V DC outlet. Prolonged exposure to engine exhaust can cause serious injury or death. While charging a device do no place on the exhaust side of the generator. Extreme heat caused by exhaust can damage the device, and cause a potential fire hazard.

ASSEMBLY

Your generator requires some assembly. This unit ships from our factory without oil. It must be properly serviced with fuel and oil before operation.

If you have any questions regarding the assembly of your generator, call our help line at 1-877-338-0999. Please have your serial number and model number available.

Remove the Generator from the Shipping Carton

- 1. Set the shipping carton on a solid, flat surface.
- 2. Remove everything from the carton except the generator.
- 3. Using the carrying handles of the unit, carefully remove the generator from the box. (two people lifting is recommended)

Add Engine Oil


(CAUTION

DO NOT attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil. Damage to the generator as a result of failure to follow these instructions will void your warranty.

NOTE


The recommended oil type is 10W-30 automotive oil.

- 1. Place the generator on a flat, level surface.
- 2. Loosen the cover screws and remove the maintenance cover.



Add Engine Oil Cont'd.

- 3. Remove oil fill cap/dipstick to add oil.
- 4. Add 0.6 L (0.6 qt.) of oil (not included) and replace oil fill cap/dipstick. DO NOT OVERFILL.



5. Check engine oil level daily and add as needed.

CAUTION

The engine is equipped with a low oil shut-off and will stop when the oil level in the crankcase falls below the threshold level.

NOTE


Check oil often during the break-in period. Refer to the Maintenance section for recommended service intervals.

♥ NOTE

The generator rotor has a sealed, pre-lubricated ball bearing that requires no additional lubrication for the life of the bearing.

Add Fuel

- 1. Use clean, fresh, regular unleaded fuel with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.
- 2. DO NOT mix oil with fuel.
- 3. Clean the area around the fuel cap.
- 4. Remove the fuel cap.
- 5. Slowly add fuel to the tank. DO NOT OVERFILL. Fuel can expand after filling. A minimum of 1/4 in. (6.4 mm) of space left in the tank is required for fuel expansion, more than 1/4 in. (6.4 mm) is recommended. Fuel can be forced out of the tank as a result of expansion if it is overfilled, and can affect the stable running condition of the product. When filling the tank, it is recommended to leave enough space for the fuel to expand.
- 6. Screw on the fuel cap and wipe away any spilled fuel.



(I) CAUTION

Use regular unleaded gasoline with a minimum octane rating of 85.

Do not mix oil and gasoline.

Fill tank to approximately 1/4 in. (6.4 mm) below the top of the tank to allow for fuel expansion.

DO NOT pump gas directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT fill fuel tank indoors.

DO NOT fill fuel tank when the engine is running or hot.

DO NOT overfill the fuel tank.

DO NOT light cigarettes or smoke when filling the fuel tank.

⚠ WARNING

Pouring fuel too fast through the fuel screen may result in blow back of fuel at the operator while filling. Add Fuel Cont'd.



NOTE

Our engines work well with 10% or less ethanol blend fuels. When using blended fuels there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor.
- With gravity-fed fuel supplies, this compromised fuel can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- There are only a few suppliers of fuel stabilizer that are formulated to work with ethanol blend fuels.
- Any damages or hazards caused by using improper fuel, improperly stored fuel, and/ or improperly formulated stabilizers, are not covered by manufacture's warranty.

It is advisable to always shut off the fuel supply, run the engine to fuel starvation and drain the tank when the equipment is not in use for more than 30 days.

Grounding

Your generator must be properly connected to an appropriate ground to help prevent electric shock.



Failure to properly ground the generator can result in electric shock.

A ground terminal connected to the frame of the generator has been provided on the power panel. For remote grounding, connect of a length of heavy gauge (12 AWG minimum) copper wire between the generator ground terminal and a copper rod driven into the ground. We strongly recommend that you consult with a qualified electrician to ensure compliance with local electrical codes.

Generator Location

NEVER operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. Please consult your local authority. In some areas, generators must be registered with the local utility. Generators used at construction sites may be subject to additional rules and regulations. Generators should be on a flat, level surface at all times (even while not in operation). Generators must have at least 5 ft. (1.5 m) of clearance from all combustible material. In addition to clearance from all combustible material, generators must also have at least 3 ft. (91.4 cm) of clearance on all sides to allow for adequate cooling, maintenance and servicing. Generators should never be started or operated in the back of a SUV, camper, trailer, in the bed of a truck (regular, flat or otherwise), under staircases/stairwells, next to walls or buildings, or in any other location that will not allow for adequate cooling of the generator and/or the muffler. DO NOT contain generators during operation. Allow generators to properly cool before transport or storage. Place the generator in a well-ventilated area. DO NOT place the generator near vents or intakes where exhaust fumes could be drawn into occupied or confined spaces. Carefully consider wind and air currents when positioning generator.

Failure to follow proper safety precautions may void manufacturer's warranty.

MARNING

Do not operate or store the generator in rain, snow, or wet weather.

Using a generator or electrical appliance in wet conditions, such as rain or snow, or near a pool or sprinkler system, or when your hands are wet, could result in electrocution.

↑ WARNING

During operation the muffler and exhaust fumes produced will become hot. If adequate cooling and breathing space are not supplied, or if the generator is blocked or contained, temperatures can become extremely heated and may lead to fire.


Grounding

The generator system ground connects the frame to the ground terminals on the power panel.


- The generator (stator winding) is isolated from the frame and from the AC receptacle ground pin.
- Electrical devices that require a grounded receptacle pin connection will not function if the receptacle ground pin is not functional.

Starting the Engine


- 1. Make certain the generator is on a flat, level surface.
- Disconnect all electrical loads from the generator.
 Never start or stop the generator with electrical devices plugged in or turned on.
- 3. Turn the fuel valve to the "On" position.



4. Pull choke lever out to the "Choke" position.



5. Turn the engine switch to the "On" position.



Starting the Engine Cont'd.

- 6. Pull the starter cord slowly until resistance is felt and then pull rapidly.
- As engine warms up, push the choke lever in to the "Run" position.



■ NOTE

Keep choke lever in "Choke" position for only 1 pull of the recoil starter. After first pull, move choke lever to the "Run" position for up to the next 3 pulls of the recoil starter. Too much choke leads to spark plug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.



■ NOTE

If the engine starts but does not continue to run make certain that the generator is on a flat, level surface. The engine is equipped with a low oil sensor that will prevent the engine from running when the oil level falls below a critical threshold.

Economy Control Switch

The Economy Control switch can be activated in order to minimize fuel consumption and noise while operating the unit during times of reduced electrical output, allowing the engine speed to idle during periods of non-use. The engine speed returns to normal when an electrical load is connected. When the economy switch is off, the engine runs at normal speed continuously.



⚠ WARNING

For periods of high electrical load or momentary fluctuations, the Economy Control Switch should be turned OFF.

Connecting Electrical Loads

- Let the engine stabilize and warm up for a few minutes after starting
- Plug in and turn on the desired 120 Volt AC single phase, 60 Hz electrical loads.
- DO NOT connect 3-phase loads to the generator.
- DO NOT connect 50 Hz loads to the generator.
- DO NOT overload the generator.



◯ NOTE

Connecting a generator to your electric utility company's power lines or to another power source may be against the law. In addition this action, if done incorrectly, could damage your generator and appliances and could cause serious injury or even death to you or a utility worker who may be working on nearby power lines. If you plan to run a portable electric generator during an outage, please notify your electric utility company immediately and remember to plug your appliances directly into the generator. Do not plug the generator into any electric outlet in your home. Doing so could create a connection to the utility company power lines. You are responsible for ensuring that your generator's electricity does not feed back into the electric utility power lines.

If the generator will be connected to a building electrical system, consult your local utility company or a qualified electrician. Connections must isolate generator power from utility power and must comply with all applicable laws and codes.



⚠ WARNING

Do not operate a device while it is plugged in to the 12V DC outlet.

Prolonged exposure to engine exhaust can cause serious injury or death.

⚠ WARNING

While charging a device do not place on the exhaust side of the generator. Extreme heat caused by exhaust can damage the device, and cause a potential fire hazard.

OPERATION

12V DC Outlet

The 12V DC outlet is ONLY to be used with the supplied 12V battery charging cable. The DC output is unregulated and will damage other 12V DC products. When using the DC outlet, turn the Economy switch to the "OFF" position.

! CAUTION

Do not start the vehicle while the battery charging cable is connected and the generator is running. It will not give the battery a boost of power. The vehicle or the generator may be damaged. Charge only vented wet lead acid batteries. Other types of batteries may burst, causing personal injury or damage.



NOTE

Be sure all electric devices including the lines and plug connections are in good condition before connection to the generator.

- 1. Before connecting the battery charging cable to a battery that is installed in a vehicle, disconnect the vehicle battery ground cable from the negative (-) battery terminal.
- 2. Plug the battery charging cable into the DC receptacle of the generator.
- 3. Connect the red (+) battery charger lead to the red (+) battery terminal.
- 4. Connect the black (-) battery charger lead to the black (-) battery terminal.
- 5. Start the generator.

Stopping the Engine

- 1. Turn off and unplug all electrical loads. Never start or stop the generator with electrical devices plugged in or turned on.
- Let the generator run at no-load for several minutes to stabilize internal temperatures of the engine and generator.
- 3. Turn the Fuel Valve to the "OFF" position.
- Let the engine run until fuel starvation has stopped the engine. This usually takes a few minutes.
- Turn the engine switch to the "Off" position. **Important:** Always ensure that the Fuel Valve and the Engine Switch are in the "OFF" position when the engine is not in use.



NOTE

If the engine will not be used for a period of two (2) weeks or longer, please see the storage section for proper engine and fuel storage.

Do Not Overload Generator

Capacity

Follow these simple steps to calculate the running and starting watts necessary for your purposes.

- Select the electrical devices you plan on running at the same time.
- Total the running watts of these items. This is the amount of power you need to keep your items running.
- Identify the highest starting wattage of all devices identified in step 1. Add this number to the number calculated in step 2. Surge wattage is the extra burst of power needed to start some electric driven equipment. Following the steps listed under "Power Management" will guarantee that only one device will be starting at a time.

Power Management

Use the following formula to convert voltage and amperage to watts:

Volts x Amps = Watts

To prolong the life of your generator and attached devices, follow these steps to add electrical load:

- Start the generator with no electrical load attached.
- 2. Allow the engine to run for several minutes to stabilize.
- 3. Plug in and turn on the first item. It is best to attach the item with the largest load first.
- Allow the engine to stabilize.
- 5. Plug in and turn on the next item.
- Allow the engine to stabilize.
- 7. Repeat steps 5-6 for each additional item.



♥ NOTE

Never exceed the specified capacity when adding loads to the generator.

Overload Operation

The overload indicator light will turn on when the rated load is exceeded. When the maximum load is reached. the LED will blink and cut power to the receptacles. To recover the power, shut down the engine, wait until the light turns off and restart the generator.

Operation at High Altitude

The density of air at high altitude is lower than at sea level. Engine power is reduced as the air mass and airfuel ratio decrease. Engine power and generator output will be reduced approximately 3½% for every 1000 feet of elevation above sea level. This is a natural trend and cannot be changed by adjusting the engine. At high altitudes increased exhaust emissions can also result due to the increased enrichment of the air fuel ratio. Other high altitude issues can include hard starting, increased fuel consumption and spark plug fouling. To alleviate high altitude issues other than the natural power loss, Champion Power Equipment can provide a high altitude carburetor main jet. The alternative main jet and installation instructions can be obtained by contacting Customer Support. Installation instructions are also available in the Technical Bulletin area of the Champion Power Equipment internet site.

The part number and recommended minimum altitude for the application of the high altitude carburetor main jet is listed in the table below.

In order to select the correct high altitude main jet it is necessary to identify the carburetor model. For this purpose, a code is stamped on the side of the carburetor. Select the correct main jet part number corresponding to the carburetor code found on your particular carburetor.

Carburetor Code	Main Jet	Part Number	Altitude
P20-2-H	Standard	83.131017.01.H	
P20-2-H	Altitude	83.131017.01.01.H	3500 Feet
P20-2-Y	Standard	83.131017.01.Y	(1067 Meters)
	Altitude	83.131017.01.01.Y	

MARNING

Operation using the alternative main jet at elevations lower than the recommended minimum altitude can damage the engine. For operation at lower elevations, the standard main jet must be used. Operating the engine with the wrong engine configuration at a given altitude may increase its emissions and decrease fuel efficiency and performance.

MAINTENANCE AND STORAGE

The owner/operator is responsible for all periodic maintenance.

⚠ WARNING

Never operate a damaged or defective generator.

⚠ WARNING

Tampering with the factory set governor will void your warranty.

⚠ WARNING

Improper maintenance will void your warranty.



Maintenance, replacement, or repair of emission control devices and systems may be performed by any non-road engine repair establishment or individual.

Complete all scheduled maintenance in a timely manner. Correct any issue before operating the generator.

NOTE

For service or parts assistance, contact our help line at 1-877-338-0999

Engine Maintenance

To prevent accidental starting, remove and ground spark plug wire before performing any service.

0il


Change oil when the engine is warm. Refer to the oil specification to select the proper grade of oil for your operating environment.

- Remove oil fill cap/dipstick.
- 2. Use pliers to slide the spring clamp down the oil drain hose and pull the hose off the plug bracket.
- Point the hose into a drain pan and allow the oil to drain completely. Note: The hose end must be lower than the engine base to allow the oil to drain.
- 4. Replace oil drain hose onto plug bracket and slide spring clamp back into position.
- 5. Add up to 0.6 qt. (0.6 L) of oil and replace oil fill cap/dipstick. DO NOT OVERFILL.
- 6. Dispose of used oil at an approved waste management facility.

Oil Cont'd.


◯ NOTE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.



Spark Plugs

- 1. Remove the maintenance cover.
- 2. Remove the spark plug cable from the spark plug.
- 3. Use the spark plug tool that shipped with your generator to remove the plug.
- 4. Remove the spark plug.
- 5. Inspect the electrode on the plug. It must be clean and not worn to produce the spark required for ignition.
- 6. Make certain the spark plug gap is 0.7 0.8 mm (0.028 - 0.031 in.).



- 7. Carefully thread the plug into the engine.
- 8. Use the spark plug tool to firmly install the plug.
- 9. Attach the spark plug cap to the plug.
- 10. Reinstall the spark plug access cap, and maintenance cover.

MAINTENANCE AND STORAGE

Air Filter

- 1. Remove the maintenance cover.
- 2. Locate the air filter plastic cover.
- 3. Unsnap the locking hinge on the cover.
- 4. Remove the old filter.
- 5. Place the new filter in the assembly.
- 6. Re-snap the hinge on the air filter cover.
- 7. Reinstall the maintenance cover and tighten the cover screw securely.

Cleaning



DO NOT spray engine with water.


Water can contaminate the fuel system.

Use a damp cloth to clean exterior surfaces of the engine. Use a soft bristle brush to remove dirt and oil.

Use an air compressor (25 PSI) to clear dirt and debris from the engine.

Spark Arrester

- 1. Allow the engine to cool completely before servicing the spark arrester.
- Remove the two screws holding the cover plate which retains the end of the spark arrester to the muffler.
- 3. Remove the spark arrester screen.
- 4. Carefully remove the carbon deposits from the spark arrester screen with a wire brush.
- 5. Replace the spark arrester if it is damaged.
- 6. Position the spark arrester in the muffler and attach with the two screws.



(1) CAUTION

Failure to clean the spark arrester will result in degraded engine performance.

Adjustments

The air-fuel mixture is not adjustable. Tampering with the governor can damage your generator and your electrical devices and will void your warranty. CPE recommends that you contact our service line at 1-877-338-0999 for all other service and/or adjustment needs.

Maintenance Schedule

Follow the service intervals indicated in the following maintenance schedule.

Service your generator more frequently when operating in adverse conditions.

Contact our help line at **1-877-338-0999** to locate the nearest Champion Power Equipment certified service dealer for your generator or engine maintenance needs.

Every 8 hours or daily		
Check oil level		
Clean around air intake and muffler		
First 5 hours		
Change oil		
Every 50 hours or every season		
Clean air filter		
Change oil if operating under heavy load or in hot environments		
Every 100 hours or every season		
Change oil		
Clean/Adjust spark plug		
Check/Adjust valve clearance*		
Clean spark arrester		
Clean fuel tank and filter*		
Every 250 hours		
Clean combustion chamber*		
Every 3 years		
Replace fuel line		

^{*}To be performed by knowledgeable, experienced owners or Champion Power Equipment certified dealers.

MAINTENANCE AND STORAGE

Generator Maintenance

Make certain that the generator is kept clean and stored properly. Only operate the unit on a flat, level surface in a clean, dry operating environment. DO NOT expose the unit to extreme conditions, excessive dust, dirt, moisture or corrosive vapours.



DO NOT use a garden hose to clean the generator.

Water can enter the generator through the cooling slots and damage the generator windings.

Use a damp cloth to clean exterior surfaces of the generator. Use a soft bristle brush to remove dirt and oil.

Use an air compressor (25 PSI) to clear dirt and debris from the generator.

Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

Storage

The generator should be started at least once every 14 days and allowed to run for at least 20 minutes. For longer term storage, please follow these guidelines.

Generator Storage

- Add a properly formulated fuel stabilizer to the tank.
- Be sure all appliances are disconnected from the generator.
- Run the generator for a few minutes so the treated fuel cycles through the fuel system and carburetor.
- Turn the fuel valve to the "Off" position.
- Let the generator run until fuel starvation has stopped the engine. This usually takes a few minutes.
- The generator needs to cool completely before cleaning and storage.
- Remove the spark plug cap, then pull the recoil grip 3 times to drain the gasoline from the carburetor jets.
- Change the engine oil.
- Remove the spark plug and pour about a tablespoon of oil into the cylinder. Crank the engine slowly to distribute the oil and lubricate the cylinder.
- 10. Reattach the spark plug.
- 11. Store the unit in a clean, dry place out of direct sunlight.



A DANGER

Generator exhaust contains odorless and colorless carbon monoxide gas.

To avoid accidental or unintended ignition of your generator during periods of storage, the following precautions should be followed:

 When storing the generator for short or extended periods of time make sure that the Engine Switch and the Fuel Valve are set in the **OFF** position.

Engine Specifications

-	Model
_	Displacement
_	Type
_	Start Type

Generator Specifications

	•
-	Model
_	Running Watts
_	Starting Watts
_	AC Load
_	Phase
_	Frequency
_	Fuel Capacity
_	Gross Weight
_	Net Weight
_	Height
_	Width
_	Length

Fuel


Fuel capacity is 1.6 gal. (6 L). Use regular unleaded gasoline with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.

Oil

Use 10W-30 automotive oil. Oil capacity is 0.6 L (0.6 qt.).

DO NOT OVERFILL

Please reference the following chart for recommended oil types for use in the generator.



NOTE

Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

Spark Plugs

OEM spark plug: NHSP F6RTC

Replacement spark plug: NGK BPR6ES or equivalent Make certain the spark plug gap is 0.7 - 0.8 mm or (0.028 - 0.031 in.).


Maintenance Valve Clearance

- Intake: 0.06 0.12 mm (0.002 0.005 in.)
- Exhaust: 0.08 0.14 mm (0.003 0.006 in.)
 Note: Tech bulletin regarding the valve adjustment procedure is on www.championpowerequipment.com.

An Important Message About Temperature

Your Champion Power Equipment product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed your product may be operated at temperatures ranging from -15°C (5°F) to 50°C (122°F) for short periods. If the product is exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and other vents.


Parts Diagram



# 1 2 3 4 5 6 7 8 9 10 11	Part Number 1.9074.4.0516.1 2.08.052.1 83.200200.01.2 83.201600.03 1.5789.0612 83.200701.02.2	Description Screw M5×16 Bolt (M6×16) Cover, Left, Black Supporter, Left	4 10 1
2 3 4 5 6 7 8 9	2.08.052.1 83.200200.01.2 83.201600.03 1.5789.0612	Bolt (M6×16) Cover, Left, Black	10
3 4 5 6 7 8 9	83.200200.01.2 83.201600.03 1.5789.0612	Cover, Left, Black	
4 5 6 7 8 9	83.201600.03 1.5789.0612		1
5 6 7 8 9	1.5789.0612		1
6 7 8 9		Flange Bolt M6×12	10
7 8 9 10		Handle, Left, Black	10
8 9 10	1.9074.4.0512.1	Screw M5×12	11
9	83.200500.01.48	Cover, Top, Yellow	1
	83.200502.01	Spillway, Fuel Tank	1
11	83.070100.01	Fuel Tank Cap	1
	2.06.016	Clip (Ø8.7×b8)	3
12	83.070011.01	Fuel Pipe, Fuel Tank To Petcock	1
13	2.06.018	Clip (Ø10.5×b8)	1
14	111.070300.01	Inline Fuel Filter Assembly	1
15	2.08.068.2	Bolt M5×13	6
16	83.071000.01	Fuel Tank	1
17	83.070300.01	Fuel Filter Assembly	1
18	83.070014.01	Pipe, Fuel Tank To Canister	1
19	1.845.4213	Screw ST4.2×13	6
20	83.081400.01	Muffler Protector Assembly, Upper	1
21	83.081004.01	Plate	1
22	2.02.001	Nut (M6), Long	2
23	83.100001.01	Gasket, Exhaust	1
24	83.101100.02	Muffler Assembly	1
25	46.101300.08	Arrester Assembly, Spark	1
26	46.101503.08	Plate, Spark Arrester	1
27	1.9074.4.0514	Screw M5×14	2
28	1.845.4816	Screw ST4.8×16	6
29	1.845.4219	Screw ST4.2×19	1
30	83.081500.01 83.100501.01	Muffler Protector Assembly, Lower	1 1
32	2.06.013	, ,	
33	1.16674.0616	Clip (Ø13.5×b10) Flange Bolt M6×16	
34	1.93.06	Spring Washer Ø6	3
35	1.5789.0620	Flange Bolt M6×20	6
36	83.100500.01	Supporter, Secondary Air Intake Valve	1
37	24.100003.03	Gasket, Air Supply Valve	1
38	24.100300.03	Secondary Air Intake Valve	1
39	2.08.055.1	Bolt, Maintenance Cover	2
40	83.200402.01.48	Protector, Rear Cover, Yellow	1
41	83.200401.01.48	Supporter, Rear Cover, Yellow	1
42	2.02.014	Nut (M6), Square	12
43	2.02.010	Cage Nut (M5)	8
44	83.200701.03.2	Handle, Left, Black	1
45	83.200704.01.2	Bracket, Left, Black	1
46	83.201600.05	Supporter, Right	1
47	1.5789.0615	Flange Bolt M6×15	9
48	1.6187.1.08	Flange Lock Nut M8	2
49	2.13.001	Bushing (Ø13.3ר19.3×8)	2
50	1.5789.0612.1	Flange Bolt M6×12, Black	4
51	83.200704.02.2	Bracket, Right, Black	1
52	2.03.001	Bushing (Ø13.3ר19.3×2)	2
53	2.03.002	Washer (Ø13ר20×2.5)	2
54	2.08.002 83.200701.04.2	Bolt (M8×28)	2
55 56	2.02.002	Handle, Right, Black Nut (M6), T-Style	2
57	83.200705.01.2	Handle, Upper, Black	1
58	83.200705.01.2	Handle, Copper, Black	1
59	1.9074.3.0512.1	Screw M5×12, Black	3
60	1.5789.0635.1	Flange Bolt M6×35, Black	2
61	83.190006.01	Rubber Sleeve, End Cover	1
62	83.190003.01	Generator End Cover	1
	83.190001.01	Generator Fan 1	
63	2.02.006	Nut (M14×1.5)	1
63 64	L.0L.000		

#	Part Number	Description	Qty
66	1.5789.0645	Flange Bolt M6×45	4
67	83.191200.01	Stator Assembly	1
68	83.190002.01	End Cover, Motor	1
69	83.401	Engine	1
70	1.6177.1.08	Flange Lock Nut M8	12
71	2.05.050	Wire Clip, 100mm	2
72	83.201600.02	Supporter, Left	1
73	83.201600.01	Supporter, Right	1
74	83.201200.01	Motor Mount	4
75	83.200607.01	Plug	1
76	1.6182.06	Lock Nut M6	6
77	83.200601.01	Base Setting Component	1
78	83.201400.01	Rubber	2
79	83.201702.01	Plug, Wheel	2
80	1.894.1.12	Retaining Ring Ø12	2
81	1.848.12	Washer Ø12	2
82	83.201701.01	Wheel, Left	1
83	83.201500.01	Axle	1
84	83.201701.02	Wheel, Right	1 5
85	83.200305.01 83.200304.01	Spring Patch	5
86 87	1.845.3595	Rubber Seal Sleeve Screw ST3.5×9.5	9
88	1.845.3595 83,200303.01.2	Cover, Right Muffler, Black	1
89	83.200303.01.2	Handle, Right, Black	1
90	83.200302.01.2	Cover, Right Side, Black	1
91	2.08.075.1	Bolt M6×20	2
92	81.220002.00	Mount Rubber, Control Unit	2
93	81.220001.00	Protector, Control Unit	2
94	83.220003.01	Plate, Controller 2	
95	83.221000.00	Control Unit (120V/60Hz) 1	
96	1.5783.0520	Bolt M5×20 1	
97	1.93.05	Spring Washer Ø5	
98	122.190600.00	Rectifier 1	
99	83.070013.01	Pipe, Canister To Air Cleaner 1	
100	46.070700.00	Carbon Canister (150 CC) 1	
101	83.070702.01	Support Arm 1	
102	83.070011.02	Fuel Pipe, Petcock To Carburetor	1
103	1.845.4819	Screw ST4.8×19	2
104	1.97.1.05	Washer Ø5	2
105	83.070400.01	Fuel Cock	1
106	83.200101.01.48	Front Cover, Yellow	1
107	83.200106.01 83.061200.01.2	Protector Guide, Rope, Black	1
108	1.823.0408.1	Screw M4×8, Black	2
110	83.070001.01	Fuel Cock Knob	1
111	83.130200.01	Pull Choke Assembly	1
112	5.1110.000	Receptacle (DC.12V)	1
113	1.9074.4.0414.1	Screw M4×14, Black	6
114	5.1210.920	A.C 20A Breaker, Push Button	1
115	5.1120.010	Receptacle 5-20R Duplex	1
116	1.6177.1.04.1	Flange Lock Nut M4, Black	6
117	83.210002.02	Control Box	1
118	122.210003.01	Grommet 1	
119	1.9074.4.0535	Screw M5×35 2	
120	5.1200.308	Breaker (8A) 1	
121	5.1120.036	Receptacle TT-30R	1
122	1.818.0514.3	Screw M5×14, Green	2
123	83.210016.00	Speed Limiter	1
124	1.5783.0514.3	Bolt M5×14, Green 1	
125	83.01.2.2	Control Panel, Black 1	
126	1.97.1.05.3	Washer Ø5, Green 1	
127 128	1.6170.05.3 5.1000.002.1	Nut M5, Green 2	
120		Ignition Switch 1	
129	5 1010 001 1	Switch Economy	1 1
129 130	5.1010.001.1 9.1600.011	Switch, Economy Cables, DC 12V	1 1


Engine Parts Diagram



#	Part Number	Description	Oty
			Qty
1	1.5789.0835	Flange Bolt M8×35	6
3	2.11.014	Oil Seal (Ø25ר40×7)	2
4	83.030007.01 83.127000.01	Cover, Crankcase Oil Level Sensor	1
5	1.5789.0612	Flange Bolt M6×12	11
6	83.030010.01	Plate, Coil	1
7	83.120100.01	Flywheel	1
8	83.080001.01	Cooling Fan	1
9	83.060001.01	Pulley, Starter	1
10	2.02.006	Nut M14×1.5	1
11	83.080100.01.2	Fan Cover, Black	1
12	45.060008.00	Screw, Ratchet Guige	1
13	45.060007.00	Ratchet Guide	1
14	45.060009.00	Spring, Ratchet Guide	1
15	45.060002.00	Starter Ratchet (Iron)	2
16	45.060003.00	Spring, Ratchet	2
17	21.061001.01	Recoil Starter Reel	1
18	21.061005.00	Recoil Starter Spring	1
19	81.061010.01	Rope Button	1
20	81.061006.00	Grip, Starter	1
21	2.10.001	Rope (Ø4×1570)	1
22	2.05.050	Wire Clip, 100 mm	1
23	83.061100.01.2	Recoil Starter Cover, Black	1
24	1.5789.0608	Flange Bolt M6×8	3
25	83.091200.01	Cover, Air Cleaner	1
26	83.091300.01	Element, Air Cleaner	1
27	1.6177.1.06	Lock Nut M6, Flange	2
28	83.090001.01	Flange	1
29	83.091100.01	Base, Air Cleaner	1
30	83.091006.01	Buckle	1
31	83.091002.02	Seal	1
32	83.090004.01	Pipe, Air Cleaner	1
33	83.130004.01	Gasket, Air Cleaner	1
34	83.130000.01	Carburetor, Assembly	1
35	83.130001.01	Insulator, Carburetor	1
36	83.130002.01	Gasket, Insulator	2
37	1.5789.0620	Flange Bolt M6×20	2
38	83.123000.01	Ignition Coil	1
39	83.030100.01	Crankcase	1
40	83.040013.01	Lifter, Valve	2
41	83.030013.01	Seal Strip, Crankcase Cover	2
42	2.04.002	Dowel Pin (Ø8×14)	2
43	1.276.6205	Bearing 6205	2
44	2.14.017	Woodruff Key (4×6.5×16)	1
45	83.050100.01	Crankshaft	1
46	83.030008.01	Gasket, Crankcase Cover	1
47	1.9074.4.0510	Screw M5×10	4
48	83.080014.01	Air Guide Board	1
49	2.03.016	Washer, Drain Bolt (Ø10ר16×1.5)	1
50	83.032000.00	Hose, Oil Drain	1
51	83.030009.01	Gasket, Cylinder Head	1
52	2.04.003	Dowel Pin (Ø10×14)	2
53	83.040006.01	Valve, Exhaust	1

#	Part Number	Description	Qty
54	83.040002.01	Valve, Intake	1
55	2.01.017	Stud Bolt (M6×32)	
56	83.010100.01	Cylinder Head	1
57	2.15.002	Spark Plug (F6RTC)	1
58	83.040017.01	Oil Seal, Valve	1
59	83.040004.01	Guide Plate, Push Rod	1
60	1.5789.0865	Flange Bolt M8×65	2
61	1.5789.0845	Flange Bolt M8×45	2
62	2.01.020	Stud Bolt (M6×97)	2
63	83.040010.01	Bolt, Rocker Arm	2
64	83.040005.01	Push Rod	2
65	83.040003.01	Spring, Valve	2
66	83.040009.01	Rocker Arm, Intake Valve	2
67	83.040001.01	Retainer, Valve Spring (Up)	2
68	83.040014.01	Valve Collet	2
69	21.040020.00	Adjusting Nut, Valve	2
70	21.040021.00	Nut, Lock	2
71	83.080200.01	Air Shroud, Cylinder	1
72	23.020001.01	Breather Tube	1
73	83.021101.01	Cover, Cylinder Head	1
74	83.021001.01	Gasket, Cylinder Head Element	1
75	83.021200.01	Element Component, Head Cover	1
76	83.020002.01	Gasket, Cylinder Head Cover	
77	83.050301.01	Ring, First Piston	
78	83.050302.01	Ring, Second Piston	
79	83.050303.01	Ring, Oil	
80	2.09.002	Circlip (Ø16ר1)	
81	83.050005.01	Piston	1
82	83.050003.01	Piston Pin	1
83	83.050200.01	Connecting Rod	1
84	83.040100.01	Camshaft	1
85	83.031000.01	Oil Dipstick Assembly	1
86	83.030035.01	Oil Nipple	1
87	1.818.0306	Screw M3×6	2
88	81.132200.00	Stepper Motor, Throttle Valve	1
89	1.9074.1.0408	Screw M4×8	2
90	82.132100.00	Stepper Motor Base	1
91	1.819.0508	Screw M5×8	1
92	81.130010.00	Spring, Connector	1
93	81.130008.00	Connector, Choke Valve Axis	1
94	83.131000.01	Carburetor	1
	83.131000.03		<u> </u>
95	1.9074.3.0512	Screw M5×12	1
96	81.130007.00	Clamp Board, Choke Control Line	1
97	83.130005.01	Support, Stepper Motor	2
98	1.9074.3.0508	Screw M5×8	
99	83.131017.01	Standard Main Jet	1
100	83.131017.01.01	Altitude Main Jet	/
100	83.061000.01	Recoil Assembly	1
101	83.091000.01	Air Cleaner Assembly	
102	83.021000.01	Cylinder Head Cover	1
103	2.06.013	Clamp, Ø13.5 × b10	1
104	45.030200.00	Support	1

Wiring Diagram



Problem	Cause	Solution
Generator will not start	No fuel	Add fuel
	Faulty spark plug	Replace spark plug
	Unit loaded during start up	Remove load from unit
Generator will not start;	Low oil level	Fill crankcase to the proper level
Generator starts but runs roughly		Place generator on a flat, level surface
	Choke in the wrong position	Adjust choke
	Spark plug wire loose	Attach wire to spark plug
Generator shuts down during operation	Out of fuel	Fill fuel tank
	Low oil level	Fill crankcase to the proper level. Place generator on a flat, level surface
Generator cannot supply enough power or overheating	Generator is overloaded	Review load and adjust. See "Power Management"
	Insufficient ventilation	Check for air restriction. Move to a well ventilated area
No AC output	Cable not properly connected	Check all connections
	Connected device is defective	Replace defective device
	Circuit breaker is open	Reset circuit breaker
	Loose wiring	Inspect and tighten wiring connections
	Other	Contact the help line
Repeated circuit breaker tripping	Overload	Review load and adjust. See "Power Management"
	Faulty cords or device	Check for damaged, bare or frayed wires. Replace defective device

For further technical support:

Technical Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

tech@championpowerequipment.com

WARRANTY*

CHAMPION POWER EQUIPMENT
3 YEAR LIMITED WARRANTY

Warranty Qualifications

Champion Power Equipment (CPE) will register this warranty upon receipt of your Warranty Registration Card and a copy of your sales receipt from one of CPE's retail locations as proof of purchase. Please submit your warranty registration and your proof of purchase within ten (10) days of the date of purchase.

Repair/Replacement Warranty

CPE warrants to the original purchaser that the mechanical and electrical components will be free of defects in material and workmanship for a period of three years (parts and labor) from the original date of purchase and 270 days (parts and labor) for commercial and industrial use. Transportation charges on product submitted for repair or replacement under this warranty are the sole responsibility of the purchaser. This warranty only applies to the original purchaser and is not transferable.

Do Not Return The Unit To The Place Of Purchase

Contact CPE's Technical Service and CPE will troubleshoot any issue via phone or e-mail. If the problem is not corrected by this method, CPE will, at its option, authorize evaluation, repair or replacement of the defective part or component at a CPE Service Center. CPE will provide you with a case number for warranty service. Please keep it for future reference. Repairs or replacements without prior authorization, or at an unauthorized repair facility, will not be covered by this warranty.

Warranty Exclusions

This warranty does not cover the following repairs and equipment:

Normal Wear

Products with mechanical and electrical components need periodic parts and service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

Installation, Use and Maintenance

This warranty will not apply to parts and/or labor if the product is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond the product's limits, modified, installed improperly or connected incorrectly to any electrical component. Normal maintenance is not covered by this warranty and is not required to be performed at a facility or by a person authorized by CPE.

Other Exclusions

This warranty excludes:

- Cosmetic defects such as paint, decals, etc.
- Wear items such as filter elements, o-rings, etc.
- Accessory parts such as starting batteries, and storage covers.
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not original Champion Power Equipment parts.

When applicable, this warranty does not apply to products used for prime power in place of a utility.

Limits of Implied Warranty and Consequential Damage

Champion Power Equipment disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this product. THIS WARRANTY AND THE ATTACHED U.S. EPA, CARB and/or ECCC EMISSION CONTROL SYSTEM WARRANTIES (WHEN APPLICABLE) ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

A unit provided as an exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit.

This warranty gives you certain legal rights which may change from state to state or province to province. Your state or province may also have other rights you may be entitled to that are not listed within this warranty.

Contact Information

Address

Champion Power Equipment, Inc. Customer Service 12039 Smith Ave. Santa Fe Springs, CA 90670 USA www.championpowerequipment.com

Customer Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

info@championpowerequipment.com

Fax no.: 1-562-236-9429

Technical Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

tech@championpowerequipment.com 24/7 Tech Support: 1-562-204-1188

^{*}Except as otherwise stipulated in any of the following enclosed Emission Control System Warranties (when applicable) for the Emission Control System: U.S. Environment Protection Agency (EPA), California Air Resources Board (CARB) and/or Environment and Climate Change Canada (ECCC). Whichever warranty applies for the longer period, either this 3 year limited warranty or the applicable Emission Control System Warranty, shall supersede the other.

Champion Power Equipment, Inc. (CPE), The United States Environment Protection Agency (U.S. EPA.) and the California Air Resources Board (CARB) Emission Control System Warranty

Your Champion Power Equipment (CPE) engine complies with both the U.S. EPA and state of California Air Resources Board (CARB) emission regulations.

YOUR WARRANTY RIGHTS AND OBLIGATIONS:

The US EPA, California Air Resources Board, and CPE are pleased to explain the Federal and California Emission Control Systems Warranty on your 2017 small off-road engine and engine powered equipment. In California, new, small off-road engines and new equipment that use small off-engines must be designed, built and equipped to meet the State's stringent anti smog standards. In the other states, new engines and equipment must be designed, built and equipped, at the time of sale, to meet U.S. EPA regulations for small non-road engines. CPE warrants the emission control system on your small off-road engine and equipment for the period of time listed below, provided there has been no abuse, neglect, unapproved modification, or improper maintenance of your equipment.

Your emission control system may include parts such as the carburetor, fuel-injection system, the ignition system, catalytic converter and fuel lines. Also included may be hoses, belts, connectors and other emission related assemblies. Where a warrantable condition exits, CPE will repair your small off-road engine at no cost to you including diagnosis, parts and labor. For engines less than or equal to 80cc, only the fuel tank and fuel line is subject to the evaporative emission control warranty requirements of this section.

MANUFACTURER'S EMISSION CONTROL SYSTEM WARRANTY COVERAGE:

This emission control system is warranted for two years, subject to provisions set forth below. If, during the warranty period, emission related part on your engine is defective in materials or workmanship, the part will be repaired or replaced by CPE.

OWNER WARRANTY RESPONSIBILITIES:

As the small off-road engine owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. CPE recommends that you retain all your receipts covering maintenance on your small off-road engine, but CPE cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the small off-road engine owner, you should however be aware that CPE may deny you warranty coverage if your small, off-road engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine to an Authorized CPE service outlet or alternate service outlet as described in (3)(f.) below, CPE dealer or CPE, Santa Fe Springs, Ca. as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities, you should contact:

Champion Power Equipment, Inc.
Customer Service
12039 Smith Ave.
Santa Fe Springs, CA 90670
1-877-338-0999
tech@championpowerequipment.com

EMISSION CONTROL SYSTEM WARRANTY

The following are specific provisions relative to your Emission Control System (ECS) Warranty Coverage.

1. APPLICABILITY: This warranty shall apply to 1995 and later model year California small off-road engines (for other states, 1997 and later model year engines). The ECS Warranty Period shall begin on the date the new engine or equipment is delivered to its original, end-use purchaser, and shall continue for 24 consecutive months thereafter.

2. GENERAL EMISSIONS WARRANTY COVERAGE

CPE warrants to the original, end-use purchaser of the new engine or equipment and to each subsequent purchaser that each of its small off-road engines is:

- a. Designed, built and equipped so as to conform to U.S. EPA emissions standards for spark-ignited engines at or below 19 kilowatts and all applicable regulations adopted by the California Air Resources Board and
- b. Free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the engine manufacturer's application for certification for a period of two years.

3. THE WARRANTY ON EMISSION-RELATED PARTS WILL BE INTERPRETED AS FOLLOWS:

- a. Any warranted part that is not scheduled for replacement as required maintenance in the Owners Manual shall be warranted for the ECS Warranty Period. If any such part fails during the ECS Warranty Period, it shall be repaired or replaced by CPE according to Subsection "d" below. Any such part repaired or replaced under the ECS Warranty shall be warranted for any remainder of the ECS Warranty Period.
- b. Any warranted, emissions-related part which is scheduled only for regular inspection as specified in the Owners Manual shall be warranted for the ECS Warranty Period. A statement in such written instructions to the effect of "repair or replace as necessary", shall not reduce the ECS Warranty Period. Any such part repaired or replaced under the ECS Warranty shall be warranted for the remainder of the ECS Warranty Period.
- c. Any warranted, emissions-related part which is scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part shall be repaired or replaced by CPE according to Subsection "d" below. Any such emissions-related part repaired or replaced under the ECS Warranty, shall be warranted for the remainder of the ECS Warranty Period prior to the first scheduled replacement point for such emissions-related part.
- d. Repair or replacement of any warranted, emissions-related part under this ECS Warranty shall be performed at no charge to the owner at a CPE Authorized Service Outlet.
- e. The owner shall not be charged for diagnostic labor which leads to the determination that a part covered by the ECS Warranty is in fact defective, provided that such diagnostic work is performed at a CPE Authorized Service Outlet.
- f. CPE shall pay for covered emissions warranty repairs at non-authorized service outlets under the following circumstances:
- i. The service is required in a population center with a population over 100,000 according to U.S. Census 2000 without a CPE Authorized Service Outlet AND
- ii. The service is required more than 100 miles from a CPE Authorized Service Outlet. The 100 mile limitation does not apply in the following states: Alaska, Arizona, Colorado, Hawaii, Idaho, Montana, Nebraska, Nevada, New Mexico, Oregon, Texas, Utah and Wyoming.
- g. CPE shall be liable for damages to other original engine components or approved modifications proximately caused by a failure under warranty of an emission-related part covered by the ECS Warranty.
- h. Throughout the ECS Warranty Period, CPE shall maintain a supply of warranted emission-related parts sufficient to meet the expected demand for such emission-related parts.
- i. Any CPE Authorized and approved emission-related replacement part may be used in the performance of any ECS Warranty maintenance or repair and will be provided without charge to the owner. Such use shall not reduce CPE's warranty obligation.
- j. Unapproved add-on or modified parts may not be used to modify or repair a CPE engine. Such use voids this ECS Warranty and shall be sufficient grounds for disallowing an ECS Warranty claim. CPE shall not be liable hereunder for failures of any warranted parts of a CPE engine caused by the use of such an unapproved add-on or modified part.

EMISSION-RELATED PARTS INCLUDE THE FOLLOWING: (using those portions of the list applicable to the engine)

Systems covered by this warranty	Parts Description
Fuel Metering System	Fuel regulator, Carburetor and internal parts
Air Induction System	Air cleaner, Intake manifold
Ignition System	Spark plug and parts, Magneto ignition system
Exhaust System	Exhaust manifold, catalytic converter
Miscellaneous Parts	Tubing, Fittings, Seals, Gaskets, and Clamps associated with these listed systems.
Evaporative Emissions	Fuel Tank, Fuel Cap, Fuel Line, Fuel Line Fittings, Clamps, Pressure Relief Valves, Control Valves, Control Solenoids, Electronic Controls, Vacuum Control Diaphragms, Control Cables, Control Linkages, Purge Valves, Vapor Hoses, Liquid/Vapor Separator, Carbon Canister, Canister Mounting Brackets, Carburetor Purge Port Connector

TO OBTAIN WARRANTY SERVICE:

You must take your CPE engine or the product on which it is installed, along with your warranty registration card or other proof of original purchase date, at your expense, to any Champion Power Equipment dealer who is authorized by Champion Power Equipment, Inc. to sell and service that CPE product during his normal business hours. Alternate service locations defined in Section (3)(f.) above must be approved by CPE prior to service. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you have any questions regarding your warranty rights and responsibilities, or to obtain warranty service, please write or call Customer Service at Champion Power Equipment, Inc.

Champion Power Equipment, Inc. 12039 Smith Ave. Santa Fe Springs, CA 90670 1-877-338-0999 Attn.: Customer Service tech@championpowerequipment.com