

21R700

Illustrated Parts List

Model Series

21R700

TYPE NUMBERS

0001, 0002, 0003, 0003, 0004, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013,
0014, 0015, 0016, 0017, 0018, 0019, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027, 0028,
0029, 0030, 0031, 0032, 0033, 0034, 0035, 0036, 0037, 0038, 0039, 0040, 0041, 0042, 0043,
0044, 0045, 0046, 0047, 0048, 0049, 0050, 0051, 0052, 0053, 0054, 0055, 0056, 0058, 0059,
0060, 0061, 0062, 0063, 0064, 0065, 0066, 0067, 0068, 0069, 0070, 0071, 0072, 0073, 0074,
0075, 0076, 0077, 0078, 0079, 0080, 0081, 0082, 0083, 0084, 0085, 0086, 0087, 0088, 0089,
0090, 0091, 0092, 0093, 0094, 0095, 0096, 0097, 0098, 0099, 0100, 0101, 0102, 0103, 0104,
0105, 0106, 0107, 0108, 0109, 0110, 0111, 0112, 0113, 0114, 0115, 0116, 0117, 0118, 0119,
0120, 0121, 0122, 0123, 0124.

Not for
Reproduction










PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without
permission
in writing from Briggs & Stratton Corporation






1036 EMISSIONS LABEL





















121A CARBURETOR OVERHAUL KIT			
51	104A	137A	617
51A	105A	137A	633
98A	127A	137A	633B
	217	276A	1266








24 



729A 

697 

21R700



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 10481-8 Assemblies include all parts shown in frames. 05/13/2016

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697377	Cylinder Assembly	23	591759	Flywheel	24	591757	Key-Flywheel
2	797673	Kit-Bushing/Seal (Magnetos Side)			----- Note -----	25	595053	Piston Assembly (Standard)
3	391086s	Seal-Oil (Magnetos Side)			591758 Flywheel			----- Note -----
4	697106	Sump-Engine			Used on Type No(s).			595054 Piston Assembly (.020" Oversize)
4A	592849	Sump-Engine			0006, 0012, 0017, 0022, 0030, 0094, 0124.	26	797011	Ring Set (Standard)
		Used on Type No(s).	23A	591950	Flywheel			----- Note -----
		0025, 0027, 0031, 0033, 0037, 0044, 0053, 0058, 0067, 0074, 0088, 0091, 0094, 0099, 0100, 0102, 0113, 0114, 0119.			Used on Type No(s).			792643 Ring Set (.020" Oversize)
4B	799738	Sump-Engine			0003, 0014, 0020, 0025, 0031, 0036, 0038, 0041, 0042, 0043, 0044, 0051, 0061, 0065, 0067, 0070, 0072, 0074, 0075, 0078, 0085, 0087, 0089, 0091, 0092, 0095, 0096, 0101, 0106, 0114, 0121, 0122, 0123.	27	698469	Lock-Piston Pin
		Used on Type No(s).			0002, 0016, 0037, 0049, 0050, 0053, 0058, 0062, 0079, 0102, 0107, 0109, 0112, 0113, 0119, 0120, .	28	797013	Pin-Piston
5	796183	Head-Cylinder			----- Note -----	29	791633	Rod-Connecting (Standard)
7	273280s	Gasket-Cylinder Head	23B	591760	Flywheel	32	791118	Screw (Connecting Rod)
11	794683	Tube-Breather			Used on Type No(s).	33	792868	Valve-Exhaust (Chrome)
12	697110	Gasket-Crankcase (.015" Thick) (Standard)			0001, 0007, 0011, 0013, 0023, 0024, 0028, 0033, 0046, 0047, 0052, 0054, 0055, 0056, 0059, 0064, 0066, 0069, 0077, 0080, 0083, 0090, 0093, 0097, 0099, 0108, 0110, 0111, 0116, 0117.	34	791935	Valve-Intake
13	690360	Screw (Cylinder Head)				35	691279	Spring-Valve (Intake)
14	790560	Stud (Cylinder Head)				36	691279	Spring-Valve (Exhaust)
15	690946	Plug-Oil Drain (3/8" Standard)				37	697352	Guard-Flywheel
16	593417	Crankshaft				37A	697626	Guard-Flywheel
		----- Note -----				42	499586	Keeper-Valve
		591949 Crankshaft				43	691968	Slinger-Governor/Oil
		Used on Type No(s).				45	690564	Tappet-Valve
		0003, 0009, 0010, 0015, 0017, 0018, 0019, 0034, 0036, 0042, 0045, 0048, 0063, 0076, 0080, 0084, 0090, 0095, 0101, 0103, 0115.				46	793880	Camshaft
20	795387	Seal-Oil (PTO Side)				50	592845	Manifold-Intake
22	692125	Screw (Crankcase Cover/Sump)				51	692137	Gasket-Intake
						51A	796081	Gasket-Intake
						53	591260	Stud (Carburetor)
						54	691148	Screw (Intake Manifold)

21R700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	695130	Housing-Rewind Starter	117	591936	Jet-Main (Standard)	118	696134	Jet-Main (High Altitude)
56	695129	Pulley-Starter			----- Note -----			----- Note -----
57	695131	Spring-Rewind Starter		791405	Jet-Main		698788	Jet-Main
58	695132	Rope-Starter			Used on Type No(s).			Used on Type No(s).
60	490652	Grip-Starter Rope			0004, 0005, 0006,			0004, 0005, 0006,
65	690940	Screw			0008, 0009, 0010,			0008, 0009, 0010,
		(Starter-Rewind)			0012, 0015, 0017,			0012, 0015, 0017,
78	691693	Screw			0018, 0019, 0021,			0018, 0019, 0021,
		(Flywheel Guard)			0022, 0030, 0032,			0022, 0030, 0032,
78A	690364	Screw			0033, 0034, 0035,			0033, 0034, 0035,
		(Flywheel Guard)			0039, 0040, 0042,			0039, 0040, 0042,
81	691178	Lock-Muffler Screw			0047, 0048, 0053,			0047, 0048, 0053,
94A	793610	Kit-Idle Mixture (Nikki)			0063, 0068, 0073,			0063, 0068, 0073,
95A	690718	Screw			0076, 0077, 0081,			0076, 0077, 0081,
		(Throttle Valve)(Nikki)			0084, 0098, 0102,			0084, 0098, 0102,
98A	695408	Kit-Idle Speed (Nikki)			0103, 0104, 0105,			0103, 0104, 0105,
					0115, 0117, 0118,			0115, 0117, 0118,
					0124.			0124.
104A	694918	Pin-Float Hinge (Nikki)		791405	Jet-Main		698788	Jet-Main
105A	696136	Valve-Float Needle (Nikki)			(Used Before Code			(Used Before Code
108A	698773	Valve-Choke (Nikki)			Date 13092400).			Date 13092400).
					Used on Type No(s).			Used on Type No(s).
112	593040	Screw			0001, 0002, 0003,			0001, 0002, 0003,
		(Choke Lever)			0007, 0011, 0013,			0007, 0011, 0013,
					0014, 0016, 0020,			0014, 0016, 0020,
					0023, 0024, 0025,			0023, 0024, 0025,
					0026, 0027, 0028,			0026, 0027, 0028,
					0029, 0031, 0036,			0029, 0031, 0036,
					0037, 0038, 0041,			0037, 0038, 0041,
					0043, 0044, 0069,			0043, 0044, 0069,
					0074, 0079, 0080,			0074, 0079, 0080,
					0083, 0086.			0083, 0086.
						121A	796184	Kit-Carburetor Overhaul (Nikki)
						125	590400	Carburetor (With Solenoid) Used on Type No(s). 0045, 0046, 0047.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
125A	593432	Carburetor ----- Note ----- 594597 Carburetor Used on Type No(s). 0113. 593432 Carburetor (Used After Code Date 13092300). Used on Type No(s). 0001, 0002, 0003, 0007, 0011, 0013, 0014, 0016, 0020, 0023, 0024, 0025, 0026, 0027, 0028, 0029, 0031, 0036, 0037, 0038, 0041, 0043, 0044, 0069, 0074, 0079, 0080, 0083, 0086. 590399 Carburetor Used on Type No(s). 0004, 0005, 0006, 0008, 0009, 0010, 0012, 0015, 0017, 0018, 0019, 0021, 0022, 0030, 0032, 0033, 0034, 0035, 0039, 0040, 0042, 0047, 0048, 0053, 0063, 0065, 0068, 0073, 0075, 0076, 0077, 0081, 0084, 0087, 0098, 0100, 0102, 0103, 0104, 0105, 0115, 0117, 0118, 0124. 590399 Carburetor (Used Before Code Date 13092400). Used on Type No(s). 0001, 0002, 0003, 0007, 0011, 0013, 0014, 0016, 0020, 0023, 0024, 0025, 0026, 0027, 0028, 0029, 0031, 0036, 0037, 0038, 0041, 0043, 0044, 0069, 0074, 0079, 0080, 0083, 0086.	135A	796400	Tube-Fuel Transfer ----- Note ----- 698780 Tube-Fuel Transfer Used on Type No(s). 0004, 0005, 0006, 0008, 0009, 0010, 0012, 0015, 0017, 0018, 0019, 0021, 0022, 0030, 0032, 0033, 0034, 0035, 0039, 0040, 0042, 0047, 0048, 0053, 0063, 0065, 0068, 0073, 0075, 0076, 0077, 0081, 0084, 0087, 0098, 0100, 0102, 0103, 0104, 0105, 0115, 0117, 0118, 0124.	209	792813	Spring-Governor (Brown) ----- Note ----- 792602 Spring-Governor (Red) Used on Type No(s). 0007, 0011, 0015, 0016, 0018, 0023, 0024, 0025, 0029, 0030, 0031, 0039, 0042, 0044, 0045, 0047, 0048, 0050, 0063, 0067, 0068, 0073, 0076, 0081, 0083, 0089, 0098, 0105, 0114. 796260 Spring-Governor (Green) Used on Type No(s). 0009, 0010, 0012, 0017, 0019, 0021, 0022, 0026, 0027, 0033, 0035, 0053, 0081, 0102, 0113, 0124. 796261 Spring-Governor (Yellow) Used on Type No(s). 0004, 0005, 0006, 0032, 0040, 0097, 0099, 0100. 691278 Spring-Governor Used on Type No(s). 0003. 260902 Spring-Governor (Natural) Used on Type No(s). 0103, 0115, 0118.
127A	690727	Plug-Welch	137A	698781	Gasket-Float Bowl	216	691840	Link-Choke
130A	698774	Valve-Throttle (Nikki)	141A	698778	Kit-Choke Shaft	216A	691281	Link-Choke
131A	698776	Kit-Throttle Shaft (Nikki)	186	794873	Hose-Connector (Intake Manifold)	216B	593043	Link-Choke (Ready Start)
133A	694914	Float-Carburetor (Nikki)	186A	796532	Hose-Connector	217	695409	Spring-Choke Return
			187	791766	Line-Fuel (Straight)(Cut to Required Length)	222	694042	Bracket-Control
			187A	796491	Line-Fuel (Formed)(Cut To Required Length)	222A	694335	Bracket-Control Used on Type No(s). 0043.
			187B	791805	Line-Fuel (Formed)(Cut To Required Length)	226	793386	Kit-Choke Shaft (Manual Choke)
			187D	791744	Line-Fuel (Formed)(Cut To Required Length)			
			188	691693	Screw (Control Bracket)			
			190	796174	Screw (Fuel Tank)			
			192	691986	Adjuster-Rocker Arm			
			202	691841	Link-Mechanical Governor			
			203	691381	Crank-Bell			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

21R700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
227	691374	Lever-Governor Control	318	594384	Screw (Snap Switch)	422A	593056	Switch-Snap
227A	694339	Lever-Governor Control	324	593933	Screen-Rotating	431B	797901	Elbow-Intake (EVAP)
		Used on Type No(s). 0043.	333	799650	Armature-Magneto	445B	591583	Filter-Air Cleaner Cartridge (Canister Style)
232	691842	Spring-Governor Link	333A	595304	Armature-Magneto			
238	691843	Cap-Valve	334	691061	Screw (Magneto Armature)	455	695113	Cup-Flywheel Used on Type No(s). 0101.
239	694115	Switch-Oil Pressure	337	792015	Plug-Spark (Resistor/EMS)	455A	796615	Cup-Starter
		----- Note -----			----- Note -----	456	695128	Plate-Pawl Friction
		491657s Switch-Oil Pressure			491055s Plug-Spark (Resistor)	459	281505s	Pawl-Ratchet
		Used on Type No(s). 0058.			Used on Type No(s). 0001, 0002, 0003, 0007, 0011, 0013, 0014, 0015, 0028, 0031, 0034, 0038, 0039, 0040, 0041, 0042, 0043, 0044, 0045, 0047, 0048, 0049, 0050, 0051, 0052, 0053, 0055, 0056, 0058, 0059, 0060, 0061, 0062, 0064, 0066, 0067, 0069, 0071, 0072, 0080, 0085, 0094, 0095, 0096, 0101, 0105, 0106, 0109, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123.	462	691261	Washer (Starter Cable)
240	394358s	Filter-Fuel (White, 75 Microns)				474A	592828	Alternator (DC Only) Used on Type No(s). 0019, 0026, 0027, 0032, 0039, 0063, 0081, 0097, 0099, 0105.
240A	691035	Filter-Fuel						
265	691024	Clamp-Casing				474B	592831	Alternator (Dual Circuit) Used on Type No(s). 0004, 0005, 0007, 0009, 0010, 0011, 0015, 0018, 0023, 0024, 0028, 0029, 0033, 0034, 0035, 0040, 0045, 0047, 0048, 0052, 0064, 0066, 0068, 0073, 0076, 0077, 0082, 0083, 0084, 0086, 0088, 0090, 0093, 0100, 0104, 0108, 0115, 0117, 0118.
267	794904	Screw (Casing Clamp)				474C	592829	Alternator (Tri Circuit)
268	691025	Casing-Control Wire (Cut To Required Length)				474D	592830	Alternator (10-16 AMP) Used on Type No(s). 0037, 0050, 0053, 0058, 0079, 0102.
269	691026	Wire-Control (Cut To Required Length)						
270	691027	Nut (Control Wire Casing)				501	794360	Regulator
271	691028	Lever-Control				501A	698315	Regulator Used on Type No(s). 0016, 0055, 0056, 0062, 0107, 0112.
276A	695410	Washer-Sealing						
300	796000	Muffler				501D	845907	Regulator Used on Type No(s). 0037, 0050, 0053, 0058, 0079, 0102.
		----- Note -----						
		592322 Muffler Used on Type No(s). 0039, 0105.						
300B	795997	Muffler						
304G	591641	Housing-Blower (Black-Compatible With Canister Style Filter)	346	794845	Screw (Spark-Arrester)			
			356	398808	Wire-Stop			
305	697102	Screw (Blower Housing)	356A	697397	Wire-Stop			
305B	795891	Screw (Blower Housing To Intake Elbow)	356B	697089	Wire-Stop			
305C	799370	Screw (Grommet Style Blower Housing)	357	691483	Key-Drive Pulley			
			358	796181	Gasket Set-Engine			
306	592778	Shield-Cylinder	363	19203	Puller-Flywheel			
307	691693	Screw (Cylinder Shield)	377	691639	Key-Woodruff			
309	593934	Motor-Starter	383	19576s	Wrench-Spark Plug (Fuel Pump)			
310	690323	Screw (Starter Motor)						
			387	808656	Pump-Fuel			
			404	691691	Washer (Governor Crank)			
			415	794903	Plug (Intake Manifold)			
			415A	794129	Plug (Cover/Retainer)			

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
503	691532	Strap-Starter	633B	690998	Seal-Throttle Shaft (Nikki)	797	693167	Nut (Brush Retainer)
505	691251	Nut (Governor Control Lever)	634A	698779	Spring/Seal Assembly (Nikki)	801	691283	Cap-Drive
510	693699	Drive-Starter	635	691909	Boot-Spark Plug	802	691286	Cap-End
512	594200	Hose-Oil Drain	654	690958	Nut (Carburetor)	823	698941	Screw (Muffler Adapter)
513	692024	Clutch-Drive	670	796175	Spacer-Fuel Tank	830	691095	Stud-Rocker Arm
521	690581	Shield-Cable	676	795036	Deflector-Muffler (Side Out)	832	790244	Guard-Muffler
523	699908	Dipstick	676A	396903	Deflector-Muffler (Direct Out)	----- Note -----		
524	691032	Seal-Dipstick Tube	676B	795038	Deflector-Muffler (Louvered)	832A	595029	Guard-Muffler
525	697085	Tube-Dipstick (With Tube Connector)	677	690661	Screw (Muffler Deflector) (#8-18 x 0.375 Lg)	832B	706336	Guard-Muffler
525A	697184	Tube-Dipstick (Without Tube Connector)	----- Note -----			836	690367	Screw-Tapping (Guard-Muffler)
526	697088	Screw (Regulator)	684	697157	Screw (Breather Assembly)	842	691031	Seal-O Ring (Dipstick Tube)
526B	697348	Screw (Regulator)	689	691855	Spring-Friction	847	790443	Dipstick/Tube Assembly (With Hose Nipple)
552	697144	Bushing-Governor Crank	691	692407	Seal-Governor Shaft	847A	790442	Dipstick/Tube Assembly (Without Hose Nipple)
562	691119	Bolt (Governor Control Lever)	697	791680	Screw (Drive Cap)	850	100106	Sealant-Liquid (Rocker Cover Gasket and Breather Gasket)
563A	799359	Screw (Debris Guard)	705	790561	Nut (Fuel Tank)	851	692424	Terminal-Spark Plug
578	692306	Wire Assembly	718	690959	Pin-Locating	864	796002	Adapter-Muffler (Length 2.25 Inches)
579	691029	Nut (Starter Cable)	729A	691224	Clip-Wire (Starter Motor)	----- Note -----		
584	794682	Cover-Breather Passage (Use With Liquid Sealant Reference 850)	741	697128	Gear-Timing	592323	Adapter-Muffler (Length 1.75 Inches) Used on Type No(s). 0039.	
597	691696	Screw	750	790832	Screw (Oil Pump Cover)	868	690968	Seal-Valve
598	799739	Shim-End Play	757	793242	Counterweight	877	393456	Wire/Connector-Alternator (Dual Circuit)
601	791850	Clamp-Hose (Green)	758	593418	Counterweight	877D	790544	Wire/Connector-Alternator
608	593939	Starter-Rewind (Metal) Used on Type No(s). 0101.	759	697392	Pin-Counterweight	878	398661	Harness-Alternator (Dual Circuit)
608A	591606	Starter-Rewind	773	796448	Retainer	878A	691955	Harness-Alternator (Tri Circuit)
613	691416	Screw (Muffler)	783	593935	Gear-Pinion	883	692236	Gasket-Exhaust
613A	691678	Screw (Muffler)	789	698329	Harness-Wiring	914	691108	Screw (Rocker Cover)
613B	690297	Screw (Muffler)	789A	594433	Harness-Wiring	920	691656	Solenoid-Starter
614	691620	Pin-Cotter	789B	594434	Harness-Wiring (Used After Code Date 14080600). Used on Type No(s). 0100.	943	690589	O-Ring
616	692012	Crank-Governor	789C	594359	Harness-Wiring (Used Before Code Date 14080700) Used on Type No(s). 0100.	947	699915	Solenoid-Fuel
617	692138	Seal-O Ring (Intake Manifold)	789D	594999	Harness-Wiring Used in Conjunction with Regulator 698315	949A	799358	Guard-Debris Screen
633	699813	Seal-Choke/Throttle Shaft (Nikki)				951	593039	Lever-Choke (Ready Start)

21R700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
957	795027	Cap-Fuel Tank (Standard)	994	794945	Spark-Arrestor	1051	691265	Ring-Retaining
957A	799719	Cap-Fuel Tank (Carbon In Cap)	1005	796082	Fan-Flywheel	1059	698516	Kit-Screw/Washer
958	698183	Valve-Fuel Shut Off	1017	796981	Screen-Oil Pump	1090	691293	Retainer-Brush
964	799159	Cap-Connector (EVAP)	1022	272475s	Gasket-Rocker Cover	1091	691333	Cap-Limiter
965	499613	Cover-Oil Pump	1023	797421	Cover-Rocker	1095	796189	Gasket Set-Valve
968B	591646	Cover-Air Cleaner (Black-Compatible With Canister Style Filter)	1024A	794644	Pump-Oil	1119	691183	Screw (Alternator)
972	799111	Tank-Fuel (Fluorinated)	1026	794573	Rod-Push (Exhaust)	1127	695407	Screw (Float Bowl)
972A	792168	Tank-Fuel Used on Type No(s). 0023, 0024, 0025, 0052, 0067, 0072, 0091, 0099, 0108, 0114.	----- Note -----			1139	796449	Washer
975	698783	Bowl-Float (Without Solenoid)	1027	492932s	Filter-Oil	1146	793380	Screw (Choke Shaft)(Manual Choke)
975A	796400	Bowl-Float (With Solenoid)	----- Note -----			1263	697124	Reed-Breather
						1264	697104	Screw (Breather Reed)
			1029	691751	Arm-Rocker	1266	691917	Seal-O Ring (Intake Elbow)
			1034	690822	Guide-Push Rod Label-Emissions (Available From A Briggs & Stratton Authorized Dealer)	1270	793243	Plug-AVS Counterweight
			1036			1319	794467	Label-Warning
			1040	698368	Plate-Trim (Black)	1319A	797669	Label-Warning
			1040A	697381	Plate-Trim (Black)	1448	690260	Washer (Magneto Armature)
			1044	698139	Screw (Flywheel)	1478	593037	Solenoid-Choke (Ready Start)
						1479	593041	Screw (Choke Solenoid)
						1479A	593042	Screw (Choke Solenoid)

Not for
Reproduction

Not for
Reproduction

