

19J100

Illustrated Parts List

Model Series

19J100

TYPE NUMBERS


0001, 0002, 0004, 0005, 0006, 0007, 0008, 0009, 0010.

Not for
Reproduction








PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without
permission
in writing from Briggs & Stratton Corporation





Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.













Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.









Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	593663	Cylinder Assembly	26	592614	Ring Set (Standard)	202	591834	Link-Mechanical Governor
3	591794	Seal-Oil (Magneto Side)			----- Note -----	209	593657	Spring-Governor
5	593093	Head-Cylinder		593110	Ring Set (.010" Oversize)	211	799927	Spring-Governed Idle
7A	592834	Gasket-Cylinder Head		593111	Ring Set (.020" Oversize)	222A	593666	Bracket-Control
12A	592597	Gasket-Crankcase	27	592044	Lock-Piston Pin	227	592616	Lever-Governor Control
13	797791	Screw (Cylinder Head)	28	592045	Pin-Piston	232	797809	Spring-Governor Link
15	797793	Plug-Oil Drain	29	592046	Rod-Connecting	238	591817	Cap-Valve
16	593662	Crankshaft Used on Type No(s). 0001, 0002, 0007, 0009.	33	592612	Valve-Exhaust	265	691024	Clamp-Casing
		----- Note -----	34	592611	Valve-Intake	267	699492	Screw (Casing Clamp)
		593691 Crankshaft Used on Type No(s). 0005, 0006.	35	591814	Spring-Valve (Intake)	268	691025	Casing-Control Wire (Cut To Required Length)
		594631 Crankshaft Used on Type No(s). 0004.	36	591814	Spring-Valve (Exhaust)	269	691026	Wire-Control (Cut To Required Length)
17	591792	Bearing-Ball (Crankshaft)	40A	797782	Retainer-Valve	270	691027	Nut (Control Wire Casing)
18C	593661	Cover-Crankcase (Includes Governor Gear - Not Serviced Separately)	40B	591815	Retainer-Valve	271	691028	Lever-Control
20	591793	Seal-Oil (PTO Side)	40C	591816	Retainer-Valve	276	797847	Washer-Sealing (Rocker Cover)
22	797776	Screw (Crankcase Cover/Sump)	45	797786	Tappet-Valve	281C	593677	Panel-Control
22A	593107	Screw (Crankcase Cover/Sump)	46	592617	Camshaft	287	798618	Screw (Dipstick Tube)
23	593139	Flywheel Used on Type No(s). 0001, 0002, 0007, 0008, 0009.	51	591779	Gasket-Intake	300E	593186	Muffler-Exhaust
		----- Note -----	51A	591798	Gasket-Intake	304	593672	Housing-Blower
		593690 Flywheel Used on Type No(s). 0004, 0005, 0006, 0010.	53	591801	Stud (Carburetor)	305	798618	Screw (Blower Housing)
24	797812	Key-Flywheel	58	691921	Rope-Starter (Cut to Required Length)	306B	593680	Shield-Cylinder
25	592613	Piston Assembly (Standard)	65	799923	Screw (Rewind Starter)	307	798618	Screw (Cylinder Shield)
		----- Note -----	98	593104	Kit-Idle Speed (High Speed Adjustment)	309A	593684	Motor-Starter Used on Type No(s). 0002, 0004, 0005, 0006, 0009, 0010.
		593108 Piston Assembly (.010" Oversize)	109	593178	Shaft-Choke			----- Note -----
		593109 Piston Assembly (.020" Oversize)	117	593675	Jet-Main (Standard)			593683 Motor-Starter Used on Type No(s). 0001, 0007, 0008.
			118	590452	Jet-Main (High Altitude)	318	799814	Screw (Mounting Bracket)
			121C	592229	Kit-Carburetor Overhaul	318A	799846	Screw (Mounting Bracket)
			122	591797	Spacer-Carburetor	332	797811	Nut (Flywheel)
			125E	593674	Carburetor	333A	798616	Armature-Magneto
			163	797756	Gasket-Air Cleaner	334	797655	Screw (Magneto Armature)
			187E	593671	Line-Fuel (Formed Hose)			
			187F	593670	Line-Fuel (Formed Hose)			
			188	798618	Screw (Control Bracket)			
			190	590997	Screw (Fuel Tank)			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

19J100

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
337	696202	Plug-Spark	601	791850	Clamp-Hose	957	794641	Cap-Fuel Tank
356	799789	Wire-Stop	608	593668	Starter-Rewind	958A	593171	Valve-Fuel Shut Off (Plastic)
358	593112	Gasket Set-Engine	610	799805	Arrester-Intake	972	593170	Tank-Fuel (Metal)
363	19203	Puller-Flywheel	614	797229	Pin-Cotter	976	793382	Primer-Carburetor
367	798618	Screw (Wire Clip)	616	592615	Crank-Governor	990A	798177	Key Set
383	19576S	Wrench-Spark Plug	631	797794	Washer (Oil Drain Plug)	996A	593179	Shield-Carburetor
436	799796	Manifold-Exhaust	635A	797685	Boot-Spark Plug	998	799809	Pipe-Oil
455	591820	Cup-Flywheel	654	690939	Nut (Carburetor)	1005	591789	Fan-Flywheel
458	699334	Kit-Handle/Rope	663	799846	Screw (Control Panel)	1009	797795	Screw (Starter Motor)
472C	791948	Knob-Choke Shaft	705	590965	Nut (Fuel Tank)	1022	797846	Gasket-Rocker Cover
474	591094	Alternator Used on Type No(s). 0001, 0002, 0007, 0008, 0009.	711	798618	Screw (Carburetor Shield)	1023	799778	Cover-Rocker Arm
		----- Note -----	718	797792	Pin-Locating (Cylinder Head)	1026	591818	Rod-Push
		799843 Alternator Used on Type No(s). 0004, 0005, 0006, 0010.	718A	797761	Pin-Locating (Crankcase Cover)	1029	591087	Arm-Rocker
485	695755	Knob-Control	729	797750	Clip-Wire	1034	591819	Guide-Push Rod Label-Emissions (Available From A Briggs & Stratton Authorized Dealer)
493B	691177	Bracket-Mounting	729C	593137	Clip-Wire	1036		
493D	593682	Bracket-Mounting	731D	593679	Hood-Snow	1095	593113	Gasket Set-Valve
501	698315	Regulator	731E	593678	Hood-Snow	1119	799845	Screw (Alternator)
505	690939	Nut (Governor Control Lever)	813	590392	Clamp	1177	590965	Nut (Muffler)
512	591863	Hose-Oil Drain	830	591088	Stud-Rocker Arm	1196A	799919	Screw (Snow Hood)
522	799941	Plug-Dipstick/Fill	832D	593187	Guard-Muffler	1302	590457	Washer (Muffler Guard)
526	690297	Screw (Regulator)	836A	798976	Screw (Muffler Guard)	1319	794467	Label-Warning
528	799918	Hose-Primer	842	797327	Seal-O Ring (Dipstick Tube)	1319A	797669	Label-Warning
529	799933	Grommet (Fuel Tank)	847	593174	Dipstick/Tube Assembly	1509	797346	Outlet-Tank
562	797230	Bolt (Governor-Control Lever)	868	797854	Seal-Valve (Intake)			
			883	797770	Gasket-Exhaust			
			883A	799797	Gasket-Exhaust			
			892	798182	Switch-Key			
			914	797848	Screw (Rocker Cover)			

Not for
Reproduction

Not for
Reproduction

