

44T800

Illustrated Parts List

Model Series

44T800

TYPE NUMBERS

0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009,















0010, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018.











Not for
Reproduction




PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.










44T800











44T800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	594970	Cylinder Assembly (Used After Code Date 15071500)	16	796237	Crankshaft ----- Note ----- 796256 Crankshaft Used on Type No(s). 0003, 0004, 0005, 0012. 796257 Crankshaft Used on Type No(s). 0008, 0011.	108	699723	Valve-Choke
1A	594162	Cylinder Assembly (Used Before Code Date 15071600)	20	795387	Seal-Oil (PTO Side)	117	842081	Jet-Main (Standard)
2	797673	Kit-Bushing/Seal (Magnet Side)	22	694966	Screw (Crankcase Cover/Sump)	118	699733	Jet-Main (High Altitude)
3	391086s	Seal-Oil (Magnet Side)	23	594169	Flywheel	121	799132	Kit- Carburetor Overhaul
4	594973	Sump-Engine (Used After Code Date 15071500)	24	222698s	Key-Flywheel	122	593425	Spacer-Carburetor
4A	594974	Sump-Engine (Used After Code Date 15071500) Used on Type No(s). 0015, 0016, 0018.	25	792023	Piston Assembly (Standard) ----- Note ----- 792072 Piston Assembly (.020" Oversize)	125	799109	Carburetor
4B	797502	Sump-Engine (Used Before Code Date 15071600)	26	792026	Ring Set (Standard) ----- Note ----- 792073 Ring Set (.020" Oversize)	130	690993	Valve-Throttle
5	799088	Head-Cylinder (Cylinder #1)	27	690975	Lock-Piston Pin	131	799113	Kit-Throttle Shaft
5A	799089	Head-Cylinder (Cylinder #2)	28	696581	Pin-Piston	133	699724	Float-Carburetor
7	693997	Gasket-Cylinder Head	29	796209	Rod-Connecting	135	699729	Tube-Fuel Transfer
8	792185	Breather Assembly (Used Before Code Date 14110500)	32	690976	Screw (Connecting Rod)	137	690994	Gasket-Float Bowl
9	690937	Gasket-Breather (Used Before Code Date 14110500)	33	793557	Valve-Exhaust	141	799112	Kit-Choke Shaft
10	691108	Screw (Breather Assembly)	34	793556	Valve-Intake	142	796871	Nozzle-Carburetor
11	594163	Tube-Breather (Used After Code Date 14110400) ----- Note ----- 792184 Tube-Breather (Used Before Code Date 14110500)	35	694865	Spring-Valve (Intake)	150	841649	Gasket-Nozzle
12	594195	Gasket-Crankcase (Used Before Code Date 15071600)	36	694865	Spring-Valve (Exhaust)	163	691001	Gasket-Air Cleaner
13	592244	Screw (Cylinder Head)	42	499586	Keeper-Valve	186	794873	Connector-Hose (Intake Manifold)
15	690946	Plug-Pipe (Oil Drain)	45	690977	Tappet-Valve	186A	796532	Connector-Hose (Oil Drain)
			46	797242	Camshaft	186B	799158	Connector-Hose (EVAP)
			50	797503	Manifold-Intake	186C	845141	Connector-Hose (EVAP)
			51	690949	Gasket-Intake	187	791766	Line-Fuel (Cut to Required Length)
			51A	594427	Gasket-Intake	188	691108	Screw (Control Bracket)
			53	690951	Stud (Carburetor)	192	690083	Adjuster-Rocker Arm
			54	699816	Screw (Intake Manifold)	212	695238	Link-Throttle
			75	691056	Washer (Flywheel)	213	799510	Bracket-Control (Manual Choke) Used on Type No(s). 0002, 0003, 0004, 0008, 0010, 0013, 0015, 0016, 0018. ----- Note ----- 799153 Bracket- Control Used on Type No(s). 0001, 0005, 0006, 0007, 0009, 0011, 0012, 0014, 0017.
			93	845864	Collar-Throttle	216	796229	Link-Choke Used on Type No(s). 0001, 0006, 0007.
			95	690718	Screw (Throttle Valve)	216A	691022	Link-Choke Used on Type No(s). 0002, 0003, 0004, 0008, 0010, 0013, 0015, 0016, 0018.
			98	699721	Kit-Idle Speed			
			104	694918	Pin-Float Hinge			
			105	797410	Valve-Float			

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
216B	796879	Link-Choke Used on Type No(s). 0005, 0009, 0011, 0012, 0014, 0017.	318	691127	Screw (Mounting Bracket)	501	794360	Regulator Used on Type No(s). 0015.
217	799771	Spring-Choke Return	318A	792629	Screw (Electronic Choke Module to Mounting Bracket)	501A	845907	Regulator
219	793338	Gear-Governor				505	691029	Nut (Governor Control Lever)
220	799772	Washer (Governor Gear)	332	691059	Nut (Flywheel)	512	594200	Hose-Oil Drain
221	841026	Cup-Governor	333	592846	Armature-Magneto	523	594528	Dipstick
222	798916	Bracket-Control (V3 Manual Choke)	334	691061	Screw (Magneto Armature)	524	691032	Seal-Dipstick Tube
222A	592555	Bracket-Control (Choke-A-Matic) Used on Type No(s). 0001, 0006, 0007.	337	792015	Plug-Spark ----- Note ----- 491055s Plug-Spark Used on Type No(s). 0001, 0002, 0005, 0015.	525	691037	Tube-Dipstick
227	798856	Lever- Governor Control				526	691129	Screw (Regulator)
231	690718	Screw (Choke Valve)	357	691483	Key-Pulley	526A	691108	Screw (Regulator)
239	697049	Switch-Oil Pressure	358	799117	Gasket Set-Engine	537	594918	Kit- Governed/Idle Spring ----- Note ----- 594911 Kit- Governed/Idle Spring Used on Type No(s). 0009.
239A	792028	Switch-Oil Pressure Used on Type No(s). 0006, 0007.	363	19203	Puller-Flywheel			594912 Kit- Governed/Idle Spring Used on Type No(s). 0001, 0006, 0011, 0014, 0015, 0016. 594919 Kit- Governed/Idle Spring Used on Type No(s). 0003, 0004, 0008.
240	695666	Filter-Fuel	377	690979	Key-Woodruff	540	594325	Plate-Breather Baffle
250	690957	Retainer-Breather (Used Before Code Date 14110500)	383	19576s	Wrench-Spark Plug	552	796638	Bushing- Governor Crank
252	794389	Collector-Oil (Used Before Code Date 14110500)	385	797409	Screw (Fuel Pump)	552A	690553	Bushing- Governor Crank
265	691024	Clamp-Casing	387	808656	Pump-Fuel	562	690311	Bolt (Governor Control Lever)
267	792629	Screw (Casing Clamp)	400	796862	Cooler-Oil	563	799360	Screw (Debris Screen Guard)
276	695410	Washer-Sealing	404	690442	Washer (Governor Crank)	563A	698425	Screw (Debris Screen Guard)
287	697820	Screw (Dipstick Tube)	405	594937	Screw (Backplate)	573	594902	Plate-Back
304	799957	Housing-Blower ----- Note ----- 799958 Housing-Blower Used on Type No(s). 0015, 0016, 0018.	411	698304	Screw (Air Cleaner Base)	584	594164	Cover-Breather
305	594618	Screw (Blower Housing)	415	794903	Plug	601	691038	Clamp-Hose
305A	557049	Screw (Blower Housing)	418	795912	Plate-Carburetor	601A	841597	Clamp-Hose
306	796852	Shield-Cylinder (Cylinder #1)	431	799097	Elbow-Intake	613	690341	Screw Muffler
306A	591666	Shield-Cylinder (Cylinder #2)	445	798897	Filter- Air Cleaner Cartridge	615	698290	Retainer- Governor Shaft
307	691003	Screw (Cylinder Shield)	447	691003	Screw (Air Guide Cover)	616	691045	Crank-Governor
307A	691108	Screw (Cylinder Shield)	448	799103	Bracket-Oil Cooler			
309	590476	Motor-Starter	467	790697	Knob-Air Cleaner (1" Long)			
			474	592829	Alternator (5/9 Amp. Regulated Or Tri-Circuit) Used on Type No(s). 0015.			
			474A	592830	Alternator (10 - 16 Amp. Regulated)			
			493	797176	Bracket-Electronic Choke Module			
			496	799095	Lever-Air Cleaner Base			

44T800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
618	594326	Screw (Breather Baffle Plate)	865	591667	Cover-Air Guide (Valley)	1027	795890	Filter-Oil (Yellow)
633	690722	Seal- Choke/Throttle Shaft	868	690968	Seal-Valve (Rocker Cover)	----- Note -----		
633A	691321	Seal- Choke/Throttle Shaft	875	799094	Base-Air Cleaner	798576	Filter-Oil (Orange)	
635	692076	Boot-Spark Plug	883	690970	Gasket-Exhaust	Used on Type No(s). 0010.		
640	796913	Thermostat	914	691127	Screw (Rocker Cover)	1028	796864	Adapter-Oil Filter
654	690958	Nut (Carburetor)	918	593998	Hose-Vacuum (Length 3.2 Inches)	1029	690972	Arm-Rocker
672	690234	Gasket- Carburetor Plate	918A	799160	Hose-Vacuum (Length 9.4 Inches)	1029A	807323	Rocker Arm
691	790574	Seal-Governor Shaft	929	794904	Screw (Air Cleaner Base Tab To Choke Bracket)	1036		Label-Emissions (Available from a Briggs & Stratton Authorized Dealer)
697	591909	Screw (Drive Cap)	934	593638	Screw (Fan Retainer)	1054	280275	Tie-Cable
703	691010	Clip	943	796222	Seal-O Ring (Oil Pump Cover)	1059	698516	Kit-Screw/Washer (Alternator)
718	690959	Pin-Locating	947	798779	Solenoid-Fuel	1095	694013	Gasket Set-Valve
718A	594988	Pin-Locating	949	799357	Guard-Debris Screen	1100	791959	Pivot-Rocker Arm
726	499612	Gear-Ring	949A	593218	Guard-Debris Screen	1119	691183	Screw (Alternator)
729	797454	Clip-Wire	949B	593206	Guard-Debris Screen	1124	841653	Seal-O Ring (Fuel Transfer Tube)
741	690980	Gear-Timing	958	698183	Valve-Fuel Shut Off (Plastic)	1124A	690988	Seal-O Ring (Fuel Transfer Tube)
742	690328	Retainer-E Ring	964	799159	Cap-Connector	1126	690991	Screw (Fuel Transfer Tube)
750	796208	Screw (Oil Pump Cover)	965	796221	Cover-Oil Pump	1127	695407	Screw (Float Bowl)
789	695050	Harness-Wiring Used on Type No(s). 0001.	967	593217	Filter-Foam	1128	690990	Screw (Carburetor Nozzle)
789A	796860	Harness-Wiring Used on Type No(s). 0017.	968	799102	Cover-Air Cleaner	1169	690990	Screw (Carburetor Cover Plate)
789B	797492	Harness-Wiring Used on Type No(s). 0005, 0009, 0011, 0012, 0014.	969	799093	Screw (Blower Housing Cover)	1263	594166	Reed-Valve Breather
789C	591392	Harness-Wiring Used on Type No(s). 0001, 0002, 0004, 0008, 0010, 0013, 0018.	975	799114	Bowl-Float/Solenoid	1264	594165	Screw (Valve Breather Reed)
789D	591393	Harness-Wiring Used on Type No(s). 0003, 0006, 0007, 0015, 0016.	987	808183	Seal-Throttle Shaft	1319	794467	Label-Warning
789E	796914	Harness-Wiring Used on Type No(s). 0005, 0009, 0011, 0012, 0014, 0017.	997	592782	Cover-Blower Housing	1319A	797669	Label-Warning
798	697890	Screw (Rocker Arm)	1005	791236	Fan-Flywheel	1330	273521	Manual-Repair
829	799104	Hose-Oil Cooler	1006	798750	Retainer-Fan	1366	799131	Diverter-Oil Cooler
842	691031	Seal-O Ring (Dipstick)	1012	592556	Retainer-Link	1373	695629	Screw (Oil Cooler Bracket)
847	594609	Dipstick/Tube Assembly	1013	690954	Nipple-Oil Filter	1373A	799105	Screw (Oil Cooler Bracket)
850	100106	Sealant-Liquid	1017	796214	Screen-Oil Pump	1374	796863	Seal-O Ring (Oil Cooler Diverter)
			1022	690971	Gasket-Rocker Cover	1406	799096	Valve
			1023	793146	Cover-Rocker (Cylinder #1)	1436	799108	Motor-Stepper
			1023A	499600	Cover-Rocker (Cylinder #2)	1437	699891	Screw (Stepper/Bracket Motor)
			1024	796220	Pump-Oil	1438	796352s	Module-Electronic Choke
			1026	690981	Rod-Push (Steel) (Exhaust)	1439	794904	Screw (Thermistor Bracket)
			1026A	690982	Rod-Push (Aluminum) (Intake)			

Not for
Reproduction

