

44N800

Illustrated Parts List

Model Series

44N800












TYPE NUMBERS
0001 THROUGH 0014.









Not for
Reproduction








PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.



















REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	594970	Cylinder Assembly (Used After Code Date 15071500)	23	594169	Flywheel	127	699810	Plug- Welch
1A	594162	Cylinder Assembly (Used Before Code Date 15071600)	24	222698s	Key- Flywheel	131	594210	Kit- Throttle Shaft
2	797673	Kit- Bushing/Seal (Magneto Side)	25	792023	Piston Assembly (Standard)	133	694914	Float- Carburetor
3	391086s	Seal- Oil (Magneto Side)			----- Note -----	135	591701	Tube- Fuel Transfer
4	594974	Sump- Engine (Used After Code Date 15071500)			792072 Piston Assembly (.020" Oversize)	137	698781	Gasket- Float Bowl
4A	796307	Sump- Engine (Used Before Code Date 15071600)	26	792026	Ring Set (Standard)	141	594211	Kit- Choke Shaft
5	799088	Head- Cylinder (Cylinder #1)			----- Note -----	141A	595218	Kit- Choke Shaft Used on Type No(s). 0003, 0004, 0005, 0011, 0012.
5A	799089	Head- Cylinder (Cylinder #2)			792073 Ring Set (.020" Oversize)	186	796532	Connector- Hose (Oil Drain)
7	693997	Gasket- Cylinder Head	27	690975	Lock- Piston Pin	186A	799158	Connector- Hose (EVAP)
8	792185	Breather Assembly (Used Before Code Date 14110500)	28	696581	Pin- Piston	186B	845141	Connector- Hose (EVAP)
9	690937	Gasket- Breather (Used Before Code Date 14110500)	29	796209	Rod- Connecting (Standard)	187	791766	Line- Fuel (15" Long- Cut to Required Length)
10	691108	Screw (Breather Assembly)	32	690976	Screw (Connecting Rod)	188	691108	Screw (Control Bracket)
11	594163	Tube- Breather (Used After Code Date 14110400)	33	793557	Valve- Exhaust	192	690083	Adjuster- Rocker Arm
		----- Note -----	34	793556	Valve- Intake	212	792265	Link- Throttle
		792184 Tube- Breather (Used Before Code Date 14110500)	35	694865	Spring- Valve (Intake)	213	691021	Lever- Control Bracket
12	594195	Gasket- Crankcase (Used Before Code Date 15071600)	36	694865	Spring- Valve (Exhaust)	216	796229	Link- Choke (Manual Link)
13	592244	Screw (Cylinder Head)	42	499586	Keeper- Valve	216A	691022	Link- Choke Used on Type No(s). 0009, 0014.
15	690946	Plug- Oil Drain	45	690977	Tappet- Valve	216B	595217	Link- Choke Used on Type No(s). 0003, 0004, 0005, 0011, 0012.
16	699701	Crankshaft	46	797242	Camshaft	217	799771	Spring- Choke Return
		----- Note -----	50	594206	Manifold- Intake	217A	592585	Spring- Choke Return Used on Type No(s). 0003, 0004, 0005, 0011, 0012.
		796237 Crankshaft Used on Type No(s). 0001, 0006, 0007, 0008, 0009.	51	594204	Gasket- Intake	219	793338	Gear- Governor
		796256 Crankshaft Used on Type No(s). 0004, 0005, 0012.	51A	594203	Gasket- Intake	220	799772	Washer (Governor Gear)
20	795387	Seal- Oil (PTO Side)	53	690951	Stud (Carburetor)	221	841026	Cup- Governor
22	694966	Screw (Crankcase Cover/Sump)	54	699816	Screw (Intake Manifold)	222	592555	Bracket- Control
			73	494439	Screen- Rotating	222A	798916	Bracket- Control Used on Type No(s). 0009, 0014.
			74	698425	Screw (Rotating Screen)	227	798856	Lever- Governor Control
			75	691056	Washer (Flywheel)	231	690991	Screw (Choke Valve)
			95	690718	Screw (Throttle Valve)	239	792028	Switch- Oil Pressure
			98	695408	Kit- Idle Speed	240	691035	Filter- Fuel
			104	694918	Pin- Float Hinge	240A	695666	Filter- Fuel Used on Type No(s). 0004, 0005.
			105	698537	Valve- Float Needle			
			117	842139	Jet- Main (Standard)			
			118	842627	Jet- Main (High Altitude)			
			121	594212	Kit- Carburetor Overhaul			
			125	594530	Carburetor			
			125A	595321	Carburetor Used on Type No(s). 0003, 0004, 0005, 0011, 0012.			

44N800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
250	690957	Retainer- Breather (Used Before Code Date 14110500)	383	19576S	Wrench- Spark Plug	537	594915	Kit- Governor/Idle Spring
252	794389	Collector- Oil (Used Before Code Date 14110500)	385	797409	Screw (Fuel Pump Mounted To Blower Housing)	-----	Note	-----
255	690721	Collar- Choke	387	808656	Pump- Fuel	594911	Kit-	
265	691024	Clamp- Casing	404	690442	Washer (Governor Crank)	594911	Governor/Idle Spring	
267	792629	Screw (Casing Clamp)	405	594937	Screw (Back Plate)	594911	Used on Type No(s).	
276	695410	Washer- Sealing	415	794903	Plug	594911	0014.	
287	697820	Screw (Dipstick Tube)	431	594205	Elbow- Intake	540	594325	Plate- Breather Baffle
291	592581	Thermostat	445	594201	Filter- Air Cleaner Cartridge (Canister)	552	796638	Bushing- Governor Crank
304	591656	Housing- Blower (Black)	447	691003	Screw (Air Guide Cover)	552A	690553	Bushing- Governor Crank
-----	Note	-----	467	591660	Knob- Air Cleaner (7/8" Long)	562	690311	Bolt (Governor Control Lever)
591657	Housing- Blower (Gray)		474	592829	Alternator (5/9 Amp. Regulated Or Tri- Circuit)	573	594902	Plate- Back
591657	Used on Type No(s).					584	594164	Cover- Breather
591657	0004, 0005.					601	691038	Clamp- Hose (Black)
305	790690	Screw (Blower Housing to Intake Elbow)				615	698290	Retainer- Governor Shaft
305A	594618	Screw (Blower Housing)	474A	592830	Alternator (10 - 16 Amp. Regulated)	616	691045	Crank- Governor
306	796852	Shield- Cylinder (Cylinder #1)				617	594209	Seal- O Ring (Intake Manifold)
306A	591666	Shield- Cylinder (Cylinder #2)				618	594326	Screw (Breather Baffle Plate)
307	691003	Screw (Cylinder Shield)				633	699813	Seal- Choke/Throttle Shaft
307A	691108	Screw (Cylinder Shield)	474B	592831	Alternator (Dual Circuit)	635	66538s	Boot- Spark Plug
309	592599	Motor- Starter				635A	692076	Boot- Spark Plug Used on Type No(s).
-----	Note	-----						0009.
590476	Motor- Starter		501	794360	Regulator	654	690958	Nut (Carburetor)
590476	Used on Type No(s).					668	691500	Spacer
590476	0007, 0009, 0014.					668A	691215	Spacer
332	691059	Nut (Flywheel)	501A	593490	Regulator	691	790574	Seal- Governor Shaft
333	592846	Armature- Magneto				697	591909	Screw (Drive Cap)
334	691061	Screw (Magneto Armature)				703	691010	Clip
337	491055s	Plug- Spark	505	691029	Nut (Governor Control Lever)	703A	592584	Clip
-----	Note	-----				718	690959	Pin- Locating
792015	Plug- Spark					718A	594988	Pin- Locating
792015	Used on Type No(s).		512	594200	Hose- Oil Drain	729	593826	Clip- Wire
792015	0006, 0009.		523	594528	Dipstick	741	690980	Gear- Timing
793541	Plug- Spark		524	691032	Seal- Dipstick Tube	742	690328	Retainer- E Ring
793541	Used on Type No(s).		525	691037	Tube- Dipstick	750	796208	Screw (Oil Pump Cover)
793541	0004.		526	691129	Screw (Regulator)	788	793145	Bracket- Fuel Pump
358	594213	Gasket Set- Engine	526A	691108	Screw (Regulator)	789	591392	Harness- Wiring
363	19203	Puller- Flywheel				789A	591393	Harness- Wiring Used on Type No(s).
377	690979	Key- Woodruff						0006, 0007, 0008, 0009, 0014.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
789B	698330	Harness- Wiring Used on Type No(s). 0010.	968	591658	Cover- Air Cleaner (Black) ----- Note -----	1029	690972	Arm- Rocker
798	697890	Screw (Rocker Arm)		591659	Cover- Air Cleaner (Gray)	1029A	807323	Arm- Rocker
842	691031	Seal- O Ring (Dipstick Tube)			Used on Type No(s). 0004, 0005.	1036		Label- Emissions (Available from a Briggs & Stratton Authorized Dealer)
847	594609	Dipstick/Tube Assembly	971	799159	Cap- Fuel Connector	1040	791237	Plate- Trim (Black) ----- Note -----
850	100106	Sealant- Liquid	975	591699	Bowl- Float		798585	Plate- Trim (Orange) Used on Type No(s). 0004, 0005.
865	591667	Cover- Air Guide (Valley)	1005	593640	Fan- Flywheel	1059	698516	Kit- Screw/Washer
868	690968	Seal- Valve	1012	592556	Retainer- Link	1095	594214	Gasket Set- Valve
877	790544	Wire/Connector - Alternator	1013	690954	Nipple- Oil Filter	1100	791959	Pivot- Rocker Arm
883	690970	Gasket- Exhaust	1017	796214	Screen- Oil Pump	1119	691183	Screw (Alternator)
914	691127	Screw (Rocker Cover)	1022	690971	Gasket- Rocker Cover	1127	695407	Screw (Aluminum Float Bowl)
918	593998	Hose- Vacuum (Length 3.2 Inches)	1023	793146	Cover- Rocker (Cylinder #1)	1193	592577	Screw (Thermostat)
918A	799160	Hose- Vacuum (Length 9.4 Inches)	1023A	499600	Cover- Rocker (Cylinder #2)	1263	594166	Reed- Valve Breather
929	695239	Screw (Choke Control Bracket)	1024	794644	Pump- Oil	1264	594165	Screw (Valve Breather Reed)
934	593638	Screw (Fan Retainer)	1026	690981	Rod- Push (Steel)	1319	794467	Label- Warning
943	796222	Seal- O Ring (Oil Pump Cover)	1026A	690982	Rod- Push (Aluminum)	1319A	797669	Label- Warning
947	798779	Solenoid- Fuel	1027	492932s	Filter- Oil ----- Note -----	1330	273521	Repair Manual
964	799159	Cap- Connector		696854	Filter- Oil Used on Type No(s). 0001.	1386	592580	Vane- Air Choke
965	796221	Cover- Oil Pump		798576	Filter- Oil Used on Type No(s). 0004, 0005.	1474	592579	Stud- Mounting (Air Choke Vane)
						1475	592578	Nut (Air Choke Vane)

Not for
Reproduction

