



0 24847 90279 2

14D900

Illustrated Parts List

Model Series

14D900

TYPE NUMBER
0101.

TABLE OF CONTENTS

Air Cleaner	7
Alternator	10
Blower Housing	5
Camshaft	2
Carburetor	8
Carburetor Overhaul Kit	8
Controls	9
Covers/Guards	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	10
Exhaust System	6
Flywheel	5
Fuel Supply	6
Gasket Set - Engine	4
Gasket Set - Valve	3
Governor Spring	9
Ignition	10
Lubrication	6
Operator's Manual	2
Piston/Rings/Connecting Rod	2
Sump	4
Thermostat	9
Valves	3
Warning Label	2



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

1319 WARNING LABEL



REQUIRED when replacing parts with warning labels affixed.

1319A WARNING LABEL












REQUIRED when replacing parts with warning labels affixed.


1058 OPERATOR'S MANUAL





1036 EMISSIONS LABEL




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.







Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	799278	Cylinder Assembly	35	691304	Spring-Valve (Intake)	202	796657	Link-Mechanical Governor
3	299819s	Seal-Oil (Magneto Side)	36	691304	Spring-Valve (Exhaust)	209	796926	Spring-Governor Used on Type No(s). 0101.
4	799476	Sump-Engine	37	590921	Guard-Flywheel Used on Type No(s). 0101.	216A	798944	Link-Choke
5	592175	Head-Cylinder	37A	799266	Guard-Flywheel Used on Type No(s). 0101.	217	799179	Spring-Choke Return
7	799275	Gasket-Cylinder Head	40	692194	Retainer-Valve	222	796482	Bracket-Control (Manual Friction, Remote, & Fixed Speed Control)
11	796478	Tube-Breather	43	796525	Slinger-Governor/Oil	227	796487	Lever-Governor Control
12	692232	Gasket-Crankcase	45	690977	Tappet-Valve	238	691300	Cap-Valve
13	799277	Screw (Cylinder Head)	46	694039	Camshaft	240	298090s	Filter-Fuel
15	691680	Plug-Oil Drain (Square Socket)	51B	592159	Gasket-Intake	265	691024	Clamp-Casing
16	590489	Crankshaft Used on Type No(s). 0101.	78	793480	Screw (Flywheel Guard)	----- Note -----		
17	798538	Bearing-Ball	81	691740	Lock-Muffler Screw	690798 Clamp-Casing		
20	399781s	Seal-Oil (PTO Side)	104	797622	Pin-Float Hinge	Used on Type No(s). 0101.		
22	691092	Screw (Crankcase Cover/Sump)	117	799178	Jet-Main (Standard)	267	691044	Screw (Casing Clamp)
23B	591399	Flywheel (Cast Iron) Used on Type No(s). 0101.	121A	592172	Kit-Carburetor Overhaul Used on Type No(s). 0101.	268	691025	Casing-Control Wire (Cut To Required Length)
24	796335	Key-Flywheel	122A	592160	Spacer-Carburetor Used on Type No(s). 0101.	269	691026	Wire-Control (Cut To Required Length)
25	799270	Piston Assembly (Standard) ----- Note ----- 799271 Piston Assembly (.020" Oversize)	125	590944	Carburetor Used on Type No(s). 0101.	270	691027	Nut (Control Wire Casing)
26	799272	Ring Set (Standard) ----- Note ----- 799273 Ring Set (.020" Oversize)	133	797626	Float-Carburetor Used on Type No(s). 0101.	271	691028	Lever-Control
27	691588	Lock-Piston Pin	134	799177	Kit-Needle/Seat Used on Type No(s). 0101.	276	797632	Washer-Sealing Used on Type No(s). 0101.
28	799274	Pin-Piston	137	797625	Gasket-Float Bowl Used on Type No(s). 0101.	291A	798938	Thermostat
29	796470	Rod-Connecting	163	691894	Gasket-Air Cleaner	300B	799259	Muffler-Exhaust
32	691664	Screw (Connecting Rod)	187A	796491	Line-Fuel (Formed Hose)	304A	591172	Housing-Blower (Electric Start) Used on Type No(s). 0101.
32A	695759	Screw (Connecting Rod)	192	796631	Adjuster-Rocker Arm	309	799241	Motor-Starter
33	499642	Valve-Exhaust				332	690662	Nut (Flywheel)
34	795443	Valve-Intake				333	796500	Armature-Magneto Used on Type No(s). 0101.

14D900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
334	793454	Screw (Magneto Armature)	635	66538s	Boot-Spark Plug	993	796473	Gasket-Cylinder Head Plate
337	692720	Plug-Spark Used on Type No(s). 0101.	668	797373	Spacer	1005	799265	Fan-Flywheel
356J	592156	Wire-Stop Used on Type No(s). 0101.	697	691127	Screw (Drive Cap)	1006	799264	Retainer-Fan
358	592173	Gasket Set-Engine	718	690959	Pin-Locating	1022	796480	Gasket-Rocker Cover
363	19069	Puller-Flywheel	741	797521	Gear-Timing	1023	796479	Cover-Rocker Arm
365	793458	Screw (Carburetor)	742	93941	Retainer-E Ring	1026	796481	Rod-Push
383	19576s	Wrench-Spark Plug	830	796472	Stud-Rocker Arm	1029	691230	Arm-Rocker
404	690272	Washer (Governor Crank)	832B	799262	Guard-Muffler	1034	691343	Guide-Push Rod
445	795066	Filter-Air Cleaner Cartridge	836	793500	Screw (Muffler Guard)	1036		Label-Emissions (Available From A Briggs & Stratton Authorized Dealer)
474	794103	Alternator	837	799261	Spacer-Muffler	1058	279946	Manual-Operator's
505	793515	Nut (Governor Control Lever)	842	691031	Seal-O Ring (Dipstick Tube)	1095	592174	Gasket Set-Valve
523	796503	Dipstick	847	796501	Dipstick/Tube Assembly	1119	794100	Screw (Alternator)
524	692296	Seal-Dipstick Tube	851	493880s	Terminal-Spark Plug	1212	591164	Stud (Blower Housing)
525	796502	Tube-Dipstick	853A	695897	Adapter-Wire	1212A	591165	Stud (Blower Housing)
562	793514	Bolt (Governor-Control Lever)	868	795440	Seal-Valve	1212B	591166	Stud (Blower Housing) (Used With Alternator Only)
601	791850	Clamp-Hose	875	796492	Base-Air Cleaner	1263	697124	Reed-Breather
613	799260	Screw (Muffler)	883	793497	Gasket-Exhaust	1264	793453	Screw (Breather Reed)
615	690340	Retainer-Governor Shaft	886	799492	Gasket Kit-Cylinder Head Plate	1319	794467	Label-Warning
616	798327	Crank-Governor	910	796498	Stud (Alternator)	1319A	797669	Label-Warning
623	793628	Seal-O Ring (Carburetor Spacer)	914	794451	Screw (Rocker Arm Cover)	1335	793481	Nut (Blower Housing)
			937	799420	Spline-Starter	1375	799493	Cover-Breather/Reed
			949	799474	Guard-Debris Screen	1376	794451	Screw (Breather/Reed Cover)
			967	796254	Filter-Pre Cleaner	1430	799494	Gasket-Breather/Reed
			968	796493	Cover-Air Cleaner			
			971	690349	Screw (Air Cleaner Base to Carburetor)			
			975	797631	Bowl-Float Used on Type No(s). 0101.			

Not for
Reproduction

Not for
Reproduction

Not for
Reproduction

Not for
Reproduction

