

44T900

Illustrated Parts List

Model Series

44T900












TYPE NUMBERS
0001 THROUGH 0022.


Not for
Reproduction




PRINTED IN U.S.A.





COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.










44T900











44T900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	594970	Cylinder Assembly (Used After Code Date 15071500)	16	796256	Crankshaft ----- Note ----- 796237 Crankshaft Used on Type No(s). 0003, 0006, 0007, 0008, 0009, 0013, 0014, 0015, 0018, 0019, 0021.	104	694918	Pin- Float Hinge
1A	594162	Cylinder Assembly (Used Before Code Date 15071600)	20	795387	Seal- Oil (PTO Side)	105	797410	Valve- Float
2	797673	Kit- Bushing/Seal (Magneto Side)	22	694966	Screw (Crankcase Cover/Sump)	108	699723	Valve- Choke
3	391086s	Seal- Oil (Magneto Side)	23	594169	Flywheel	117	842081	Jet- Main (Standard)
4	594973	Sump- Engine (Used After Code Date 15071500) ----- Note ----- 594974 Sump- Engine (Used After Code Date 15071500) Used on Type No(s). 0005, 0006, 0010, 0016, 0018, 0021, 0022.	24	222698s	Key- Flywheel	118	699733	Jet- Main (High Altitude)
4A	797502	Sump- Engine (Used Before Code Date 15071600) ----- Note ----- 796307 Sump- Engine (Used Before Code Date 15071600) Used on Type No(s). 0005, 0006, 0010, 0016, 0018.	25	792023	Piston Assembly (Standard) ----- Note ----- 792072 Piston Assembly (.020" Oversize)	121	799132	Kit- Carburetor Overhaul
5	799088	Head- Cylinder (Cylinder #1)	26	792026	Ring Set (Standard) ----- Note ----- 792073 Ring Set (.020" Oversize)	122	593425	Spacer- Carburetor
5A	799089	Head- Cylinder (Cylinder #2)	27	690975	Lock- Piston Pin	125	799109	Carburetor
7	693997	Gasket- Cylinder Head	28	696581	Pin- Piston	130	690993	Valve- Throttle
8	792185	Breather Assembly (Used Before Code Date 14082500)	29	796209	Rod- Connecting	131	799113	Kit- Throttle Shaft
9	690937	Gasket- Breather (Used Before Code Date 14082500)	32	690976	Screw (Connecting Rod)	133	699724	Float- Carburetor
10	691108	Screw (Breather Assembly)	33	793557	Valve- Exhaust	135	699729	Tube- Fuel Transfer
11	594163	Tube- Breather (Used After Code Date 14082400)	34	793556	Valve- Intake	137	690994	Gasket- Float Bowl
11A	792184	Tube- Breather (Used Before Code Date 14082500)	35	694865	Spring- Valve (Intake)	141	799112	Kit- Choke Shaft
12	594195	Gasket- Crankcase	36	694865	Spring- Valve (Exhaust)	142	796871	Nozzle- Carburetor
13	592244	Screw (Cylinder Head)	42	499586	Keeper- Valve	150	841649	Gasket- Nozzle
15	690946	Plug- Pipe (Oil Drain)	45	690977	Tappet- Valve	163	691001	Gasket- Air Cleaner
			46	797242	Camshaft	186A	796532	Connector- Hose (Oil Drain)
			50	797503	Manifold- Intake	186B	799158	Connector- Hose (EVAP)
			51	690949	Gasket- Intake	186C	845141	Connector- Hose (EVAP)
			51A	594427	Gasket- Intake	187	791766	Line- Fuel (Cut to Required Length)
			53	690951	Stud (Carburetor)	188	691108	Screw (Control Bracket)
			54	699816	Screw (Intake Manifold)	192	690083	Adjuster- Rocker Arm
			73	494439	Screen- Rotating	212	695238	Link- Throttle
			74	698425	Screw (Rotating Screen)	213	799510	Bracket- Control (Manual Choke) ----- Note ----- 799153 Bracket- Control Used on Type No(s). 0007, 0008, 0009, 0010, 0011, 0015.
			75	691056	Washer (Flywheel)	216	691022	Link- Choke (Manual Choke Link)
			93	845864	Collar- Throttle	216A	796229	Link- Choke (Choke- A- Matic Link) Used on Type No(s). 0008, 0009, 0010, 0011, 0015.
			95	690718	Screw (Throttle Valve)	216B	796879	Link- Choke Used on Type No(s). 0007.
			98	699721	Kit- Idle Speed	217	799771	Spring- Choke Return
						219	793338	Gear- Governor
						220	799772	Washer (Governor Gear)
						221	841026	Cup- Governor

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
222	798916	Bracket- Control (V3 Manual Choke)	318A	792629	Screw (Electronic Choke Module to Mounting Bracket)	496	799095	Lever- Air Cleaner Base
222A	592555	Bracket- Control Used on Type No(s). 0008, 0009, 0010, 0011, 0015.	332	691059	Nut (Flywheel)	501	794360	Regulator
227	798856	Lever- Governor Control	333	592846	Armature- Magneto	501A	593490	Regulator
231	690718	Screw (Choke Valve)	334	691061	Screw (Magneto Armature)	505	691029	Nut (Governor Control Lever)
239	792028	Switch- Oil Pressure ----- Note ----- 697049 Switch- Oil Pressure Used on Type No(s). 0004, 0010, 0017.	337	792015	Plug- Spark ----- Note ----- 491055s Plug- Spark Used on Type No(s). 0009, 0011, 0012, 0013, 0021.	512	594200	Hose- Oil Drain
240	695666	Filter- Fuel	358	799117	Gasket Set- Engine	523	594528	Dipstick
250	690957	Retainer- Breather (Used Before Code Date 14082500)	363	19203	Puller- Flywheel	524	691032	Seal- Dipstick Tube
252	794389	Collector- Oil (Used Before Code Date 14082500)	377	690979	Key- Woodruff	525	691037	Tube- Dipstick
265	691024	Clamp- Casing	383	19576s	Wrench- Spark Plug	526	691108	Screw (Regulator)
267	792629	Screw (Casing Clamp)	385	797409	Screw (Fuel Pump)	537	594918	Kit- Governor/Idle Spring ----- Note ----- 594915 Kit- Governor/Idle Spring Used on Type No(s). 0007, 0008, 0009, 0011, 0015, 0018, 0021.
276	695410	Washer- Sealing	387	808656	Pump- Fuel			594919 Kit- Governor/Idle Spring Used on Type No(s). 0001, 0004, 0014, 0017.
287	697820	Screw (Dipstick Tube)	400	796862	Cooler- Oil	540	594325	Plate- Breather Baffle
296	591756	Stud- Exhaust	404	690442	Washer (Governor Crank)	552	796638	Bushing- Governor Crank
304	799957	Housing- Blower ----- Note ----- 799958 Housing- Blower Used on Type No(s). 0005, 0006, 0010, 0016, 0018, 0021, 0022.	405	594937	Screw (Backplate) (Used After Code Date 15071500) ----- Note ----- 697820 Screw (Backplate) (Used Before Code Date 15071600)	552A	690553	Bushing- Governor Crank
305	594618	Screw (Blower Housing)	411	698304	Screw (Air Cleaner Base)	562	690311	Bolt (Governor Control Lever)
305A	557049	Screw (Blower Housing)	415	794903	Plug	563	799360	Screw (Debris Guard)
306	796852	Shield- Cylinder (Cylinder #1)	418	795912	Plate- Carburetor	573	594902	Plate- Back (Used After Code Date 15071500) ----- Note ----- 593465 Plate- Back (Used Before Code Date 15071600)
306A	591665	Shield- Cylinder (Cylinder #2)	431	799097	Elbow- Intake	584	594164	Cover- Breather
307	691003	Screw (Cylinder Shield)	445	595536	Filter- Air Cleaner Cartridge	601	691038	Clamp- Hose
307A	691108	Screw (Cylinder Shield)	445A	798897	Filter- Air Cleaner Cartridge	601A	841597	Clamp- Hose
309	590476	Motor- Starter	447	691003	Screw (Air Guide Cover)	613	690341	Screw Muffler
318	691127	Screw (Mounting Bracket)	448	799103	Bracket- Oil Cooler	615	698290	Retainer- Governor Shaft
			467	790697	Knob- Air Cleaner (1" Long)	616	691045	Crank- Governor
			474	592829	Alternator (5/9 Amp. Regulated Or Tri- Circuit)	618	594326	Screw (Breather Baffle Plate)
			474A	592830	Alternator (10 - 16 Amp. Regulated)	633	690722	Seal- Choke/Throttle Shaft
			493	797176	Bracket- Electronic Choke Module			

44T900

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
635	692076	Boot- Spark Plug	918	593998	Hose- Vacuum (Length 3.2 Inches)			(Yellow)
640	796913	Thermostat						----- Note -----
654	690958	Nut (Carburetor)	918A	799160	Hose- Vacuum (Length 9.4 Inches)			798576 Filter- Oil (Orange)
672	690234	Gasket- Carburetor Plate	929	691003	Screw (Choke Control Bracket)	1028	796864	Adapter- Oil Filter
691	790574	Seal- Governor Shaft				1029	690972	Arm- Rocker
697	591909	Screw (Drive Cap)	929A	794904	Screw (Air Cleaner Base Tab To Choke Bracket)	1029A	807323	Rocker Arm
703	691010	Clip				1036		Label- Emissions (Available from a Briggs & Stratton Authorized Dealer)
718	690959	Pin- Locating	934	593638	Screw (Fan Retainer) (Used After Code Date 14082400)	1054	280275	Tie- Cable
718A	594988	Pin- Locating			----- Note -----	1059	698516	Kit- Screw/Washer (Alternator)
726	499612	Gear- Ring			592604 Screw (Fan Retainer) (Used Before Code Date 14082500)	1095	694013	Gasket Set- Valve
729	593826	Clip- Wire				1100	791959	Pivot- Rocker Arm
741	690980	Gear- Timing				1119	691183	Screw (Alternator)
742	690328	Retainer- E Ring						
750	796208	Screw (Oil Pump Cover)	943	796222	Seal- O Ring (Oil Pump Cover)	1124	841653	Seal- O Ring (Fuel Transfer Tube)
789	695050	Harness- Wiring Used on Type No(s). 0009, 0011, 0012, 0013.	947	798779	Solenoid- Fuel	1124A	690988	Seal- O Ring (Fuel Transfer Tube)
789A	591392	Harness- Wiring Used on Type No(s). 0001, 0002, 0003, 0005, 0006, 0008, 0009, 0011, 0012, 0013, 0014, 0015, 0016, 0018.	949	799357	Cover- Static ----- Note ----- 593218 Cover- Static Used on Type No(s). 0005, 0006, 0014, 0015, 0016, 0018, 0021, 0022.	1126	690991	Screw (Fuel Transfer Tube)
789B	591393	Harness- Wiring Used on Type No(s). 0004, 0010, 0017, 0019, 0020, 0021, 0022.	949A	593206	Screen- Debris Guard	1127	695407	Screw (Float Bowl)
789C	796860	Harness- Wiring Used on Type No(s). 0007.	964	799159	Cap- Connector	1128	690990	Screw (Carburetor Nozzle)
789D	796914	Harness- Wiring Used on Type No(s). 0007.	965	796221	Cover- Oil Pump	1169	690990	Screw (Carburetor Cover Plate)
798	697890	Screw (Rocker Arm)	967	593217	Filter- Foam	1193	592577	Screw (Thermostat)
829	799104	Hose- Oil Cooler	968	799102	Cover- Air Cleaner	1263	594166	Reed- Valve Breather
842	691031	Seal- O Ring (Dipstick)	969	799093	Screw (Blower Housing Cover)	1264	594165	Screw (Valve Breather Reed)
847	594609	Dipstick/Tube Assembly	975	799114	Bowl- Float/Solenoid	1319	794467	Label- Warning
850	100106	Sealant- Liquid	987	808183	Seal- Throttle Shaft	1319A	797669	Label- Warning
865	591667	Cover- Air Guide (Valley)	997	592782	Cover- Blower Housing	1330	273521	Manual- Repair
868	690968	Seal- Valve (Rocker Cover)	1005	593640	Fan- Flywheel	1366	799131	Diverter- Oil Cooler
875	799094	Base- Air Cleaner	1006	798750	Retainer- Fan	1373	695629	Screw (Oil Cooler Bracket)
883	690970	Gasket- Exhaust	1012	592556	Retainer- Link	1373A	799105	Screw (Oil Cooler Bracket)
914	691127	Screw (Rocker Cover)	1013	690954	Nipple- Oil Filter	1374	796863	Seal- O Ring (Oil Cooler Diverter)
			1017	796214	Screen- Oil Pump	1406	799096	Valve
			1022	690971	Gasket- Rocker Cover	1436	799108	Motor- Stepper
			1023	793146	Cover- Rocker (Cylinder #1)	1437	699891	Screw (Stepper/Bracket Motor)
			1023A	499600	Cover- Rocker (Cylinder #2)	1438	796352s	Module- Electronic Choke
			1024	796220	Pump- Oil	1439	794904	Screw (Thermistor Bracket)
			1026	690981	Rod- Push (Steel) (Exhaust)			
			1026A	690982	Rod- Push (Aluminum) (Intake)			
			1027	696854	Filter- Oil			

Not for
Reproduction

