

21R800

Illustrated Parts List

Model Series

21R800

TYPE NUMBERS

0001, 0002, 0003, 0004, 0005, 0006, 0007, 0008, 0009, 0010, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018, 0019, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027, 0028, 0029, 0030, 0031, 0032, 0033, 0034, 0035, 0036, 0037, 0038, 0039, 0040, 0041, 0042, 0043, 0044, 0045, 0046, 0047, 0048, 0049, 0050, 0051, 0052, 0053, 0054, 0055, 0056, 0057, 0058, 0059, 0060, 0061, 0062, 0063, 0064, 0065, 0066, 0067.


TABLE OF CONTENTS

Air Cleaner	6
Alternator	8
Blower Housing	6
Camshaft	3
Carburetor	5
Controls	8
Crankshaft	3
Cylinder	2
Cylinder Head	4
Electric Starter	7
Engine Sump	2
Exhaust System	6
Flywheel	7
Fuel Supply	5
Gasket Set - Engine & Valve	4
Governor Spring	8
Ignition	8
Intake Manifold	4
Kit - Carburetor Overhaul	5
Lubrication	3
Operator's Manual	2
Piston, Rings, Connecting Rod	3
Rewind Starter	7
Valves	4

PRINTED IN U.S.A.










COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.













Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.









10482-2	Assemblies include all parts shown in frames.	09/25/2015
----------------	---	-------------------















Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 10482-4 Assemblies include all parts shown in frames. 09/25/2015









REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697377	Cylinder Assembly	23B	591760	Flywheel Used on Type No(s). 0004, 0015, 0016, 0020, 0024, 0028, 0034, 0036, 0044, 0047, 0053, 0054 0055, 0057, 0063, 0067.	65	690940	Screw (Starter-Rewind)
2	797673	Kit-Bushing/Seal (Magnetos Side)				78	691693	Screw (Flywheel Guard)
3	391086s	Seal-Oil (Magnetos Side)				78A	690364	Screw (Flywheel Guard)
4	697106	Sump-Engine				81	691178	Lock-Muffler Screw
4A	592849	Sump-Engine Used on Type No(s). 0004, 0005, 0013, 0014, 0015, 0016, 0019, 0020, 0021, 0024, 0027, 0032, 0034, 0035, 0036, 0037, 0049, 0053, 0055, 0056, 0060, 0067.				94A	793610	Kit-Idle Mixture (Nikki)
					----- Note -----	95A	690718	Screw (Throttle Valve)(Nikki)
5	796183	Head-Cylinder			591761 Flywheel Used on Type No(s). 0002, 0027, 0031, 0035, 0038, 0056, 0058, 0060, 0061.	98A	695408	Kit-Idle Speed (Nikki)
7	273280s	Gasket-Cylinder Head	24	591757	Key-Flywheel	104A	694918	Pin-Float Hinge (Nikki)
11	794683	Tube-Breather	25	797009	Piston Assembly (Standard)	105A	696136	Valve-Float Needle (Nikki)
12	697110	Gasket-Crankcase (.015" Thick) (Standard)			----- Note -----	108A	698773	Valve-Choke (Nikki)
					797010 Piston Assembly (.020" Oversize)	117	591936	Jet-Main (Standard)
13	690360	Screw (Cylinder Head)	26	797011	Ring Set (Standard)			----- Note -----
14	790560	Stud (Cylinder Head)			----- Note -----			791405 Jet-Main Used on Type No(s). 0038, 0039, 0043, 0044, 0047, 0048, 0049, 0052, 0054, 0056, 0057, 0058, 0061, 0062, 0063, 0066, 0067.
15	690946	Plug-Oil Drain (3/8" Standard)			797012 Ring Set (.020" Oversize)			791405 Jet-Main (Used After Code Date 13092300).
16	593417	Crankshaft	27	698469	Lock-Piston Pin			Used on Type No(s). 0004, 0005, 0011, 0015, 0016, 0018, 0021, 0024, 0028, 0029, 0030, 0031, 0032, 0033, 0035, 0036.
		----- Note -----	28	797013	Pin-Piston			
		591949 Crankshaft Used on Type No(s). 0003, 0023, 0025, 0042, 0065, 0067.	29	791633	Rod-Connecting (Standard)			
20	795387	Seal-Oil (PTO Side)	32	791118	Screw (Connecting Rod)			
22	692125	Screw (Crankcase Cover/Sump)	33	792868	Valve-Exhaust (Chrome)			
23	591759	Flywheel	34	791935	Valve-Intake			
		----- Note -----	35	691279	Spring-Valve (Intake)			
		591758 Flywheel Used on Type No(s). 0001, 0005, 0007, 0009, 0010, 0011, 0013, 0014, 0018, 0019, 0021, 0022, 0032, 0037, 0039, 0062, 0066.	36	691279	Spring-Valve (Exhaust)			
23A	591950	Flywheel Used on Type No(s). 0029, 0030, 0050, 0052.	37	697352	Guard-Flywheel			
			37A	697626	Guard-Flywheel			
			42	499586	Keeper-Valve			
			43	691968	Slinger-Governor/Oil			
			45	690564	Tappet-Valve			
			46	793880	Camshaft			
			50	592845	Manifold-Intake			
			51	692137	Gasket-Intake			
			51A	796081	Gasket-Intake			
			53	591260	Stud (Carburetor)			
			54	691148	Screw (Intake Manifold)			

21R800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION			
118	696134	Jet-Main (High Altitude) ----- Note ----- 698788 Jet-Main Used on Type No(s). 0038, 0039, 0043, 0044, 0047, 0048, 0049, 0052, 0054, 0056, 0057, 0058, 0061, 0062, 0063, 0066, 0067. 698788 Jet-Main (Used After Code Date 13092300). Used on Type No(s). 0004, 0005, 0011, 0015, 0016, 0018, 0021, 0024, 0028, 0029, 0030, 0031, 0032, 0033, 0035, 0036.	130A	698774	Valve-Throttle (Nikki)	209	792602	Spring-Governor ----- Note ----- 792813 Spring-Governor Used on Type No(s). 0004, 0008, 0028, 0030, 0031, 0033, 0035, 0038, 0043, 0044, 0045, 0047, 0048, 0049, 0050, 0051, 0053 0055, 0056, 0057, 0058, 0064. 796260 Spring-Governor Used on Type No(s). 0001, 0003, 0006, 0007, 0012, 0017, 0019, 0026, 0027, 0034, 0039, 0067. 796261 Spring-Governor Used on Type No(s). 0009, 0046, 0059. 690576 Spring-Governor Used on Type No(s). 0002, 0061.			
121A	796184	Kit-Carburetor Overhaul (Nikki)	131A	698776	Kit-Throttle Shaft (Nikki)	216	691840	Link-Choke			
125	590400	Carburetor ----- Note ----- 590400 Carburetor (Used Before Code Date 13092400). Used on Type No(s). 0004, 0005, 0011, 0015, 0016, 0018, 0021, 0024, 0028, 0029, 0030, 0031, 0032, 0033, 0035, 0036. 593433 Carburetor Used on Type No(s). 0038, 0039, 0043, 0044, 0047, 0048, 0049, 0052, 0054, 0056, 0057, 0058, 0061, 0062, 0063, 0066, 0067. 593433 Carburetor (Used After Code Date 13092300). Used on Type No(s). 0004, 0005, 0011, 0015, 0016, 0018, 0021, 0024, 0028, 0029, 0030, 0031, 0032, 0033, 0035, 0036.	133A	694914	Float-Carburetor (Nikki)	216A	691281	Link-Choke			
			135A	698780	Tube-Fuel Transfer (Nikki) ----- Note ----- 796400 Tube-Fuel Transfer (Nikki) Used on Type No(s). 0004, 0005, 0011, 0013, 0015, 0016, 0018, 0021, 0024, 0028, 0029, 0030, 0031, 0032, 0033, 0035, 0036, 0039, 0038, 0043, 0044, 0047, 0048, 0049, 0052, 0054, 0056, 0057, 0058, 0061, 0062, 0063, 0066, 0067.	187	791766	Line-Fuel (Straight)(15" Long, Cut to Required Length)	217	695409	Spring-Choke Return
			137A	698781	Gasket-Float Bowl (Nikki)	222	694042	Bracket-Control ----- Note ----- 594500 Bracket-Control Used on Type No(s). 0057.			
			141A	698778	Kit-Choke Shaft (Nikki)	227	691374	Lever-Governor Control			
			186A	796532	Hose-Connector	232	691842	Spring-Governor Link			
			187	791766	Line-Fuel (Straight)(15" Long, Cut to Required Length)	238	691843	Cap-Valve			
			187B	791805	Line-Fuel (Formed)(Cut To Required Length)	240	394358s	Filter-Fuel (White, 75 Microns)			
			187A	796491	Line-Fuel (Formed)(Cut To Required Length)	240A	691035	Filter-Fuel			
			187D	791744	Line-Fuel (Formed)(Cut To Required Length)	265	691024	Clamp-Casing			
			188	691693	Screw (Control Bracket)	267	794904	Screw (Casing Clamp)			
			190	796174	Screw (Fuel Tank)	268	691025	Casing-Control Wire (Cut To Required Length)			
			202	691841	Link-Mechanical Governor						
			203	691381	Crank-Bell						
127A	690727	Plug-Welch (Nikki)									

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
269	691026	Wire-Control (Cut To Required Length)	346	794845	Screw (Spark-Arrester)	503	691532	Strap-Starter
270	691027	Nut (Control Wire Casing)	356	398808	Wire-Stop	505	691251	Nut (Governor Control Lever)
271	691028	Lever-Control	356A	697397	Wire-Stop	510	693699	Drive-Starter
276A	695410	Washer-Sealing	356B	697089	Wire-Stop	512	594200	Hose-Oil Drain
300	796000	Muffler	357	691483	Key-Drive Pulley	513	692024	Clutch-Drive
300B	795997	Muffler	358	796181	Gasket Set-Engine	521	690581	Shield-Cable
304G	591641	Housing-Blower (Black-Compatible With Canister Style Filter)	363	19203	Puller-Flywheel	523	699908	Dipstick
305	697102	Screw (Blower Housing)	377	691639	Key-Woodruff	524	691032	Seal-Dipstick Tube
305B	795891	Screw (Blower Housing To Intake Elbow)	383	19576s	Wrench-Spark Plug (Fuel Pump)	525	697085	Tube-Dipstick (With Tube Connector)
305C	799370	Screw (Grommet Style Blower Housing)	387	808656	Pump-Fuel	525A	697184	Tube-Dipstick (Without Tube Connector)
306	592778	Shield-Cylinder	404	691691	Washer (Governor Crank)	526	697088	Screw (Regulator)
307	691693	Screw (Cylinder Shield)	415	794903	Plug	526B	697348	Screw (Regulator)
309	693551	Motor-Starter	415A	794129	Plug (Cover/Retainer)	552	697144	Bushing-Governor Crank
310	690323	Screw (Starter Motor)	431B	797901	Elbow-Intake (EVAP)	562	691119	Bolt (Governor Control Lever)
324	796308	Screen-Rotating	445B	591583	Filter-Air Cleaner Cartridge (Canister Style)	563A	799359	Screw (Debris Guard)
333	799650	Armature-Magneto Used on Type No(s). 0004, 0015, 0016, 0024, 0028, 0029, 0030, 0031, 0034, 0035, 0036, 0038, 0044, 0047, 0050, 0052, 0053, 0054, 0055, 0056, 0057, 0058, 0060, 0063, 0067.	455	796615	Cup-Starter	578	692306	Wire Assembly
333A	592841	Armature-Magneto	462	691261	Washer (Starter Cable)	579	691029	Nut (Starter Cable)
334	691061	Screw (Magneto Armature)	474A	592828	Alternator (DC Only) Used on Type No(s). 0033, 0035, 0038, 0058.	584	794682	Cover-Breather Passage (Use With Liquid Sealant Reference 850)
337	792015	Plug-Spark (Resistor/EMS) ----- Note ----- 691043 Plug-Spark (EMS) Used on Type No(s). 0004. 491055s Plug-Spark (Resistor) Used on Type No(s). 0023, 0025, 0028, 0029, 0030, 0031, 0033, 0034, 0038, 0046, 0047, 0053, 0055, 0059, 0065.	474B	592831	Alternator (Dual Circuit) Used on Type No(s). 0003, 0006, 0008, 0023, 0025, 0026, 0027, 0031, 0041, 0042, 0043, 0045, 0046, 0048, 0049, 0051, 0054 0055, 0056, 0059, 0060, 0065, 0066.	601	791850	Clamp-Hose (Green)
			474C	592829	Alternator (Tri Circuit)	608	591606	Starter-Rewind
			474D	592830	Alternator (10-16 AMP) Used on Type No(s). 0004, 0034, 0039.	613	691416	Screw (Muffler)
			501	794360	Regulator	613A	691678	Screw (Muffler)
			501D	845907	Regulator Used on Type No(s). 0004, 0034, 0039.	613B	690297	Screw (Muffler)
			501E	698315	Regulator Used on Type No(s). 0020, 0024, 0036, 0047, 0053, 0057, 0063, 0067.	614	691620	Pin-Cotter
						616	692012	Crank-Governor
						617	692138	Seal-O Ring (Intake Manifold)
						633	699813	Seal-Choke/Throttle Shaft (Nikki)
						633B	690998	Seal-Throttle Shaft (Nikki)
						634A	698779	Spring/Seal Assembly (Nikki)

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
10482-11 Assemblies include all parts shown in frames. 09/25/2015

21R800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
635	691909	Boot-Spark Plug	847	790443	Dipstick/Tube Assembly (With Tube Connector)	994	794945	Spark-Arrestor
654	690958	Nut (Carburetor)	847A	790442	Dipstick/Tube Assembly (Without Tube Connector)	1005	796082	Fan-Flywheel
670	796175	Spacer-Fuel Tank	850	100106	Sealant-Liquid (Rocker Cover Gasket and Breather Gasket)	1017	796981	Screen-Oil Pump
676	795036	Deflector-Muffler (Side Out)	851	692424	Terminal-Spark Plug	1022	272475s	Gasket-Rocker Cover
676A	396903	Deflector-Muffler (Direct Out)	864	796002	Adapter-Muffler (Length 2.25 Inches)	1023	797421	Cover-Rocker
676B	795038	Deflector-Muffler (Louvered)	868	690968	Seal-Valve	1024A	794644	Pump-Oil
677	690661	Screw (Muffler Deflector)	877	393456	Wire/Connector-Alternator (Dual Circuit)	1026	794573	Rod-Push (Exhaust)
684	697157	Screw (Breather Assembly)	877D	790544	Wire/Connector-Alternator	----- Note -----		
691	692407	Seal-Governor Shaft	878	398661	Harness-Alternator (Dual Circuit)	697394 Rod-Push (Intake)		
697	791680	Screw (Drive Cap)	883	692236	Gasket-Exhaust	1027	492932s	Filter-Oil (Standard Black)
705	790561	Nut (Fuel Tank)	914	691108	Screw (Rocker Cover)	----- Note -----		
718	690959	Pin-Locating	920	691656	Solenoid-Starter	696854 Filter-Oil (Premium Yellow)		
729	691335	Clip-Wire	943	690589	O-Ring	1029	691751	Arm-Rocker
729A	691224	Clip-Wire (Starter Motor)	947	699915	Solenoid-Fuel	1034	690822	Guide-Push Rod
741	697128	Gear-Timing	949A	799358	Guard-Debris Screen	1036		Label-Emissions (Available From A Briggs & Stratton Authorized Dealer)
750	790832	Screw (Oil Pump Cover)	951	793386	Kit-Choke Shaft (Manual Choke)	1040	698368	Plate-Trim
757	793242	Counterweight	957	795027	Cap-Fuel Tank (Standard)	1040A	697381	Plate-Trim (Black)
758	593418	Counterweight	957A	799719	Cap-Fuel Tank (Carbon In Cap)	1044	698139	Screw (Flywheel)
759	697392	Pin-Counterweight	958	698183	Valve-Fuel Shut Off	1051	691265	Ring-Retaining
773	796448	Retainer	964	799159	Cap-Connector (EVAP)	1059	698516	Kit-Screw/Washer
783	693713	Gear-Pinion	965	499613	Cover-Oil Pump	1090	691293	Retainer-Brush
789	698329	Harness-Wiring	968B	591646	Cover-Air Cleaner (Black-Compatible With Canister Style Filter)	1091	691333	Cap-Limiter
789B	692037	Harness-Wiring	972	799111	Tank-Fuel (Fluorinated)	1095	796189	Gasket Set-Valve
789E	594999	Harness-Wiring Used in Conjunction with Regulator 698315	972A	792168	Tank-Fuel Used on Type No(s). 0016, 0056, 0060, 0067.	1119	691183	Screw (Alternator)
797	693167	Nut (Brush Retainer)	975A	699502	Bowl-Float (Nikki)	1127	695407	Screw (Float Bowl)
801	691283	Cap-Drive				1139	796449	Washer
802	691286	Cap-End				1146	793380	Screw (Choke Shaft)(Manual Choke)
823	698941	Screw (Muffler Adapter)				1263	697124	Reed-Breather
830	691095	Stud-Rocker Arm				1264	697104	Screw (Breather Reed)
832	790244	Guard-Muffler				1266	691917	Seal-O Ring (Intake Elbow)
832A	595029	Guard-Muffler				1270	793243	Plug-AVS Counterweight
836	690367	Screw-Tapping (Guard-Muffler)				1319	794467	Label-Warning
842	691031	Seal-O Ring (Dipstick Tube)				1319A	797669	Label-Warning
						1448	690260	Washer (Magneto Armature)

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

Not for
Reproduction

Not for
Reproduction

Not for
Reproduction

