		HRV												ERV							
		VHR 704	VHR 704R	VHR 100R	FLEX 100H	SHR 1504	SHR 1505R	VHR 1404	VHR 1405R	SHR 2004	SHR 2005R	VHR 2004	VHR 2005R	SHR 3005R	SHR 3205RD	SER 1504	SER 1504N	SER 2004	SER 2004N	SER 3204D	SER 3204N
CENTRAL HALLWAY CONTROLS																					
ECO- TOUCH		/	/	/	/	/	/	/	\	/	\checkmark	/	✓	/	✓	/	/	/	/	/	\checkmark
EDF1R		×	/	/	√	×	/	×	/	×	\checkmark	×	/	√	/	×	×	×	×	×	×
EDF1	. [.] .	/	/	/	/	/	/	/	/	/	√	/	/	/	/	√	/	/	/	/	/
MDEH1	0	/	/	/	\	\	/	/	\	✓	✓	/	/	\	/	√	×	✓	×	✓	×
MDEH2	0.	/	/	×	×	/	/	/	/	✓	√	/	\	/	/	√	×	/	×	/	×
BATHROOM, KITCHEN or LAUNDRY AUXILIARY CONROLS															55 F4						
RTS5		×	×	/	/	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
RTS3		/	/	×	×	✓	✓	/	/	/	√	/	/	/	/	/	/	✓	/	✓	√
RTS2	-10-	/	/	/	√	/	/	/	/	/	/	/	/	/	/	/	/	/	/	✓	/
MDEH1	0	/	/	/	/	/	/	/	/	√	√	/	√	/	√	√	×	√	×	/	×