

USING THE TOUCH SCREEN

The ecobee Smart Thermostat uses touch screen technology that makes navigation easy. With your finger, lightly tap the icons, buttons and lists or drag you finger across the screen to move a slider or scroll wheel.

temperature slider

Use your finger to press and move the set temperature slider left or right until the value in the magnifying lens displays the temperature you desire.



WiFi signal strength

home button

Use the Home button to return to the main screen at any time.



CONNECTING TO THE INTERNET

The ecobee Smart Thermostat is equipped with an interface that connects to any home wireless network. You must enable the WiFi radio in the ecobee Smart Thermostat and configure it in order to access your home wireless network.

If your network uses Static IP addressing or filters for MAC addresses, please refer to the User Manual for instructions on setting up the WiFi connection.

To set up the WiFi radio:



From the Home screen, Press **More**.



Press Settings.



Switch WiFi on.

Select your network from the list of available networks. Enter any applicable passwords.



Press **Done**.

FEATURE BUTTONS



REGISTER

Use the Register button to register your ecobee Smart Thermostat and create a personalized web portal at www.ecobee.com. Once you've successfully registered, this button is replaced by the Weather button.



WEATHER

This button displays the current outdoor temperature, weather conditions and offers a full five-day forecast. ecobee will use your local weather data to better control your heating and cooling.



DETAILS

This feature offers access to system details such as humidity levels and furnace fan settings. If you have a ventilator, humidifier or dehumidifier connected, Details will display these settings.



QUICK SAVE

This feature works just like a light switch. Using the Quick Save button will automatically set the ecobee Smart Thermostat to energy conservation mode.



PROGRAM

Use this feature to program the desired temperatures for each day of the week. The icon on this button changes to show which period of the day (awake, away, home, sleep) is currently in effect.



VACATION

The feature allows the ecobee homeowner to create a Vacation so that they can save energy while away.

PERSONAL WEB PORTAL

Once a wireless Internet connection is established, you need to register the thermostat to create your personal web portal.

Note: Once registration is complete, the registration button on the Home Screen will be replaced with the Weather button.

To register the ecobee Smart Thermostat:



From the Home Screen, press **Register**.

You will be prompted to enter your primary e-mail address.



Press Done.

You will be prompted to enter a password. Enter a password with a minimum of eight characters.



Press Done.

The ecobee Smart Thermostat sends a registration message to the specified e-mail address. This e-mail includes a link to www.ecobee.com where you will need to enter a user name and password to complete the registration.

You can now log on to your web portal to configure your Smart Thermostat.

PROGRAMMING YOUR SMART THERMOSTAT

The Smart Thermostat Wizard takes you step-by-step through a process to determine when you wake up, when you go to work, when you come home, and when you go to sleep. You'll then set your desired temperatures for each of those time periods.

If you want to make any changes, you can either run the Wizard again, or press Editor to make specific changes. Refer to the User Manual for detailed instructions on the Editor feature.

To use the Wizard:



From the Home Screen, press **Program**.

Press **Wizard** in the upper right corner of the screen.

Choose the settings that best fit your daily routine.



Press **Next** to go to the next question.



When the congratulations screen appears press **Done**.

If you do not connect to the internet, ensure that your have set the date and time. You can do this by tapping **More** on the Home Screen and selecting **Preferences** from the menu. Select **Date and Time** in the preferences menu.

ecobee sengany product summaring suggest store green made easy. green to green the g

See whats happening at www.ecobee.com

QUESTIONS OR CONCERNS?

CALL US TOLL FREE AT

1-877-9-ecobee

OR EMAIL SUPPORT AT

support@ecobee.com

477 Richmond Street West | #210 Toronto | Ontario | M5V 3E7 | Canada

