

IMPORTANT

1. Always include complete heater model and serial number so that any specification change can be considered for parts shipment. It can save time and expense.
2. Specifications are subject to change without notice.
3. We reserve the right to substitute functional replacements
4. Order by Part Number. **Do not** order by Option Number.

Applies to: Replacement Parts for Model F, FE, B, and BE Gas-Fired Unit Heaters

INDEX of Parts by Page No.	Blower Model		Fan Model	
	B	BE*	F	FE*
Air Shutter Assembly (Same as Option ED1)	13	13	13	13
Belt Guard/Blower Inlet Guard (Same as Option CD10 or CD12)	12	12	--	--
Blower and Components	7-12	7-12	--	--
Blower/Filter Cabinet (Same as Options CW1, CW2, CW3)	22	22	--	--
Bracket for Mounting Thermostat (Same as Option CM3)	20	20	20	20
Burner Racks and Carryovers	13	13	13	13
Cabinet Parts, Heater	4-5	4-5	4-5	4-5
Contactors	8	8	--	--
Downturn Air Outlet Nozzles (Same as Option CD 2, 3, 4, 5)	23	23	23	23
Drafthood	4-5	4-5	4-5	4-5
Drives	10	10	--	--
Duct Flange (Same as Option CD9)	5	5	--	--
ECO Device	18	--	18	--
Electrical Components	18-20	18-20	18-20	18-20
Fan and Components	--	--	6	6
Fan/Blower Control	18	18	18	18
Fan Guard	--	--	6	6
Flue Baffle	--	--	5	5
Flue Collection Box	--	--	4-5	4-5
Fuse/Fuseholder	19	19	--	--
Gas Conversion Kits	See Form CP-F/B-GC			
Hangers (Same as Options CK7, CK8, CK9, CK10, CK19)	21	21	21	21
Heat Exchangers	12	12	12	12
Ignition Controller	20	20	20	20
Ignition Conversion Kits	20	--	20	--
Limit Control	18	18	18	18
Louvers	4-5	4-5	4-5	4-5
Manifold	13	13	13	13
Motor (Fan or Blower)	7, 9	7, 9	6	6
Motor (Venter)	16	15	16	15
Multiple Heater Control Kit (Same as Option CL31 and CL32)	20	20	20	20
Pilots	14	14	14	14
Polytube Adapter (Same as Options CD6, CD8, CD11)	24	24	--	--
Pressure Switch	--	15	--	15
Rating Plate	2	2	2	2
Relay Kit for Low Ambient Fan Control (Same as Option CQ3)	20	20	20	20
Replacement Parts Tag	3	3	3	3
Serial Number Information	2-3	2-3	2-3	2-3
Starters	9	9	--	--
Switch, Blocked Vent	19	--	19	--
Switch, Summer/Winter (Same as Option CH1)	18	18	18	18
Tape (Flue Exhaust)	16	16	16	16
Thermostats	20	20	20	20
Transformers (Control)	19	19	19	19
Transformers (Same as Options CF and CG)	21	21	21	21
Valve, Electric Gas	See Form P-VALVES			
Valve, Manual Shutoff	13	13	13	13
Vent Cap	17	16	17	16
Vent Damper, Automatic (Same as Option AV7)	19	--	19	--
Venter - Models FE/BE	--	15	--	15
Venters (Models F/B - Same as Options CA1, CA2, CA3)	16	--	16	--

Warranty - Models F, FE, B, BE

One-year limited warranty on the heater

Nine-year extended limited warranty on the heat exchanger, drafthood, flue baffle assembly, flue collection box, and burners

Four-year extended limited warranty on operational parts (except blower belts)

**Model F,
Fan-Type,
Gravity Vent**



**Model B,
Blower-Type,
Gravity Vent**



***Model FE,
Fan-Type,
Power Vent**



***Model BE,
Blower-Type,
Power Vent**



*Models FE and BE are no longer manufactured.

Dates of Introduction

Model	Introduction
F	AND (4/88)
FE	AND (4/88)
B	ANL (12/88)
BE	ANL (12/88)

Example of a Rating Plate

REZNOR MERCER, PA. USA 16137 MADE IN MEXICO UNIT HEATER CATEGORY III FOR INDUSTRIAL/COMMERCIAL USE ONLY ANSI Z83.8a CGA 2.6-M98 UNIT HEATER MODEL [B] [C] SERIAL NO. BAA 65W7N12345 [D] VOLTS [D] PH [D] HZ MAXIMUM TOTAL INPUT [D] AMPS TYPE OF GAS: [E] ORIFICE SIZE [F] DRILL HAS BEEN FACTORY ADJUSTED FOR USE AT [H] FEET [G] METERS OF ALTITUDE <table border="0"> <tr> <td></td> <td>SEA LEVEL</td> <td>ALT. ADJUSTED</td> </tr> <tr> <td>NORMAL INPUT</td> <td>[I]</td> <td>[J] BTU/HR.</td> </tr> <tr> <td>THERMAL OUTPUT CAPACITY</td> <td>[K]</td> <td>[L] BTU/HR.</td> </tr> <tr> <td>MINIMUM INPUT (-2 MODELS)</td> <td>[M]</td> <td>[N] BTU/HR.</td> </tr> <tr> <td>NORMAL MANIFOLD PRESSURE</td> <td></td> <td>[O] IN.W.C.</td> </tr> <tr> <td>MIN. PERMISSIBLE GAS SUPPLY PRESSURE</td> <td></td> <td></td> </tr> <tr> <td>FOR PURPOSE OF INPUT ADJUSTMENT.</td> <td></td> <td>[P] IN.W.C.</td> </tr> </table>			SEA LEVEL	ALT. ADJUSTED	NORMAL INPUT	[I]	[J] BTU/HR.	THERMAL OUTPUT CAPACITY	[K]	[L] BTU/HR.	MINIMUM INPUT (-2 MODELS)	[M]	[N] BTU/HR.	NORMAL MANIFOLD PRESSURE		[O] IN.W.C.	MIN. PERMISSIBLE GAS SUPPLY PRESSURE			FOR PURPOSE OF INPUT ADJUSTMENT.		[P] IN.W.C.	 
	SEA LEVEL	ALT. ADJUSTED																					
NORMAL INPUT	[I]	[J] BTU/HR.																					
THERMAL OUTPUT CAPACITY	[K]	[L] BTU/HR.																					
MINIMUM INPUT (-2 MODELS)	[M]	[N] BTU/HR.																					
NORMAL MANIFOLD PRESSURE		[O] IN.W.C.																					
MIN. PERMISSIBLE GAS SUPPLY PRESSURE																							
FOR PURPOSE OF INPUT ADJUSTMENT.		[P] IN.W.C.																					
CLEARANCES TO COMBUSTIBLE CONSTRUCTION: TOP-[Q]", FLUE CONNECTION-6", LEFT SIDE-18", RIGHT SIDE-18", BOTTOM-12" EXCEPT WHEN SUPPLIED WITH OPTIONAL DOWNTURN NOZZLE BOTTOM IS 42". FOR ALTERNATE INSTALLATIONS USE THE LATEST EDITIONS OF THE APPROPRIATE STANDARD LISTED BELOW / INSTALL IN ACCORDANCE WITH REQUIREMENTS OF ENFORCING AUTHORITIES: FOR AIRCRAFT HANGARS USE STANDARD ANSI/NFPA 409 FOR PARKING STRUCTURES USE STANDARD ANSI/NFPA 88A FOR REPAIR GARAGES USE STANDARD ANSI/NFPA 88B THIS UNIT IS NOT FOR USE WITH DUCTS. THIS UNIT IS NOT FOR USE WITH FILTERS. THIS UNIT IS FOR USE WITH NATURAL GAS AND PROPANE. A CONVERSION KIT AS SUPPLIED BY THE MANUFACTURER, SHALL BE USED TO CONVERT THIS UNIT HEATER TO THE ALTERNATE FUEL.																							

Key to Rating Plate Information:

- B** = Model No. (Size)
C = Month and Year of Manufacture
D = Volts, Phase, Hertz and Maximum Total Input Amps
E = Type of Gas (Natural or Propane)
F = Burner Orifice Size
G and H = Elevation in Feet and Meters
I = Normal Input (BTUH) at Sea Level
J = BTUH Input Adjusted for Altitude
K = Thermal Output Capacity (BTUH) at Sea Level
L = BTUH Output Adjusted for Altitude
M = Minimum Input (BTUH) at Sea Level
N = BTUH Minimum Input Adjusted for Altitude
O = Normal Manifold Pressure (in. w.c.)
P = Minimum Gas Supply Pressure (in w.c.)
Q = Top Clearance (inches)

Serial No. Explanation

Example:

BAA	65	W7	N	12345
1	2	3	4	5

Key:

- 1 = Date of manufacturer (see table on page 3)
 2 = Type of Pilot (Refer to Form P-VALVES)
 3 = Gas Valve (Refer to Form P-VALVES)
 4 = Type of Gas (N = Natural; L = Propane)
 5 = Consecutive number of heater made (identification only)

Model No. Suffixes:

- S = Stainless steel heat exchanger
 -2 = Two-stage gas valve
 -E = Intermittent spark ignition (Models F/B)
 -H = High altitude

Example of a Replacement Parts Tag

Replacement parts tags on unit heaters are for your convenience in identifying replacement part numbers. Always give the full Model No., Serial No., and Part No. with description when ordering replacement parts.

COMMON REPLACEMENT PARTS FOR: MODEL: FE100 SERIAL NUMBER: BAA65W7N12345 WHEN ORDERING PARTS, ALWAYS GIVE THE FULL MODEL NUMBER AND SERIAL NUMBER. Fan or Blower Motor 95548 Fan Blade 41004 Fan Control 123976 Limit Control 45602 Transformer 131988 Pilot 97534 Gas Valve 170609 Heat Exchanger 102285 WARNING ALL PARTS ARE FOR USE WITH THE FUEL IDENTIFIED ON THE UNIT RATING PLATE. IF THE UNIT HAS BEEN CONVERTED TO OTHER FUELS, CHECK WITH THE DEALER FOR PROPER FUEL-CARRYING PARTS. INSTALLATION OF IMPROPER PARTS CAN CAUSE DEATH OR INJURY OR PROPERTY LOSS.	
--	--

First Element of the Serial Number - Date of Manufacture

Year	Jan	Feb	Mar	Apr	May	June	July	Aug	Sept	Oct	Nov	Dec
1988	ANA	ANB	ANC	AND	ANE	ANF	ANG	ANH	ANI	ANJ	ANK	ANL
1989	AOA	AOB	AOC	AOD	AOE	AOE	AOG	AOH	AOI	AOJ	AOK	AOL
1990	APA	APB	APC	APD	APE	APF	APG	APH	API	APJ	APK	APL
1991	AQA	AQB	AQC	AOD	AOE	AOF	AOG	AOH	AOI	AOJ	AOK	AOL
1992	ARA	ARB	ARC	ARD	ARE	ARF	ARG	ARH	ARI	ARJ	ARK	ARL
1993	ASA	ASB	ASC	ASD	ASE	ASF	ASG	ASH	ASI	ASJ	ASK	ASL
1994	ATA	ATB	ATC	ATD	ATE	ATF	ATG	ATH	ATI	ATJ	ATK	ATL
1995	AUA	AUB	AUC	AUD	AUE	AUF	AUG	AUH	AUI	AUJ	AUK	AUL
1996	AVA	AVB	AVC	AVD	AVE	AVF	AVG	AVH	AVI	AVJ	AVK	AVL
1997	AWA	AWB	AWC	AWD	AWE	AWF	AWG	AWH	AWI	AWJ	AWK	AWL
1998	AXA	AXB	AXC	AXD	AXE	AXF	AXG	AXH	AXI	AXJ	AXK	AXL
1999	AYA	AYB	AYC	AYD	AYE	AYF	AYG	AYH	AYI	AYJ	AYK	AYL
2000	AZA	AZB	AZC	AZD	AZE	AZF	AZG	AZH	AZI	AZJ	AZK	AZL
2001	BAA	BAB	BAC	BAD	BAE	BAF	BAG	BAH	BAI	BAJ	BAK	BAL
2002	BBA	BBB	BBC	BBD	BBE	BBF	BBG	BBH	BBI	BBJ	BBK	BBL
2003	BCA	BCB	BCC	BCD	BCE	BCF	BCG	BCH	BCI	BCJ	BCK	BCL
2004	BDA	BDB	BDC	BDD	BDE	BDF	BDG	BDH	BDI	BDJ	BDK	BDL
2005	BEA	BEB	BEC	BED	BEE	BEF	BEG	BEH	BEI	BEJ	BEK	BEL
2006	BFA	BFB	BFC	BFD	BFE	BFF	BFG	BFH	BFI	BFJ	BFK	BFL
2007	BGA	BGB	BGC	BGD	BGE	BGF	BGG	BGH	BGI	BGJ	BGK	BGL
2008	BHA	BHB	BHC	BHD	BHE	BHF	BHG	BHH	BHI	BHJ	BHK	BHL
2009	BIA	BIB	BIC	BID	BIE	BIF	BIG	BIH	BIJ	BIJ	BIK	BIL
2010	BJA	BJB	BJC	BJD	BJE	BJF	BJG	BJH	BJI	BJJ	BJK	BJL
2011	BKA	BKB	BKC	BKD	BKE	BKF	BKG	BKH	BKI	BKJ	BKK	BKL
2012	BLA	BLB	BLC	BLD	BLE	BLF	BLG	BLH	BLI	BLJ	BLK	BLL
2013	BMA	BMB	BMC	BMD	BME	BMF	BMG	BMH	BMI	BMJ	BMK	BML
2014	BNA	BNB	BNC	BND	BNE	BNF	BNG	BNH	BNI	BNJ	BNK	BNL
2015	BOA	BOB	BOC	BOD	BOE	BOF	BOG	BOH	BOI	BOJ	BOK	BOL
2016	BPA	BPB	BPC	BPD	BPE	BPF	BPG	BPH	BPI	BPJ	BPK	BPL
2017	BQA	BQB	BQC	BQD	BQE	BQF	BQG	BQH	BQI	BQJ	BQK	BQL
2018	BRA	BRB	BRC	BRD	BRE	BRF	BRG	BRH	BRI	BRJ	BRK	BRL
2019	BSA	BSB	BSC	BSD	BSE	BSF	BSG	BSH	BSI	BSJ	BSK	BSL
2020	BTA	BTB	BTC	BTD	BTE	BTG	BTG	BTH	BTI	BTJ	BTK	BTL


Literature References by Form No.:

All literature is available for viewing or downloading on www.RezSpec.com


Form	Applies to	Installation Instructions for:	Form P/N
I-F/B	F/B	Heater Installation Manual	98126
I-F/B-HV	F/B 250, 300, 400	Horizontal/Vertical Vent Outlet	102860
I-F/B-HV125	F/B125	Horizontal/Vertical Vent Outlet	132794
I-F/B-PV	F/B	Optional Power Venter	97967
I-FE/BE	FE/BE	Heater Installation Manual	98807
I-F/B-AS	F/B/FE/BE	Optional Air Shutters	98239
I-B-BF	B/BE	Optional Blower Cabinet	99714
I-B-BG	B/BE	Optional Guards	101542
I-B-DF	B/BE	Optional Duct Flange	101192
I-F/B-DN	F/B/FE/BE	Optional Downturn Air Nozzles	97926
CP-F/B-GC	F/B/FE/BE	Gas Conversion Kits	99279
I-F/B-LA	F/B/FE/BE w/1-stg gas valve	Optional Low Ambient Fan Control Relay	131134
I-B-PF	B/BE	Optional Polytube Adapters for Floor-Level Units	101694
I-B-PS	B/BE	Optional Polytube Adapters for Suspended Units	101500
I-F/B-R	F/FE/B/BE	Optional Relays	98149
I-B-SWB	B/BE	Optional Summer Fan Switch	101678
I-F-SWF	F/FE	Optional Summer Fan Switch	98294
I-F/B-VL	F/FE/B/BE	Optional Vertical Louvers	97925
I-F/B-X	F/FE/B/BE	Optional Stepdown Transformers	102265
P-VALVES	All	Ignition Controllers, Valves, & Serial No. Identification	N/A
CP-F/B-IGN	F/B	Ignition Conversion Kits	100550

Cabinet Parts

Model F/B Drafthoods (heaters manufactured beginning 10/89)




Sizes 25-100, 130-200




Sizes 125, 250-400

Original Vertical-only drafthood
(Models F&B manufactured before 10/89)
Replace with Codes 19A, 19B, 19C, 19D
illustrated at the top of the page




Code 20 -
Flue Baffle
Assembly -
Gravity
Vented
Models



REZNOR®

Code	Description	Size										
		25	50	75	100	125	130	165	200	250	300	400
1	Top Front	94661		94662	94663	94665	94663	94664	94665	94666		94667
2	Bottom Front	94668		94669	94670	94672	94670	94671	94672	94673		94674
3	Right Side Outer Panel			104968						104970		
4	Left Side Outer Panel			104969						104971		
5	Fan/Limit Access Panel						94898					
6	Wiring Access Panel						94897					
7	Bottom Panel	94687	94688	94689	94690	131607	94691	94692	94693	94694	94695	94696
8	Right Hinge Pin Assembly for Bottom Panel						96445					
	Left Hinge Pin Assembly for Bottom Panel						99351					
9	Fan Back Panel - Fan Model	94675		94676	161181	161184	N/A	161182	94680	161183		94682
10	Back Panel - Blower Model	99830		99831	99832	99835	99833	99834	99835	99836		99837
11	Latch Fastener for Fan Back (2) - used prior to 2/95						96435					
12	Horizontal Louver Assembly	94851		94855	94857	131803	94859	94863	94865	94867		94869
13	Vertical Louver Assembly (Same as Option CD1)	98500		98501	98502	136863	98503	98504	98505	98506		98507
13A	Vertical Louver Top/Bottom Member only	97852		97853	97854	97856	97854	97855	97856	97857		97858
13B	Vertical Louver only			95937					95938			
		(4)	(4)	(4)	(4)	(6)	(4)	(6)	(6)	(8)	(8)	(10)
14	Inner Left Side Panel			94842					94837			
15	Inner Right Side Panel (includes conduit nut plate for electrical supply)			99025					99026			
				102346					102347			
16A	Upper Stiffening Channel			100867 (2)					100869 (2)			
16B	Lower Stiffening Channel			100868 (2)					100870 (2)			
17	Air Deflectors (not illustrated)											
	Horizontal - Right Side	Fan Models	--	--	--	--		96141				94899
	Vertical - Right Side	All Models	96714	--	--	--	--	--	--	--	--	--
	Horizontal - Left Side	Fan Models	--	96140	--	--	96140		96141			94900
	Vertical - Left Side	All Models	96714	--	--	--	--	--	--	--	--	--
18A	Vertical Barrier			94749					94750			
18B	Horizontal Barrier						94751					
19A	Drafthood for Gravity Vent Sizes 25-200	102449		102450	102451	131608	102838	102839	102840	--	--	--
NOTE Below)	Drafthood Assembly for Gravity Vent Sizes 250-400	--	--	--	--	--	--	--	--	101909		101910
	Components: Drafthood Front	--	--	--	--	--	--	--	--	105310		105311
	Drafthood Right Rear	--	--	--	--	--	--	--	--	101903		101904
	Drafthood Left Rear	--	--	--	--	--	--	--	--	101906		101907
	Screws, #10 x 1/2" sheetmetal	--	--	--	--	--	--	--	--	51489 (6)		
19B	Flue Collar Assembly - Gravity Vent Models	102363		102364	102365	132765	102844	102845		102846		102847
19C	Flue Collar Support - Gravity Vent Models	--	--	--	--	131992	--	--	--			102857
19D	Cover for Horizontal/Vertical Vent	--	--	--	--	132764	--	--	--	102855		
	(On sizes 25-100 and 130-200, the cover and flue collar assembly are one piece)											
20	Flue Baffle Assembly - Gravity Vent Models	100859	100886	100887	100860	131811	100861	100862	100863	100864	100865	100866
21	Flue Collection Box Assembly - Power Vent Models	97744		97746	97747	131804	97748	97749	97750	97751	97752	97753
22A	Flue Baffle - Power Vent Models	--	--	97783	97784	134766	97785	97786	97787	101008	101009	101010
22B	Flue Baffle Clamp - Power Vent Models	--	--					98196				
23	Adapter Back Assy including Baffles	Blower Models	100871	100872	100873	131975	100874	100875	100876	100877		100878
24	Duct Flange Kit (Same as Option CD9)	Blower Models	101194	101195	101501	135591	101196	101197	101198	101199		101200
24A	Duct Flange Top and Bottom	Parts in Opts	101155	101156	101157	101159	101157	101158	101159	101160		101161
24B	Duct Flange Sides	CD9 and AX4	101163	101163	101163	101163	101164	101164	101164	101164		101164
25A	Reznor Logo Label						196690					
25B	Tawny Beige Touch-up Paint, 10 oz spray can						37919					
25C	Maroon touch-up Paint, 12 oz spray can						207432					


NOTE: Effective 4/1/91, all gravity-vent Model F and B heaters include a blocked vent system requiring holes in the drafthood. When replacing a drafthood on a heater without a blocked vent switch, these holes will not affect heater operation.



Fan Components -- Models F and FE

Code	Description	Size										
		25	50	75	100	125	130	165	200	250	300	400
26A	Full Fan Guard (See Notes below)	110907		110908	110910	132363	110910	136209 (replaces 110911)	110912	176647 (replaces 131404 and 110914)		176648 (replaces 110915 & 131405)
26B	Fan Guard Plate (2)	--	--	--	--	133977	--	133978	--	176151		
26C	Fan Guard Screws w/Washer	96450 (4)				--	--	--	96450 (4)			
	#10-32 1/2" Ig Hex Hd Screw									113275 (8)		
26D	Fan Guard Isolator Assy (4)	--	--	--	--	96451	--	96451	--	96451		
26E	Washer for Code 26D (4)	--	--	--	--	96452	--	96452	--	96452		
27	Motor Adapter Plate	--	--	--	--	96452	--	96452	--	176523		
28	Fan Motor, 115/1/60, Open	96286 Universal #JA2C377N	96287 Universal #JA2N199N	96288 Universal #JA2R238N	95548 1/30HP A.O. Smith #326P 139		95547 1/20HP			95546 1/6HP A.O. Smith #F42A51 AB	147913 1/4HP A.O. Smith #F48H01A13 (replaces 95545)	156275 1/2HP
	Fan Motor, 208/230/1/60, Open	--	--	--	--	97809 1/6HP A.O. Smith #322P943					122665 1/2HP Fasco #7128-0341	
	Fan Motor, 115/1/60, Enclosed	96286 Universal #JA2C377 M	100992 Universal #JA2S128N		102380 1/8HP A.O. Smith #322P986			102381 1/6HP A.O. Smith #F48G56A13	137044 1/4HP (replaces 115866)		--	
	Fan Motor, 230/1/50 Hertz (Opt AK11) Model F only	112675 Universal #JF2K010N			121277 A.O. Smith #92AC154					172794 Assy including motor P/N 155063		
	Fan Motor, .018HP, 115/1, School Option (Opt AL2B) for Model F50 only	--	174403	--	--	--	--	--	--	--	--	--
29	Fan Blades (For proper shaft placement, see Table in Fan Guard Notes below)	132465 Revcor #01005-18 (replaces 96377)	129853 Revcor #011005- 34 (replaces 96378)	96379 Revcor #G1203-30	41004 Lau #FP- 1437	131970 Revcor #T160 3-32	104692 Revcor #T1404- 40 (replaces 48692)	96380 Revcor G1603-40	96381 Lau #F10 H8.7 20-24	96382 Lau #F10 H8.7 22- 26	96383 Lau #F10 H8.7 22-36	96384 Lau #F-12 H8.7 24-36
	Fan Blades, 5/16" bore, 10" dia, 5 blades, 34° pitch, School Option (Opt AL2B) for Model F50 only	--	129853	--	--	--	--	--	--	--	--	--

Model FE illustrating one-piece Fan Guard



Fan Guard Notes

Model	Date of Manufacture	Type of Standard Fan Guard Marking	Standard Carton Fan Guard	Available Optional with Option	Carton Marking
F	4/88 - 10/90	Lower Half only	None	Upper Half	Upper Fan Guard
	After 10/90	One-Piece Full Guard	Full Fan	None	N/A
FE	4/88 - 10/89	Lower Half only	None	Upper Half	Upper Fan Guard
	10/89 - 10/90	Both Upper and Lower Halves	Upper Fan	None	N/A
	After 10/90	One-Piece Full Guard	Full Fan	None	N/A

Fan Guard Replacement - The upper and lower fan guard halves are no longer available.

If adding an "upper half" or replacing a fan guard, it is necessary to install the full fan guard (Code 24). To make this replacement, follow these instructions.


1. If the heater is installed, turn off the gas and disconnect the electric power.
2. Remove the left outer side panel (left when facing the rear of the unit). Disconnect the fan motor wires.
3. If present, remove the tension-mounted upper half fan guard.
4. Remove the four screws for attaching the fan guard. Remove the lower half fan guard, the motor, and the fan blade.
5. Assemble the new full fan guard, the motor and the fan blade. To Assure proper grounding of the motor, it is important that the same hardware be used for attaching the motor to the fan guard as was used with the original guard.

Be sure fan blade is in the same position on the shaft; see illustration and Table, page 7.


Blower Components (cont'd)

Models B and BE 50-400 with Belt-Driven Motor

Model BE with a Belt-Driven Motor




Code 44A - Motor Adjustment Mounting Assy - used with less than 1HP Motor



Code 44B - Blower Motor Mounting Bracket



Motor Adjustment Mounting Assy - 1HP and larger motor



Code	Description	Size							
		50	75	100	125	130/165	200	250/300	400
42A	Blower only	100655, Lau #A9-6ACD		100656, Lau #A9-9A	1357, LAU #10AC-10AC	100657, Lau #A12-9ACD	100658, Lau #A15-11ACD		100659, Lau #A15-15ACD
42B	Blower Mounting Angle	100888 (2)			131800 (2)	100889 (2)	100890 (2)		
42C	Blower Bearings	7310 (2)				10437 (2)			
43	Blower Washer 3/4" x 1-1/2"	--	--	--	--	1087 (4)			
44A	Mtr Adjustment Bracket Assy - 3/4HP or less	44411							
44B	Blower Mtr Mounting Bracket - 3/4HP or less	102536		102537	44409	102533	102534	102535	
45	Blower Mtr Mounting Plate - 1 HP and larger (plate only, see illustration for additional parts)	--	--	--	--	114545	194120	194118	
46	Key-1/4" square x 1-1/4" long	16099							

Motor Contactor

Code	Description	Sizes		Code 47 - Motor Contactor with Cover Removed
		50-300	400	
47A	Contactor, 115V, Furnas #42AF35AF (Important Note: If replacing a Gould contactor, order complete contactor assy including a new enclosure, P/N 95527)	119626 (replaces 93662)	--	
	Contactor, 230V, Furnas #42AF35AG (Important Note: If replacing a Gould contactor, order complete contactor assy including a new enclosure, P/N 95528)	119627 (replaces 93663)		
	Contactor, 460V, 24V Coil, Furnas #42AF35AJ (Important Note: If replacing a Gould contactor, order complete contactor assy including a new enclosure, P/N 95526)	119625 (replaces 93661)		
47B	Contactor Enclosure (for use with Furnas contactor only)	93917		
47C	Contactor Enclosure Cover (for use with Furnas contactor only)	120302		

Belt-Driven Blower Motors and Motor Starters

Motors that do not list a contactor and overload have internal overload protection and are used with a contactor (**Code 47A**, page 8). Motors in the tables below with a contactor (starter) and overload listed do not have internal overload protection and must be used with the motor starter and overload. All motor starters must be ordered with a NEMA 1 enclosure, **P/N 151207**, GE#CLXE1A.

Motor							Service	Power	Eff	Contactor	Reznor	Overload	o.l.	o.l.	Reznor
Type	HP	FLA	Model No.	P/N	volt	ph	Factor	Factor	%	GE #	P/N	GE #	min	max	P/N
Open	1/4	4.6	BF2024	210611	120	1	1.35			-	-	-	-	-	-
Open	1/4	2.3	BF2024	210611	208	1	1.15	63	59	-	-	-	-	-	-
Open	1/4	2.3	BF2024	210611	240	1	1.15	63	59	-	-	-	-	-	-
Open	1/4	1.1	H200	115864	208	3	1.35	72	74	-	-	-	-	-	-
Open	1/4	1.4	H200	115864	240	3	1.35	72	74	-	-	-	-	-	-
Open	1/4	0.75	H200	115864	480	3	1.35	72	81	-	-	-	-	-	-
Open	1/3	6	BF2034	202091	120	1	1.35			-	-	-	-	-	-
Open	1/3	3	BF2034	202091	208	1	1.35	62.8	61.3	-	-	-	-	-	-
Open	1/3	3	BF2034	202091	240	1	1.35	62.8	61.3	-	-	-	-	-	-
Open	1/3	1.4	H260	115863	208	3	1.35			CL00A310T-L	151150	RTA1-G	1.00	1.50	151187
Open	1/3	1.6	H260	115863	240	3	1.35			CL00A310T-S	151147	RTA1-H	1.30	1.90	151188
Open	1/3	0.8	H260	115863	480	3	1.35			CL00A310T-U	151148	RTA1-F	0.65	1.10	151186
Open	1/2	8.8	BF2054	102627	120	1	1.15			-	-	-	-	-	-
Open	1/2	5.1	BF2054	102627	208	1	1.15			-	-	-	-	-	-
Open	1/2	4.4	BF2054	102627	240	1	1.15			-	-	-	-	-	-
Open	1/2	2.5	H880	159183	208	3	1.25			-	-	-	-	-	-
Open	1/2	3	H880	159183	240	3	1.25			-	-	-	-	-	-
Open	1/2	1.5	H880	159183	480	3	1.25			-	-	-	-	-	-
Open	1/2		AOS - H991	202089	575	3				Contact distributor or factory.					
Open	3/4	11	312P629	93548	120	1	1.25			-	-	-	-	-	-
Open	3/4	6.3	312P629	93548	208	1	1.25			-	-	-	-	-	-
Open	3/4	5.5		93548	240	1	1.25			-	-	-	-	-	-
Open	3/4	2.9	312P696	36951	208	3	1.25			-	-	-	-	-	-
Open	3/4	2.6	312P696	36951	240	3	1.25			-	-	-	-	-	-
Open	3/4	1.3	312P696	36951	480	3	1.25			-	-	-	-	-	-
Open	3/4		AOS - H992	202090	575	3				Contact distributor or factory.					
Open	1	13	C523	13685	120	1	1.25			-	-	-	-	-	-
Open	1	7.5	C523	13685	208	1	1.25			-	-	-	-	-	-
Open	1	6.5	C523	13685	240	1	1.25			-	-	-	-	-	-
Open	1	3.7	H882	36580	208	3	1.15		79	-	-	-	-	-	-
Open	1	3.2	H882	36580	240	3	1.15		79	-	-	-	-	-	-
Open	1	1.6	H882	36580	480	3	1.15		79	-	-	-	-	-	-
Open	1	1.1	E1006	158175	575	3	1.15		82.5	CL00A310T-Y	151149	RTA1-G	1.00	1.50	151187
Open	1.5	15	C621	194202	120	1	1.2	86.4	77.2	-	-	-	-	-	-
Open	1.5	7.8	C621	194202	208	1	1.2	86.4	77.2	-	-	-	-	-	-
Open	1.5	7.5	C621	194202	240	1	1.2	86.4	77.2	-	-	-	-	-	-
Open	1.5	5.6	H884	115859	208	3	1.15	66.4	78.6	-	-	-	-	-	-
Open	1.5	5	H884	115859	240	3	1.15	66.4	78.6	-	-	-	-	-	-
Open	1.5	2.8	H884	115859	480	3	1.15	66.4	78.6	-	-	-	-	-	-
Open	1.5	1.6	E1007	158162	575	3	1.15	85.3	86.3	CL00A310T-U	151148	RTA1-H	1.30	1.90	151188
Open	2	20.4	V102	202581	120	1	1.15	81.8	77.5	-	-	-	-	-	-
Open	2	10	V102	202581	208	1	1.15	81.8	77.5	-	-	-	-	-	-
Open	2	10.2	V102	202581	240	1	1.15	81.8	77.5	-	-	-	-	-	-
Open	2	7	H886	159327	208	3	1.15	67	0.79	-	-	-	-	-	-
Open	2	6.6	H886	159327	240	3	1.15	67	0.79	-	-	-	-	-	-
Open	2	3.5	H886	159327	480	3	1.15	67	0.79	-	-	-	-	-	-
Open	2	2.1	E1008	158176	575	3	1.15	86	84.8	CL00A310T-Y	151149	RTA1-J	1.90	2.70	151189
Open	3	14	B735	111560	208	1	1.15	94.5	80.3	CL02A310T-L	151159	RTA1-P	10.00	16.00	151194
Open	3	12.4	B735	111560	240	1	1.15	94.5	80.3	CL01A310T-S	151152	RTA1-P	10.00	16.00	151194
Open	3	9	H845	159185	208	3	1.15			-	-	-	-	-	-
Open	3	8.6	H845	159185	240	3	1.15			-	-	-	-	-	-
Open	3	4.3	H845	159185	480	3	1.15			-	-	-	-	-	-
Open	3	3.6	H954	120019	575	3	1.15	80.3	83.8	CL00A310T-Y	151149	RTA1-K	2.50	4.10	151190
Open	3	8.9	M3158	152002	208	3			80	-	-	-	-	-	-
Open	3	8	M3158	152002	240	3			80	-	-	-	-	-	-
Open	3	4	M3158	152002	480	3			80	-	-	-	-	-	-
Open	5	28	V211	111562	208	1	1.15	79.2	78.9	-	-	-	-	-	-
Open	5	26	V211	111562	240	1	1.15	79.2	78.9	-	-	-	-	-	-
Open	5	13.4	196033	113371	208	3	1.15	87.2	78.9	CL01A310T-L	151155	RTA1-P	10.00	16.00	151194
Open	5	13.2	196033	113371	240	3	1.15	87.2	85	CL01A310T-S	151152	RTA1-P	10.00	16.00	151194
Open	5	6.6	196033	113371	480	3	1.15	87.2	85	CL00A310T-1	151275	RTA1-M	5.50	8.50	151192
Open	5	5.4	H956	120020	575	3	1.15	85.9	85	CL00A310T-Y	151149	RTA1-L	4.00	6.30	151191

Blower Components (cont'd)

Belt-Driven Blower Motors and Motor Starters (cont'd)

Motors (cont'd)							Service	Power	Eff	Contactor	Reznor	Overload	o.l.	o.l.	Reznor
Type	HP	FLA	Model No.	P/N	volt	ph	Factor	Factor	%	GE#	P/N	GE#	min	max	P/N
TEFC	1/4	3.6	STOCK #904	105566	120	1	1			-	-	-	-	-	-
TEFC	1/4	2.2	108152	16074	208	1	1.35			-	-	-	-	-	-
TEFC	1/4	1.9	108152	16074	240	1	1.35			-	-	-	-	-	-
TEFC	1/4	1.6	125439	16075	208	3	1	61.9	72.1	-	-	-	-	-	-
TEFC	1/4	1.4	125439	16075	240	3	1	61.9	72.1	-	-	-	-	-	-
TEFC	1/4	0.7	125439	16075	480	3	1	61.9	72.1	-	-	-	-	-	-
TEFC	1/3	4.6	STOCK #906	115861	120	1	1	68.5	72.1	-	-	-	-	-	-
TEFC	1/3	2.3	C151	159501	208	1	1	67.2	69.5	-	-	-	-	-	-
TEFC	1/3	2.4	C151	159501	240	1	1	67.2	69.5	-	-	-	-	-	-
TEFC	1/3	1.2	H261	105567	208	3	1.15		79.5	CL00A310T-L	151150	RTA1-G	1.00	1.50	151187
TEFC	1/3	1.2	H261	105567	240	3	1.15		79.5	CL00A310T-S	151147	RTA1-G	1.00	1.50	151187
TEFC	1/3	0.6	H261	105567	480	3	1.15		79.5	CL00A310T-U	151148	RTA1-D	0.40	0.65	151184
TEFC	1/2	7.2	C613	159184	120	1	1.15			-	-	-	-	-	-
TEFC	1/2	3.5	C613	159184	208	1	1.15			-	-	-	-	-	-
TEFC	1/2	3.6	C613	159184	240	1	1.15			-	-	-	-	-	-
TEFC	1/2	2.3	H274	16077	208	3	1	59.5	74.8	-	-	-	-	-	-
TEFC	1/2	2	H274	16077	240	3	1	59.5	74.8	-	-	-	-	-	-
TEFC	1/2	1	H274	16077	480	3	1	59.5	74.8	-	-	-	-	-	-
TEFC	1/2	0.7	H276	105568	575	3	1.15	76.4	77	CL00A310T-J	151146	RTA1-F	0.65	0.90	151186
TEFC	3/4	11	F353	115860	120	1	1	66	65.7	-	-	-	-	-	-
TEFC	3/4	5.4	F353	115860	208	1	1	66	65.7	-	-	-	-	-	-
TEFC	3/4	5.5	F353	115860	240	1	1	66	65.7	-	-	-	-	-	-
TEFC	3/4	2	H580	20371	208	3	1	73.5	81.1	-	-	-	-	-	-
TEFC	3/4	2.2	H580	20371	240	3	1	73.5	81.1	-	-	-	-	-	-
TEFC	3/4	1.1	H580	20371	480	3	1	73.5	81.1	-	-	-	-	-	-
TEFC	3/4	0.8	H461	105569	575	3	1.15	78.3	82	CL00A310T-J	151146	RTA1-F	0.65	1.10	151186
TEFC	1	12	159105	174993	120	1	1.15	74.3	70.6	-	-	-	-	-	-
TEFC	1	6.2	159105	174993	208	1	1.15	74.3	70.6	-	-	-	-	-	-
TEFC	1	6	159105	174993	240	1	1.15	74.3	70.6	-	-	-	-	-	-
TEFC	1	3.3	H524	16080	208	3	1	74.4	80.2	-	-	-	-	-	-
TEFC	1	3.4	H524	16080	240	3	1	74.4	80.2	-	-	-	-	-	-
TEFC	1	1.7	H524	16080	480	3	1	74.4	80.2	-	-	-	-	-	-
TEFC	1	1.4	H525	105570	575	3	1.15	71.6	80.4	CL00A310T-J	151146	RTA1-G	1.00	1.50	151187
TEFC	1.5	16.4	311P402	94347	120	1				-	-	-	-	-	-
TEFC	1.5	9.5	311P402	94347	208	1				-	-	-	-	-	-
TEFC	1.5	8.2	311P402	94347	240	1				-	-	-	-	-	-
TEFC	1.5	4.3	H535	101286	208	3	1	80.9	82.4	-	-	-	-	-	-
TEFC	1.5	4.4	H535	101286	240	3	1	80.9	82.4	-	-	-	-	-	-
TEFC	1.5	2.2	H535	101286	480	3	1	80.9	82.4	-	-	-	-	-	-
TEFC	1.5	1.6	E127	105665	575	3	1.15	85.7	84	CL00A310T-J	151146	RTA1-H	1.30	1.90	151188
TEFC	2	24	K200	105572	120	1	1	76.4	75.7	-	-	-	-	-	-
TEFC	2	12	K200	105572	240	1	1	76.4	75.7	-	-	-	-	-	-
TEFC	2	7	E166	158165	208	3	1.15	77.5	84	CL00A310T-L	151150	RTA1-M	5.50	8.50	151192
TEFC	2	5.8	E166	158165	240	3	1.15	77.5	84	CL00A310T-S	151147	RTA1-L	4.00	6.30	151191
TEFC	2	2.9	E166	158165	480	3	1.15	77.5	84	CL00A310T-U	151148	RTA1-K	2.50	4.10	151190
TEFC	2	2.3	E169	158166	575	3	1.15	77.5	84	CL00A310T-Y	151149	RTA1-J	1.90	2.70	151189
TEFC	3	30	K222	111564	120	1	1	88	75.5	-	-	-	-	-	-
TEFC	3	15	K222	111564	240	1	1	88	75.5	-	-	-	-	-	-
TEFC	3	7.9	M3559T	159330	208	3	1.15		85.5	CL00A310T-L	151150	RTA1-N	5.50	8.50	151192
TEFC	3	7.2	M3559T	159330	240	3	1.15		85.5	CL00A310T-S	151147	RTA1-N	5.50	8.50	151192
TEFC	3	3.6	M3559T	159330	480	3	1.15		85.5	CL00A310T-1	151275	RTA1-K	2.50	4.10	151190
TEFC	3	3	B-M3559T-5	111571	575	3	1.15		85.5	CL00A310T-J	151146	RTA1-K	2.50	4.10	151190

Belt Drive Components

Motor HP	Open Mtr AL Opt	Voltage AK Opt (Key, top left, pg 11.)	Drive AM Option (Key, btm left, pg 11.)	Motor Pulley			Blower Pulley			Type and Average Length*
				P/N	Model	Bore	P/N	Model	Bore	
1/4, 1/3	2, 3	AK1, AK2, AK3, AK5, AK6, AK7	1, 2	4074	1VL34	1/2	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	13491	1VL40	1/2	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	13491	1VL40	1/2	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	13491	1VL40	1/2	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	13491	1VL40	1/2	135200	AK 51	1	"A-section" 3.8 ft

**Key to AK
Nos.**

AK Voltage
1 115/1
2 208/1
3 230/1
5 208/3
6 230/3
7 460/3
8 575/3

**Key to AM
Nos.**

AM No./RPM
2 451-500
3 501-550
4 551-600
5 601-650
6 651-700
7 701-750
8 751-800
9 801-850
10 851-900
11 901-950
12 951-1000
13 1001-1050
14 1051-1100
15 1101-1150
16 1151-1200
17 1201-1250

NOTE:
Pulleys
require
keyseats,
see **Code 46**,
page 8.

Motor HP	Open Mtr AL Opt	Voltage AK Opt (Key, top left.)	Drive AM Option (Key, btm left.)	Motor Pulley			Blower Pulley			Type and Average Length*
				P/N	Model	Bore	P/N	Model	Bore	
1/2, 3/4, 1, 1 1/2	4, 5, 6, 7	AK1, AK2, AK3, AK5, AK6, AK7	1, 2	13580	1VL34	5/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	7962	1VL40	5/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	7962	1VL40	5/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	7962	1VL40	5/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	7962	1VL40	5/8	135200	AK 51	1	"A-section" 3.8 ft
1/2, 3/4	4, 5	AK8	1, 2	13580	1VL34	5/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	7962	1VL40	5/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	7962	1VL40	5/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	7962	1VL40	5/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	7962	1VL40	5/8	135200	AK 51	1	"A-section" 3.8 ft
1, 1-1/2	6, 7	AK8	1, 2	110125	1VP34	7/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	106748	1VL40	7/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	106748	1VL40	7/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	106748	1VL40	7/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	106748	1VL40	7/8	135200	AK 51	1	"A-section" 3.8 ft
2	8	AK1, AK2, AK3	1, 2	13580	1VL34	5/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	7962	1VL40	5/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	7962	1VL40	5/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	7962	1VL40	5/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	7962	1VL40	5/8	135200	AK 51	1	"A-section" 3.8 ft
		AK5, AK6, AK7, AK8	1, 2	110125	1VP34	7/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	106748	1VL40	7/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	106748	1VL40	7/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	106748	1VL40	7/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	106748	1VL40	7/8	135200	AK 51	1	"A-section" 3.8 ft
3	9	AK2, AK3	9, 10, 11, 12	7962	1VL40	5/8	202652	AK124	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	7962	1VL40	5/8	202653	AK94	1	"A-section" 3.8 ft
3, 5	9, 10	AK5, AK6, AK7, AK8	9, 10, 11, 12	106748	1VL40	7/8	101414	BK130	1	"B-section" 3.8 ft
			13, 14, 15, 16, 17	106748	1VL40	7/8	202654	BK105	1	"B-section" 3.8 ft

* Assume 17 Fenner belt links per foot. One "A" belt link is P/N 201809. "B" link is P/N 202655.

Motor HP	TEFC Mtr AL Opt	Voltage AK Opt (Key, top left)	Drive AM Opt (Key, btm left)	Motor Pulley			Blower Pulley			Type and Average Length*
				P/N	Model	Bore	P/N	Model	Bore	
1/4	19	AK1	1, 2	4074	1VL34	1/2	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	13491	1VL40	1/2	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	13491	1VL40	1/2	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	13491	1VL40	1/2	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	13491	1VL40	1/2	135200	AK 51	1	"A-section" 3.8 ft
		AK2, AK3, AK5, AK6, AK7	1, 2	13580	1VL34	5/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	7962	1VL40	5/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	7962	1VL40	5/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	7962	1VL40	5/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	7962	1VL40	5/8	135200	AK 51	1	"A-section" 3.8 ft
1/3	20	AK1, AK2, AK3, AK5, AK6, AK7	1, 2	4074	1VL34	1/2	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	13491	1VL40	1/2	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	13491	1VL40	1/2	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	13491	1VL40	1/2	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	13491	1VL40	1/2	135200	AK 51	1	"A-section" 3.8 ft
1/2, 3/4, 1	21, 22, 23	AK1, AK2, AK3, AK5, AK6, AK7, AK8	1, 2	13580	1VL34	5/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	7962	1VL40	5/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	7962	1VL40	5/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	7962	1VL40	5/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	7962	1VL40	5/8	135200	AK 51	1	"A-section" 3.8 ft
1 1/2	24	AK1, AK2, AK3, AK5, AK6, AK7	1, 2	13580	1VL34	5/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	7962	1VL40	5/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	7962	1VL40	5/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	7962	1VL40	5/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	7962	1VL40	5/8	135200	AK 51	1	"A-section" 3.8 ft
		AK8	1, 2	110125	1VP34	7/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	106748	1VL40	7/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	106748	1VL40	7/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	106748	1VL40	7/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	106748	1VL40	7/8	135200	AK 51	1	"A-section" 3.8 ft

(continued)

Blower Components (cont'd)

Belt Drive Components (cont'd)

Motor HP	TEFC Mtr AL Opt	Voltage AK Opt (Key, top left)	Drive AM Opt (Key, btm left)	Motor Pulley			Blower Pulley			Type and Average Length*
				P/N	Model	Bore	P/N	Model	Bore	
2	25	AK5, AK6, AK7, AK8	1, 2	110125	1VP34	7/8	111609	AK 99	1	"A-section" 3.8 ft
			3, 4	106748	1VL40	7/8	111609	AK 99	1	"A-section" 3.8 ft
			5, 6, 7	106748	1VL40	7/8	19111	AK 84	1	"A-section" 3.8 ft
			8, 9, 10, 11, 12	106748	1VL40	7/8	18797	AK 64	1	"A-section" 3.8 ft
			13, 14, 15, 16, 17	106748	1VL40	7/8	135200	AK 51	1	"A-section" 3.8 ft
3	26	AK5, AK6, AK7, AK8	9, 10, 11, 12	106748	1VL40	7/8	101414	BK130	1	"B-section" 3.8 ft
			13, 14, 15, 16, 17	106748	1VL40	7/8	202654	BK105	1	"B-section" 3.8 ft

* Assume 17 Fenner belt links per foot. One "A" belt link is P/N 201809. One "B" link is P/N 202655.

Optional Belt and Blower Guards - Blower Models

Code	Description	Size					Codes 186 and 187 - Guard Option Packages   52 Belt Guard 54 Blower Guard
		25	50/75/100	125	130/165	200/250/300/400	
50	Guard Package (Same as Option CD10) for Sizes 50-400 with Belt Driven Motors	--	101539		101540	101541	
51	Guard Package (Same as Option CD12) for Sizes 25-100 with Direct Drive Motor	114548	114548	--	--	--	
Components:							
52	Belt Guard - in Option CD10 and AZ6	--	193796		193797	193795	
53	Contact Mounting Bracket (not illustrated) - in Option CD10	--	101405		--	--	
54	Blower Inlet Guard - in Options CD10, CD12, AZ6, and AZ7	102474			102475		

Heat Exchangers

A gasket kit is included with replacement heat exchangers for Model B and BE heaters. If a new burner rack support is required, order P/N listed. Burner rack supports manufactured prior to 8/91 (Serial No. Date Code AQH) were not indexed.

Code	Description			Size										
				25	50	75	100	125	130	165	200	250	300	400
60	Heat Exchanger Assembly	Aluminized	F/FE	102282	102283	102284	102285	132743	102286	102287	102288	102289	102290	102291
			B/BE	173823	173824	173825	173826	173827	173828	173829	173830	173831	173832	173833
		409 Stainless	F/FE	102311	102312	102313	102314	132745	102315	102316	102317	102318	102319	102320
			B/BE	173834	173835	173836	173837	173838	173839	173840	173841	173842	173843	173844
60A	Gasket Kit <i>included</i> in Replacement Heat Exchangers for blower models. Kit includes five self-adhesive gasket strips, a tube of sealant and instructions.			102280					102281					
61	Indexed Burner Rack Support			113936							113937			


Code 60 - Heat Exchanger



Code 60A

P/N 113937 - Burner Rack Support for Sizes 250-400

(Same as Code 66 on page 13)



P/N 113936, Burner Rack Support for Sizes 25-200

Burner Rack and Components

Code	Description	Size										
		25	50	75	100	125	130	165	200	250	300	400
64	Burner Rack Assembly - Aluminized (includes burners and flash carryover; less pilot; less manifold and orifices; and less valve)	98983	98984	98985	98986	132753	98987	98988	98989	98990	98991	98992
	Burner Rack Assembly - Stainless Steel (includes burners and flash carryover; less pilot; less manifold and orifices; and less valve)	98993	98994	98995	98996	132755	98997	98998	98999	99000	99001	99002
64A	Burner only - Aluminized (qty of burners per Size in parenthesis)	94777 (2) (3) (4) (5) (6)					94781 (4) (5) (6) (8) (9) (12)					
	Burner only - Stainless Steel (qty of burners per Size in parenthesis)	97345 (2) (3) (4) (5) (6)					97348 (4) (5) (6) (8) (9) (12)					
65	Carryover Assembly	96769	47690	63128	96042	96044	96043	96042	96044	--	--	--
65A	Right Carryover Assembly	--	--	--	--	--	--	--	--	96045	96046	96045
65B	Left Carryover Assembly	--	--	--	--	--	--	--	--	96047	96047	96047
65C	Center Carryover Assembly	--	--	--	--	--	--	--	--	--	--	63156
66	Burner Rack Support	113936								113937		
67	Manifold only, less orifices, less valve	95434	95435	95436	95437	95440	95436	95437	95440	95441	95442	95443
68	Manifold with Natural Gas Burner Orifices for sea level* operation (less valve)	99003	99004	99005	99006	132749	99007	99008	99009	99010	99011	99012
	Manifold with Propane Gas Burner Orifices for sea level* operation (less valve)	99013	99014	99015	99016	132751	99017	99018	99019	99020	99021	99022
69	Burner Orifices	See chart on page 14.										
70	Pilot Shield (FE and BE Models and F and B Models with optional spark pilot)	97204										
71	Air Shutter Assembly (Same as Option ED1)	98476	98477	98478	98479	98480	98478	98479	98480	98481	98482	98483
72	Shut-off Valve with Union (Same as CE Option)	1/2"	196910									
		3/4"	--	--	--	--	--	--	--	--	--	196911

* A manifold with "sea level" orifices also applies if the manifold pressure has been adjusted in the field for high altitude operation (check for manifold adjustment label). If the heater was factory equipped for high altitude operation (Option AB), select high altitude orifices separately from the chart on page 14. Check the heater rating plate to identify the elevation at which the heater was manufactured to operate.

**Code 64 - Burner Rack Assembly
(Less pilot, manifold, orifices, and valve)**



Code 64A - Burner Only



Code 65 - Carryover assembly




Code 67 - Manifold (less orifices)



**Code 68 - Manifold with Orifices
Code 69 - Burner Orifices**



Code 70 - Pilot Shield



**Code 71 - Air
Shutter
Assembly**



Code 72 - Shutoff Valve with Union



1/2" Valve with Union,
P/N 196910

3/4" Valve with Union,
P/N 196911

Burner Rack Components (cont'd)


		Size											
Code	Description	25	50	75	100	125	130	165	200	250	300	400	
69	Burner Orifices (quantity in parenthesis)	<i>Use extreme care in selecting replacement burner orifices</i>											
		(2)	(3)	(4)	(5) (6)		(4)	(5)	(6) (8)		(9)	(12)	
	Natural Gas Orifices for a unit whose rating plate indicates sea level operation (0-2000 ft) even if the manifold pressure has been adjusted for high altitude operation - U.S.A. & Canada	39650 #51	84853 #47	38678 #45	11833 #44 #44		#35	#35	#35	#35	#35	#35	
	Propane Gas Orifices for a unit whose rating plate indicates sea level operation (0-2000 ft) even if the manifold pressure has been adjusted for high altitude operation - U.S.A. & Canada	95936 #60	63003 #1.2MM	64676 #1.3MM	11830 #55 #55		#1.65MM	#1.65MM	#1.65MM	#1.65MM	#1.65MM	#1.65MM	
	Orifices for factory-equipped high altitude (check the rating plate)												
	2001-4500 ft, Natural Gas - Canada	51284 #52	39651 #49	84853 #47	38678 #45 #45		#37	#37	#37	#37	#37	#37	
	2001-4500 ft, Propane Gas - Canada	97534 #62	63922 #1.15MM	97359 #1.25MM	11830 #55 #55		#1.55MM	#1.55MM	#1.55MM	#1.55MM	#1.55MM	#1.55MM	
	2001-3000 ft, Natural Gas - U.S.A.	39650 #51	40414 #48	16590 #46	38678 #45 #45		#36	#36	#36	#36	#36	#36	
	2001-3000 ft, Propane Gas - U.S.A.	97355 #61	39658 #56	97359 #1.25MM	11830 #55 #55		#52	#52	#52	#52	#52	#52	
	3001-4000 ft, Natural Gas - U.S.A.	51284 #52	40414 #48	84853 #47	38678 #45 #45		#36	#36	#36	#36	#36	#36	
	3001-4000 ft, Propane Gas - U.S.A.	97355 #61	63922 #1.15MM	97359 #1.25MM	11830 #55 #55		#1.55MM	#1.55MM	#1.55MM	#1.55MM	#1.55MM	#1.55MM	
	NOTE: All power vented models over 4000 ft also require high altitude venter pressure switch (Code 93B).												
		4001-5000 ft, Natural Gas - U.S.A.	51284 #52	39651 #49	84853 #47	38678 #45 #45		#37	#37	#37	#37	#37	#37
		4001-5000 ft, Propane Gas - U.S.A.	97354 #62	63922 #1.15MM	97359 #1.25MM	11830 #55 #55		#1.55MM	#1.55MM	#1.55MM	#1.55MM	#1.55MM	#1.55MM
	5001-6000 ft, Natural Gas - U.S.A.	51284 #52	39651 #49	84853 #47	16590 #46 #46		#37	#37	#37	#37	#37	#37	
	5001-6000 ft, Propane Gas - U.S.A.	40415 #63	63922 #1.15MM	63003 #1.2MM	39658 #56 #56		#53	#53	#53	#53	#53	#53	
	6001-7000 ft, Natural Gas - U.S.A.	51284 #52	39651 #49	40414 #48	84853 #47 #47		#38	#38	#38	#38	#38	#38	
	6001-7000 ft, Propane Gas - U.S.A.	40415 #63	40416 #57	63003 #1.2MM	39658 #56 #56		#53	#53	#53	#53	#53	#53	
	7001-8000 ft, Natural Gas - U.S.A.	9789 #53	39652 #50	40414 #48	84853 #47 #47		#39	#39	#39	#39	#39	#39	
	7001-8000 ft, Propane Gas - U.S.A.	97352 #64	40416 #57	63922 #1.15MM	39658 #56 #56		#53	#53	#53	#53	#53	#53	
	8001-9000 ft, Natural Gas - U.S.A.	9789 #53	39652 #50	39651 #49	40414 #48 #48		#40	#40	#40	#40	#40	#40	
	8001-9000 ft, Propane Gas - U.S.A.	97352 #64	40416 #57	63922 #1.15MM	39658 #56 #56		#1.45MM	#1.45MM	#1.45MM	#1.45MM	#1.45MM	#1.45MM	

Pilots

 Match-Lit Pilot P/N 110851 - Complete replacement pilot for natural gas, match lit pilot (includes Code 80 for natural gas and 81) P/N 110852 - Complete replacement pilot for propane gas, match lit pilot (includes Code 80 for propane gas and Code 81)			 Spark Pilot P/N 110853 - Complete replacement pilot kit for natural gas, spark pilot (includes Code 82 for natural gas, 83, and 84) P/N 110854 - Complete replacement pilot kit for propane gas, spark pilot (includes Code 82 for propane gas, 83, and 84)		
Code	P/N	Component Description	Code	P/N	Component Description
80	96360	Pilot Assembly, Natural Gas , with orifice, pilot tubing, thermocouple, and one compression fitting - Johnson #J994HKA-9731-715	82	97534	Pilot Assembly, Natural Gas , with orifice, pilot tubing, flame rod, and one compression fitting (does not include flame sensor lead) - Johnson #J982HKW-9731-715
	96361	Pilot Assembly, Propane Gas , with orifice, pilot tubing, thermocouple, and one compression fitting - Johnson #J994HKA-9733-410		97535	Pilot Assembly, Propane Gas , with orifice, pilot tubing, flame rod, and one compression fitting (does not include flame sensor lead) - Johnson #J982HKW-9733-410
80A	103034	Orifice only, Natural Gas , Johnson #9731-715 (brass)	82A	103034	Orifice only, Natural Gas , Johnson #9731-715 (brass)
	98695	Orifice only, Propane Gas , Johnson #9733-410 (black)		98695	Orifice only, Propane Gas , Johnson #9733-410 (black)
80B	98698	Pilot Tubing, Johnson #B10499-995-11, 1/8" O.D. x 18" long	82B	98698	Pilot Tubing, Johnson #B10499-995-11, 1/8" O.C. x 18" long
81	97572	Compression Fitting, #FTG75	83	97572	Compression Fitting, #FTG75
80C	84761	Thermocouple, 24", #K15FA-24D	82C	98697	Flame Rod, Johnson #Y75AA-3
			84	97575	Flame Sensor Lead, 21" (not illustrated)
NOTE: Match-Lit Pilots are used on Model F and B units with heater serial number safety pilot Code 31.			NOTE: Spark Pilots are used on Model FE and BE units and Model F and B units with heater serial number safety pilot Codes 65 or 66.		

Venters - Models FE and BE

Code	Description			Size						
				25/50/75	100	125	130	165/200/250	300	400
85	Venter Housing, DeStaco			98172 #250C with 4" Collar		131985 #250C with 5" Collar	98173 #350C with 4" Collar	101052 #350C with 5" Collar	98175 #350C with 6" Collar	
				(Order Venter Gasket, Code 86, with housing for Sizes 125-400)						
86	Venter Gasket (must be ordered with Code 85 for Sizes 125-400)			--	--	97300				
87	Venter Motor and Wheel Assy by supply voltage (less pressure switch and tubing	115/1	FE	97727		131986	97730			
			BE	97727		131986	97730			--
		208/1	FE/BE	--	--	133244	98369			
			230/1	FE	--	116102	133244	98369		
				BE	--	--	--	98369		
			208/3	BE	--	--	--	98369		
		230/3		BE	--	--	--	98369		
			460/3	BE	--	--	--	116280		
		575/3		BE	--	--	--	97730		
87A	Venter Motor Only (by supply voltage)	115/1	FE	148055 (replaces 97738) Magnetek JA1M213			165700 (replaces 148053 and 97741) McMillan #229396/1			
			BE	148055 (replaces 97738) Magnetek JA1M213			148053 (replaces 97741) Magnetek JE1E024			--
		208/1	FE/BE	--	--	148054, Magnetek JE1E025 (replaces 98157)				
		230/1	FE	--	148054 (replaces 98157), Magnetek JE1E025					
			BE	--	--	148054 (replaces 98157), Magnetek JE1E025				
		208/3	BE	--	--	148054 (replaces 98157), Magnetek JE1E025				
		230/3	BE	--	--	148054 (replaces 98157), Magnetek JE1E025				
		460/3	BE	--	--	115802, Fasco #7162-3388				
		575/3	BE	--	--	148053 (replaces 97741), Magnetek JE1E024				



Code 86 - Venter Gasket, P/N 97300



Code 87 - Venter Motor and Wheel Assembly



Code 91 - Venter Fan Blade, P/N 68005



Code 92 - Capacitor, P/N 163894



Code	Description	Size					
		25/50/75/100	125	130	165/200	250	300/400
87B	Venter Wheel Only	97725, Beckett #12063	131987, Beckett V325-2035	97724, Brookside #FE400-200-2			
90	Motor Plate (not illustrated)	68007			97301		
91	Venter Fan Blade, 2-1/2"	68005					
92A	Capacitor	--	163894 (replaces 87435 and 103181)				
92B	Capacitor Boot	--	--	--	103182		
93A	Pressure Switch Replacement Kit for sea level to 4000 ft elevation for Model FE/BE heaters mfgd prior to 1/94 (Date Code ATA)	196653					
	Pressure Switch Replacement Kit for above 4000 ft elevation for Model FE/BE heaters mfgd prior to 1/94 (Date Code ATA)	196654					

Venters - Models FE and BE (cont'd)

Code	Description	Size					
		25/50/75/100	125	130	165/200	250	300/400
93B	Pressure Switch for sea level to 4000 ft elevation for Model FE/BE heaters mfgd beginning 1/94 (Date Code ATA)	195316					
	Pressure Switch for above 4000 ft elevation for Model FE/BE heaters mfgd beginning 1/94 (Date Code ATA)	195317					
94	Sensing Tube Assy - heaters mfgd prior to 1/94	97210	--	97208			
	Sensing Tube Assy - heaters mfgd beginning 1/94	129859		129860			
95	Silicone Rubber Tubing - heaters mfgd prior to 1/94	(1)123571 - 9-3/4"	--	(2) 98221 - 3-1/2"		(1) 98221 - 3-1/2"	
	(1)123572 - 10-1/2"	--	(1)113774 - 4"				
	Silicone Rubber Tubing - heaters mfgd beginning 1/94	(1)130388 - 10"		(1)130389 - 3"		(1)131795 - 3-1/4"	
96	Strain Relief, Heyco #SR-5KN-5	98393					
97	RBM Relay (Essex #134-20102-101)	98118					
99	Vent Cap	111848 - 4"	111849 - 5"	111848 - 4"	111849 - 5"		111850 - 6"
99	Flue Exhaust Tape (not illustrated)	98266, Aluminum Tape, 550°F, 1" x 10 yds (Same as Option FA1)					

Code 94 - Sensing tube Assy

used on
heaters
mfgd prior
to 1/94



used on
heaters
mfgd
beginning
1/94



Code 95 - Silicone Tubing



Two pieces required on heaters manufactured prior to 1/94; one piece required on heaters manufactured beginning 1/94.

Code 97 - RBM Relay, P/N 98118



Code 98 - Vent Cap




Optional Power Venter for Gravity-Vent Units - Models F and B

Code	Description	Size							
		25/50	75/100	125	130	165	200	250/300	400
100	Power Venter Kits								
	115 volt Venter, Venter Adapter and Parts Bag (Same as Option CA1 - includes two hanger bracket assemblies for converting fan units to 4-pt suspension.)	98467		136862	98468			98471	
	208 volt Venter, Venter Adapter and Parts Bag (Same as Option CA2 - includes two hanger bracket assemblies for converting fan units to 4-pt suspension.)	--	--	135441	98469			98472	
	230 volt Venter, Venter Adapter and Parts Bag (Same as Option CA3 - includes two hanger bracket assemblies for converting fan units to 4-pt suspension.)	--	--	135442	98470			98473	
Replacement Component Parts for Optional Power Venters									
101	Venter Assy including Blower and Motor and Wheel Assy	115 volt	97976					97955	
		208 volt	--	--	97977			97956	
		230 volt	--	--	97978			97957	
102	Blower Housing Assy	6631					10529		
103	Venter Motor and Wheel Assy	115 volt	97980					97958	
		208 volt	--	--	97981			97959	
		230 volt	--	--	97982			97960	
104	Time Delay Relay, P/N 259518 , replacement for venter kits manufactured beginning 2/2010. For kits manufactured before 2/2010, order time delay replacement kit, P/N 259521 . (Venters requiring this kit will have a TI #6000060-17 time delay relay.)								
105	Sail Switch	97908 Cemco #JMP-154 4B-A					97907 Cemco #JMP 102-4B-C		

Code	Description		Size								
			25/50	75/100	125	130	165	200	250/300	400	
106	Venter Motor	115 volt	61069, Fasco #7121-4861					87434, Fasco #7161-1775			
		208 volt	--	--	30249, Fasco #7162-0186						
		230 volt	--	--	29571, Fasco #7162-0158						
107	Venter Wheel	29791, Torrington #AA-326-215-1						29792, Torrington #AA408-228-1			
108	Fan Blade, 3", RHF-0.3125 Bore	29793									
109A	Capacitor	--	--	--	--	--	--	163894 (replaces 103181)			
109B	Capacitor Boot, Sysntex#147-78	--	--	--	--	--	--	103182			
110	Venter Adapter Assembly	97823		146094	97824			97825			
111	Parts Bag for installing all Option CA Power Venters (See component list below)	97966									
111A	Flue Restrictor (not illustrated, included in Code 111)	98665 2-3/4x6	98664 2x6	97943 1x7	97944 1-1/2x7-3/4	97943 1x7	None	97944 1-1/2x7-3/4	None		
112	Conduit Connector, Tinnerman	(2) 97941									
113	Flexible Conduit, 5/16" x 24"	(2) 17950									
114	Vent Cap for gravity vent with optional power vent. Vent caps are not included with the venter kit.	111848 - 4"						111850 - 6"			
115	Flue Exhaust Tape (not illustrated and not included with Option kit)	98266, Aluminum tape 550°F, 1" x 10 yds									

Code 100 - Power Venter Kit (Parts Bag Not Illustrated - See Code 111)



Code 105 - Sail Switch



Code 107 - Venter Wheel



Code 108 - Venter Fan Blade



Code 109A - Capacitor, P/N 163894



Code 112 - Conduit Connector Code 113 - Flexible Conduit



Code 111 Parts Bag

Parts Bag, P/N 97966, is standardized for all sizes of power venters. It contains all of the items required for any installation and may include parts that are not used. The parts in **bold type** should always be used. Each parts bag includes:

Qty	P/N	Description
2	96386	Hanger Assembly
1	98364	Brown Wire Assembly
2	97941	Conduit Connector, Tinnerman #C54882-017
13	16354	Twist-on Wire Connector, Ideal #3-0273
11	11813	Sheetmetal Screws, #10 x 1/2"
1	16199	Box Connector, %&B #253
1	1417	90° Box Connector
2	16358	Anti-Short Bushing (red)
1	91453	Orange Wire, 18 Gauge x 60", 105°C
1	38463	Yellow Wire, 18 Gauge x 60", 105°C
1	38464	Brown Wire, 18 Gauge x 60", 105°C
1	3841	Black Wire, 18 Gauge x 36", 105°C
1	87880	White Wire, 18 Gauge x 36", 105°C
1	38462	Blue Wire 18 Gauge x 60", 105°C
2	148086	Open/Closed Bushing, Heyco #OCB625
1	97843	Restrictor, 1" Wide
1	97944	Restrictor, 1-1/2" Wide
1	98664	Restrictor, 2" Wide
1	99665	Restrictor, 2-3/4" Wide
2	16355	Wire Nuts (used for field connection on blower models)
1	103171	Warning Label

NOTE: Vent Cap size **required** for gravity vent models with **optional power vent** is listed as Code 114 in the table above.

Vent cap size and part number of cap for use with **standard gravity vent model (without power vent)** is listed in the table below.

**Code 114 -
Vent Cap**
(Same type of vent cap applies to both applications.)



*Run 7" vent pipe and use a field-supplied increaser with an 8" vent cap.


F&B Size	Vent Cap Diameter	P/N
25-50	4"	111848
75	5"	111849
100	6"	111850
125, 130	* 8"	61857
165, 200	8"	61857
250, 300	10"	61866
400	12"	61875

Electrical Components

Code	Description		Size									
			25	50	75/100	125	130/165	200	250	300	400	
120	ECO Limit Control *Beginning 8/99, Models FE and BE and Models F and B with optional spark pilot do not have an ECO limit control	F/FE*	131449 Thermodisc #G4AP0202110C, 109°C (replaces 96513)		82414 Thermodisc #G4AP0200152C, 152°C							
		B/BE*			131450 Thermodisc #G5AP0201152C, 152°C (replaces 82414 on blower heaters)							
121	Limit Control - heaters mfgd beginning 9/96	FE	85449 200°F		85449 200°F		82091 160°F	85449 200°F	45602 180°F			
		F	85449 200°F			45602 180°F	82091 160°F	85449 200°F	45602 180°F			
		BE	45602 180°F			100799 150°F						
		B	45602 180°F	85449 200°F		100799 150°F						
	Limit Control - heaters mfgd prior to 9/96	FE	85449 200°F		85449 200°F		82091 160°F	85449 200°F	45602 180°F			
		F	85449 200°F		45602 180°F		82091 160°F	85449 200°F	45602 180°F			
		BE	45602 180°F			100799 150°F						
		B	45602 180°F			100799 150°F						
	122 (See Note below)	Fan Control, Thermodisc #60T12 with Bracket	F/FE	123974 105/135°F (replaces 96387)	123976 95/135°F (replaces 114009)			123974 105/135°F (replaces 96387)				
			B/BE	123975, 95/150°F (replaces 100857)								
	123	Summer/Winter Switch Assembly (Same as as Option CH1)	F/FE	98484 (Includes McGill #TS-71-6A Switch and Wiring)								98485 (McGill #1010L Switch and Wiring)
			B/BE	101679, (Includes McGill #TS-71-6A Switch, Relay, and Wiring)								
124	2-Screw Terminal Strip for 24V Connections		96041									
125	4-Screw Terminal Strip for 24V Connections		96511									
126	RBM Relay		98118 (Essex #134-201-02-101) (standard for BE or FE venter; included in 2-stage control options)									
127	Time Delay Relay		--	--	97479, Thermodisc #305048							

NOTE: Temperature settings on the current replacement fan controls are different from the previous models because of a change in construction of the switch. However, these controls are interchangeable and will perform a nearly identical control function.

Code 120 - ECO Device



Code 121 - Limit Control, Automatic Reset



Code 122 - Fan Control Assembly



Code 123 - Summer/Winter Switch



Code 124 - Two-Screw Terminal Strip Connector, P/N 96041



Code 125 - Four-Screw Terminal Strip Connector, P/N 96511



Code 126 - RBM Relay, P/N 98118



Code 127 - Time Delay Relay, P/N 97479



Code	Description	Size					
		25	50	75/100	125	130/165/200	250/300/400
128A	Blocked Vent Switch, Thermodisc #36Tx46, 1/2" Snap Disk, manual reset, 1/4" QC (standard on gravity-vent models beginning April 1991 - Applies to Standard single units only (See Code 100B, Gasket)	112751 Setting Open @ 200°F #6215	112752 Setting Open @ 225°F #6217	121275 Setting Open @ 275°F #6279			
	Blocked Vent Switch, Thermodisc #36Tx46, 1/2" Snap Disk, manual reset, 1/4" QC (standard on gravity-vent models beginning April 1991 - Applies to optional two-stage units only (See Code 100B, Gasket)	--	--	112752 Setting Open @ 225°F #6217			
128B	Blocked Vent Gasket - for heaters with single-stage	--	(2) 121341	--	--	--	--
	Blocked Vent Gasket - for heaters with optional two-stage controls	--	--	(1) 121341	--	(1) 121341	--
129	Circuit Breaker W58XB1A4A8	(Fusible disconnect	146831				
130	On/Off Switch, McGill 4125-0004	Option AI1)	146830				

Code 128A - Blocked Vent Switch 	Code 129 - Circuit Breaker, P/N 146831 	Code 130 - On/Off Switch, P/N 146830 	Code 131 - Fuse/Fuse Holder for Blower Units with Optional 575 Volt Fuse, 2.5 amp, 2501, #3120, P/N 60242 Fuse Holder, Buss HTB-481, P/N 60241
---	--	---	---

Code	Description	P/N	Used on Models
Control Transformers			
132	115/1/60, 12VA, Basler #BE141615-RAD	131988 (replaces 102706)	F 25-400 Single-Stage, March-Lit Pilot
	B 25-300 Single-Stage, Match-Lit Pilot		
	115/1/60, 20VA, Basler #BE141620-RAD	132204 (replaces 102709)	FE 25-400 Single Stage, Spark Pilot
	 Control Transformer		BE 25-300 Single-Stage, Spark Pilot
			F 25-400 Single Stage, Spark Pilot
			B 25-300 Single-Stage, Spark Pilot
			F 75-400 Two-Stage, Match-Lit Pilot
			B 75-300 Two-Stage, Match-Lit Pilot
			BE 400 Two-Stage, Spark Pilot
		B and BE 400 with Optional 575 3ph/60Hertz	
	115/1/60, 35VA, Basler #BE141640-RAK	102708 (replaces 96507)	F 75-400 Two-Stage, Spark Pilot
	B 75-300 Two-Stage, Spark Pilot		
	208/230/1/60; 208/230/3/60; 35VA, Basler #BE21537004	103500 (replaces 96508)	FE 75-400 Two-Stage, Spark Pilot
BE 75-300 Two-Stage, Spark Pilot			
B 400 Single-Stage, Match-Lit Pilot			
B 400 Two-Stage, Match-Lit Pilot			
B 400 Single-Stage, Spark Pilot			
B 400 Two-Stage, Spark Pilot			
BE 400 Single-Stage, Spark Pilot			
F 130-400 with Optional 208/230V/1Ph/60 Hertz			
FE 130-400 with Optional 208/230V/1Ph/60 Hertz			
B 50-400 with Optional 208/230V/1Ph/60 Hertz			
BE 50-400 with Optional 208/230V/1Ph/60 Hertz			
F 25-400 with Optional 230V/1Ph/50 Hertz			
B 75-400 with Optional 208/230V/3Ph/60 Hertz			
BE 130-400 with Optional 208/230V/3Ph/60 Hertz			
460/3/60, 35VA, Basler #BE641640-RAK	103495 (replaces 96509)	B 75-400 with Optional 460V/3Ph/60 Hertz	
		BE 130-400 with Optional 460V/3Ph/60 Hertz	
600/3/60, 1/4 KVA, Type HSD, Primary/120-240V Secondary, Hevi-Duty	113556	B/BE 130-400 with Optional 575V/3Ph/60 Hertz	

Code 133 - Automatic Vent Damper with 8' Wiring Harness for Model F and B (Same as Option AV7; requires ignition controller with lockout - see Code 136B, page 20)

F/B Size	Vent	P/N
25, 50	4"	234005
75	5"	234006
100	6"	234007
125	7"	234008
165, 200	8"	234009
250, 300	10"	234010
400	12"	234011

Electrical Components (cont'd)

Code 134 - Low Ambient Fan Control Relay Kit, P/N 113779

Kit Components:		
Qty	P/N	Description
1	114007	Time Delay Relay Assembly (pre-wired consisting of Time Delay Relay Thermodisc #305055, P/N 97479, and four wire assemblies)
2	82485	Screws, #4 x 3/8" long (for attaching relay assy)
1	16354	Wire Nut
1	98117	Open/Closed Bushing



Application: The low ambient fan control relay kit is designed to prevent false cycling of the fan/blower on unit heaters installed in areas with ambient temperature of less than 40°F.

Code 135 - Optional Multiple Heater Control Kits

Screw (remove to install)

Terminal Strip

Place wiring diagram on lower right corner of the outer side panel.

Screw (remove to install)

Relay Bracket Assembly

Cable Clamp

Note: Multiple Heater Control Kits have multiple uses; they include spacers and screws that do not apply to these models.

Code 135A - Package P/N 102248 (Same as Option CL31)	Qty	P/N	Component Description
	1	102708	Transformer 35VA- Basler #BE141640-RAK
	2	103152	Sheetmetal Screws, #6 x 1-1/2" lg
	2	111233	Tinnerman Clips, #C1110-62
	2	102243	Relay Assembly
	2	16228	Cable Clamp
	2	131127	Wiring Diagram Label

Code 135B - Package P/N 102249 (Same as Option CL32)	Qty	P/N	Component Description
	1	102243	Relay Assembly
	1	16225	Cable Clamp 3/16"
	1	131127	Wiring Diagram Label

Ignition Controllers and Conversion Kits

Code 136A - Ignition Controller for Intermittent Spark Pilot System without Lockout, P/N 257009 (Serial No. Code 94)



To replace a previously used recycling ignition controllers without lockout (Serial No. Codes 62 and 66), order Replacement Kit, P/N 257472

Code 136B - Ignition Controller with Lockout, P/N 257010 (Serial No. Code 95)



To replace a previously used ignition controllers with lockout (Serial No. Codes 63, 65 and 84), order Replacement Kit, P/N 257473

Ignition Conversion Kits for Models F and B with Match-Lit Pilot


Model	Gas	Spark Kit with or without lockout	P/N
F/B 25-165	Natural	without Lockout	100525
F/B 200-250			100526
F 300-400, B 300			100527
B 400			102348
F/B 25-165	Natural	with Lockout	100528
F/B 200-250			100529
F 300-400, B 300			100530
B 400			102349
F/B 25-200	Propane	with Lockout	100531
F 250-400, B 250-300			100532
B 400			102350

Optional Thermostats & Thermostat Bracket

Code 137A - 1-stage, 24 volt, 50-90°F, P/N 255350 (Same as Option CL1)



Code 137B - 2-stage, 24 volt, digital, P/N 220630 (Same as Option CL22)



*Notes:

- 1) Do not increase the length of the coupling.
- 2) Due to possible vibration, do not use mercury switch thermostat with this bracket.

Code 137C - Thermostat Bracket, Package P/N 98524 (Same as Option CM3)

Component Description	P/N
2 x 4 Electrical Box	17782
1/2" Coupling*	7447
1/2" Chase Nipple (2)	3618
Bracket	98353

Optional Stepdown Transformer Kits - All Fan Models & Blower Models 25-100 with Standard Direct Drive Motors

HEATER MODEL	Same as Option No.	Transformer Pkg P/N	Components (plus items right):	
			P/N	TRANSFORMER
F 25-75	CF2 and CF4	102266	11279	.25 KVA, Type EP, 240-480 volt Primary / 115-240 Volt Secondary, Westinghouse #6E190
FE 25 and F 25 with Option CA1*	CG2 and CG4			
F 100-300	CF2 and CF4	102267	11100	.50 KVA, Type EP, 240-480 Volt Primary / 115-240 Volt Secondary, Westinghouse #6E191
B 25-50	CF4			
FE 50-100, 250 and F 50-100, 250 with Option CA1*	CG2 and CG4			
BE 25-50 and B 25-50 with Option CA1*	CG2 and CG4	102268	11217	.75 KVA, Type EP, 240-480 Volt Primary / 115-240 Volt Secondary, Westinghouse #6E192
FE 125-200, 300 and F 125-200, 300 with Option CA1*	CG2 and CG4			
F400	CF2 and CF4	102269	16065	1.0 KVA, Type EP, 240-480 Volt Primary / 115-240 Volt Secondary, Westinghouse #6E193
B 75-100	CF4			
FE 400 and F 400 with Option CA1*	CG2 and CG4			
BE 75-100 and B 75-100 with Option CA1*	CG2 and CG4			

Code 138 - Transformer Kit



Components (required to install transformer)

Qty	P/N	Description
1	102261	Bracket Assy
1	113275	#10 x 1/2" lg Sheetmetal Screw
1	16247	5/16 x 3/4" lg Hex Head Cap Screw
1	1333	5/16 Lock Washer
2	1087	Flat Washer
1	2039	BX Cable 3/8 x 18" long
1	16202	Straight Connector
1	1417	90° Connector
2	16358	Anti-Short Bushings
1	5566	Black Wire, 14 ga x 30" lg, 105°C
1	32525	White Wire, 14 ga x 30" lg, 105°C
1	102264	Green Wire, 14 ga x 30" lg, 105°C
10	16354	Wire Nut 73B

Hangers and Optional Hanger Kits

Code	Description	Models	P/N
140	Hanger Bracket Assy (2 standard on each fan unit, 4 standard on each blower unit)	F/FE25-400 & B/BE25-400	96386
141	Four-Point Suspension Kit (Same as Option CK7)	F/FE25-400	98508
142	Swivel Connection Kit for Two-Point Suspension (Same as Option CK8)	F/FE25-400	98509
143	Four-Point Suspension with Swivel Connections Kit (Same as Option CK9)	F/FE25-400	98510
144	Swivel Connection Kit for Four-Point Suspension (Same as Option CK10)	F/FE25-400 & B/BE25-400	98511
Components for Hanger Kits listed above:			
145	Swivel Connection only (to adapt for hanging from 1" threaded pipe)	All	17627
146	Lock Washers for installing Swivel Connections	All	5197
147	Pressure Switch Bracket only (required on power vented units manufactured prior to 8/92) (Use with Codes 141 or 143 on applicable sizes only.)	FE 25-100 mfgd prior to 8/92	98448
148	8-32 Nut for installation of Pressure Switch Bracket (Code 147A)		31522
149	Four-Point Suspension Kit designed to carry a nearly equal load at each suspension point (Same as Option CK19)	B/BE165-400	165742
Components for Hanger Kit Option CK19:			
149A	Right Side Hanger Bar	B/BE165-400	162829
149B	Left Side Hanger Bar	B/BE165-400	162830
149C	HHD Tap Bolts 3/8-16NCX 11-1/2 #5	B/BE165-400	(4)114350
149D	3/8" Lockwasher	B/BE165-400	(8)5197

Code 140 - Hanger Bracket



Code 141 - Kit to Convert Fan Model to 4-Pt Suspension



(Same as Option CK7)

Code 142 - Swivel Connection Kit for 2-Pt Suspension



(Same as Option CK8)

Code 143 - Kit to Convert to 4-Pt Suspension with Swivel Connections



(Same as Option CK9)

Code 144 - Swivel Connection Kit for 4-Pt Suspension



(Same as Option CK10)


Code 149 - 4-Pt Suspension for Blower Models - designed to equalize the load (Same as Option CK19)



Optional Blower/Filter Cabinet - Blower Models

Code	Description	Size								
		25/50	75	100	125	130	165	200	250/300	400
165	Blower/Filter Cabinet Package for Field Assembly, Adaptable for 1" or 2" filters (Same as Option CW1)	101543	101544	101545	140836	101546	101547	101548	101549	101550
166	Blower/Filter Cabinet Package for Field Assembly, includes 1" Filters (Same as Option CW2)	101628	101629	101630	140884	101631	101632	101633	101634	101635
167	Blower/Filter Cabinet Package for Field Assembly, includes 2" Filters (Same as Option CW3)	101636	101637	101638	140885	101639	101640	101641	101642	101643
Components:										
168	Top and Bottom Panel	99707			140841	100642	100642		--	--
169	Top Right and Bottom Left	--	--	--	--	--	--	--	101582	101584
170	Top Left and Bottom Right	--	--	--	--	--	--	--	101583	101585
171	Stiffening Channel for Top/Btm	--	--	--	--	--	--	--	101551	
172	Stiffening Angle for Top/Btm	--	--	--	--	--	--	--	101601	101602
173	Right Side Hanger	101578				101580				
174	Left Side Hanger	101579				101581				
175	Front Leg	99761	99762	99763	137404	100634	100635	100636	100637	100638
176	Top Filler Panel Assembly	101562	101563	101564	140838	101565	101566	101567	101568	101569
177	Bottom Filler Panel Assembly	101570	101571	101572	140840	101573	101574	101575	101576	101577
178	Rear Leg	99708				100639			100640	100641
179	Door	99712				100646				
180	Plastic Plug for Door Holes	82177								
181	Door Stop	99711				100645				
182	Center Filter Bracket Assembly	--	--	--	--	101624			101625	101626
183	Filter Angle	99710				101591			101592	101593
184	Filter Member	99709				101595			101596	101597
185	Permanent Aluminum Filters									
	16" x 20" x 1"	--	--	--	--	--	--	--	(2)101607	--
	20" x 20" x 1"	101608			--	--	--	--	(2)101608	--
	16" x 25" x 1"	--	--	--	101609				--	(2)101609
	20" x 25" x 1"	--	--	--	101610				--	(2)101610
	16" x 20" x 2"	--	--	--	--	--	--	--	(2)101620	--
	20" x 20" x 2"	101621			--	--	--	--	(2)101621	--
	16" x 25" x 2"	--	--	--	101622				--	(2)101622
	20" x 25" x 2"	--	--	--	101623				--	(2)101623

Blower/Filter Cabinet (with side panel removed)




Optional Downturn Air Outlet Nozzles

Code	Description	Size								
		25/50	75	100	125	130	165	200	250/30	400
195	Downturn Nozzle Kit, 25-65° Variable Air Deflection Range, including hanger brackets to convert fan units to 4-point suspension (Same as Option CD2)	98525	98526	98527	135512	98528	98529	98530	98531	98532
196	Downturn Nozzle Kit, 50-90° Variable Air Deflection Range, including hanger brackets to convert fan units to 4-point suspension (Same as Option CD3)	98533	98534	98535	135513	98536	98537	98538	98539	98540
197	Downturn Nozzle Kit, 25-65° Variable Air Deflection Range with Vertical Louvers, including hanger brackets to convert fan units to 4-point suspension (Same as Option CD4)	98541	98542	98543	135510	98544	98545	98546	98547	98548
198	Downturn Nozzle Kit, 50-90° Variable Air Deflection Range with Vertical Louvers (Same as Option CD5) IMPORTANT: Install on blower units only.	124918	124919	124920	137302	124921	124922	124923	124924	124926
Downturn Nozzle Component Parts (for vertical louver components, see page 5)										
199	Downturn Nozzle Side Panel only	97874					97875			
200	Downturn Nozzle Top Panel only	97876	97877	97878	135509	97879	97880	97881	97882	97904


NOTE: On fan models, do not use vertical louvers in combination with Code 196 (Option CD3). Do not install Code 198 (Option CD5) on fan models.

Outlet Nozzle Options CD2 and CD4




Sizes	"A"	Range of Air Deflection
25-125	9"	25°-65°
130-400	13"	25°-65°

Outlet Nozzle Options CD3 and CD5




Sizes	"A"	Range of Air Deflection
25-125	16-1/2"	50°-90°
130-400	23-1/2"	50°-90°



Optional Polytube Adapters - Blower Models, Sizes 75-400

Code	Description	Size							
		75	100	125	130	165	200	250/300	400
210	Polytube Adapter for Suspended Units with Polytube Discharge Above or Below Heater Discharge (Same as Option CD6)	101243	101244	137299	122086	101245	101246	101247	101248
	Polytube Adapter for Suspended Units with Polytube Discharge directly in line with Heater Discharge (Same as Option CD11)	104227	104228	137301	122087	104229	104230	104231	104232
211	Polytube Adapter for Floor-Mounted Units (Same as Option CD8) - Requires the addition of guards, Code 50.	101680	101681	137300	122160	101682	101683	101684	101685
Components Common to Suspended and Floor-Mounted Polytube Adapters:									
212	Discharge Panel Assembly - CD6, 8, 11	101249			101250				
213	Discharge Collar Clamp - CD6, 8, 11	101499			146463				
214	Adapter Left Side - CD6, 8	101253		132066	101254			101255	101254
215	Adapter Right Side - CD6, 8	101259		132066	101260			101255	101260
214/ 215	Adapter Side - CD11 (2 required)	104233		132195	104234			104235	104234
216	Adapter Top - CD6, 8	101266	101267	132062	121548	101268	101269	101270	101271
	Adapter Top - CD11	104236	104237	132063	121546	104238	104239	104240	104241
217	Adapter Bottom - CD6, 8	101272	101273	132062	121547	101274	101275	101276	101277
	Adapter Bottom - CD11	104242	104243	132064	121545	104244	104245	104246	104247
218	Polytube Holes Location Label - CD6, 8, 11 (not illustrated)	101263							
Components for Floor-Mounted Adapter only:									
219	Blower Support Assembly	101686							
220	Blower Legs	101689							
221	Support Angles	101691							
222	Cross Brace	101690							
223	Polytube Adapter Legs	101692							



www.RezSpec.com

800-695-1901

©2010 Thomas & Betts Corporation, All rights reserved.

Trademark Note: Reznor® is registered in at least the United States.
2/10 Form P-F/B (Version B)

Thomas & Betts