


**MAXair Premium Air Compressor part breakdown - C4160V1-MAP**

REVISED 5/8/17

Item	Description	C4160V1-MAP
1	Compressor w/ Flywheel	PV02AHP
2	Discharge Tube (2.5ft)	TU-23-AL
	Fitting/Elbow	EL1/4X90
3	Pressure Gauge (LIQUID)	PGLF200-2.5BM1/4
4	Outlet Valve (BALL VALVE)	BV1/2MF
5	Air Receiver (TANK)	60V20X48BR-Y
6	Drain Valve	OSB WO DC Assembly
7	V-Belt	4L530
8	Belt Guard	BGC
9	Motor - 1 Phase, 208/230V	EM05.0-36-1OSPL
10	Wiring Harness	12/3-24-C4
11	Check Valve	CTF1/2X1/2 Assembly
12	Pressure Switch	21UCBDB-170
13	Pulley - Motor	MA38X5/8
14	Unloader Tube w/ Fittings	TU1/4BLK
15	Safety Valve	PSV1/4-170
	Eagle Compressor Oil	EAOIL10



# MAXair

## PREMIUM

