
## OPERATION

Fully Automatic -Upon engine start, meter shows engine RPMs in sampled increments (some meters). At engine shut down, meter displays total accumulated running time. Flash Alert alarms will flash automatically for a 2 hour period (2 hours of engine run time) at the preset service intervals, as a service reminder.

## INSTALLATION

- 1. Find a convenient mounting location. Be sure the pick-up wire will reach the spark plug wire. If not, substitute with a wire of the same outside diameter of no less than 22 gauge, up to 8 feet long. DO NOT mount meter where surface temperature exceeds 125°F. As a general guideline, if you can place your hand on the mounting surface without discomfort while equipment is at full operating temperature, then it will be suitable to mount meter in that location.
- Use drill template (Fig. 1) to locate mounting holes. DO NOT DRILL INTO GAS TANKS OR ENGINE CRANKCASE. If in doubt, contact your dealer.
- 3. Secure pick-up wire into meter by placing wire over channel and pushing down with a flat screwdriver. Wire must be seated completely in channel (see Fig. 2). Fasten meter to mounting surface with supplied screws. Route meter wire to spark plug wire and attach as shown in Figure 3.



WARRANTY: The manufacturer will replace, free of charge, any parts which prove to be defective from faulty material or workmanship for a period of one year from date of purchase. Warranty is void if failure is caused from high heat, physical damage, or any other con-

dition of misuse or abuse beyond the normal operating conditions of the product. For repair or replacement (at manufacturer's option) return product postage pre-paid, along with a sales receipt showing date of purchase and purchase price, to: Warranty Dept., 151 Perinton Pkwy, Fairport NY, 14450. The manufacturer shall in no event be liable

The manufacturer shall in no event be liable for incidental or consequential damages arising from improper use, or inability to use the product, for any purpose whatsoever. All implied warranties arising hereunder shall be limited to one year from the original purchase date. This warranty covers only the original purchaser. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty shall last. So the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary, by state.



made in UNITED STATES