10b

10 10a 10b

SERVICE PARTS LIST

SPECIFY CAT
M18TM
CATALOG NO.

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS

M18™ Compact Brushless Hammer-Drill

2702-20

STARTING SERIAL NO.


NOTE:

G40A

REVISED BULLETIN DATE Feb. 2015

WIRING INSTRUCTION SEE PAGE 2





5d

3-(4x)





FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	05-88-1500	M6 x 27mm LH Chuck Screw	(1)
2	42-66-2702	1/2" Keyless Chuck	(1)
3	06-82-0135	M3 x 18mm Pan Hd. Plastite T-10 Screw	v (4)
4	14-29-0052	Gearbox Assembly	(1)
4a	45-24-2607	Speed Selector Slide	(1)
4b	44-10-2607	Speed Change Lever	(1)
4c	40-50-2607	Torsion Spring	(1)
5	14-20-0037	Electronics Assembly	
		Consisting of: On-Off Switch, PCBA, Sta	itor,
		LED Assembly, Battery Connector Block	
		and HV Contact Plate with Screw	(1)
5a	06-82-0062	M3 x 8mm Pan Hd. T-10 ST Screw	(1)
5b	40-50-0073	HV Contact Plate	(1)
5c		HV Wire (Component of Battery Connector Bl	ock) (1)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
5d		On-Off Switch	(1)
5e		LED Assembly	(1)
5f		PCBA	(1)
5g		Stator	(1)
5h		Battery Connector Block	(1)
6	16-07-0057	Service Rotor Assembly	(1)
7	31-44-0104	Housing Kit	(1)
7a	06-82-5315	M3 x 26mm Pan Hd. T-10 Plastite Screw	(1)
7b	06-82-6350	M3 x 16mm Pan Hd. T-10 Plastite Screw	(7)
7c	45-30-2653	Rubber Slug - Stator Support	(4)
7d	45-30-1000	Rubber Slug - Battery Connector Block Suppo	ort (2)
7e		Housing Halve - Right	(1)
7 f		Housing Halve - Left	(1)
7g	06-82-0135	M3 x 18mm Pan Hd. Plastite T-10 Screw	(1)
8	42-42-0082	Forward/Reverse Shuttle	(1)
9	43-72-0550	Bit Holder Kit (Optional)	(1)
10	42-70-2653	Belt Clip Kit (Optional)	(1)
10a	06-82-0130	6-32 x 5/16" Pan Hd. T-15 Screw (Option	al) (2)
10b		Belt Clip (Optional)	(1)
11	42-55-2701	Blow Molded Carrying Case	(1)
12	12-20-2701	Service Nameplate	(1)



PRIOR TO INSTALLING THE HANDLE COVER ONTO THE HANDLE

SUPPORT, BE SURE THAT THERE ARE NO INTERFERENCES.