

# **WorkBench**

**Instructions for Assembly and Operation**

**Instrucciones de montaje y funcionamiento**

**Directives d'assemblage et d'utilisation**



**For use with the MoJack PRO and MoJack EZ**

**Para el uso con el MoJack PRO y MoJack EZ**

**À utiliser avec les Mojack PRO et Mojack EZ**



**GIVING MOWER MAINTENANCE A LIFT.**


**ELEVE EL NIVEL DE MANTENIMIENTO DE SU CORTADORA DE CÉSPED.**

**ÉLÈVE LES NORMES EN MATIÈRE D'ENTRETIEN DES TONDEUSES.**

**www.theMoJack.com | 1-877-575-3173**

## Introduction

---



This manual contains assembly, parts, operating, maintenance, adjustment and safety instructions for your MoJack WorkBench accessory.

**BEFORE USING YOUR MOJACK WORKBENCH, CAREFULLY READ THIS MANUAL IN ITS ENTIRETY.**

By following these operating, maintenance and safety instructions, you will prolong the life of your MoJack lift and accessories and promote safe operation.

















If additional information is needed, or should you require a trained service mechanic, contact your authorized MoJack equipment dealer or distributor.

All MoJack parts are thoroughly tested and inspected before leaving the factory to ensure that they comply with all relevant safety standards.

**NOTE:** Please save this manual for future reference.

## Warnings and Safety Instructions

---

-  Read and understand all safety and operating instructions for the MoJack PRO or MoJack EZ Lift.
-  Read and understand all safety and operating instructions before using the MoJack WorkBench.
-  Never allow anyone unfamiliar with the safety or operating instructions to use the MoJack WorkBench.
-  Follow all safety and servicing instructions provided by the manufacturer of product being lifted before using the MoJack WorkBench.
-  Do not modify the MoJack WorkBench in any way. Any modifications will void any and all warranties and could compromise your personal safety.
-  When using the MoJack WorkBench, keep ALL bystanders at a safe distance away from the WorkBench.
-  The MoJack must be used on a solid level surface.
-  Always stop engine and remove key before beginning any work on the mower or any other item that is being lifted on the WorkBench.
-  Never operate the mower's engine while using the MoJack WorkBench.
-  Do not exceed the lifting capacity of 200 lbs.
-  If the MoJack Tower is leaning while lifting or lowering the MoJack WorkBench, this indicates an overload condition. Remove the load immediately.
-  Do not remove safety warnings or decals from the MoJack WorkBench.
-  Do not climb on the MoJack WorkBench while it is lifted, being lifted or being lowered.
-  No one should be on the MoJack WorkBench while it is lifted, being lifted or being lowered.
-  When using the WorkBench insert(s), do not load objects in front of the warning sticker.
-  Failure to follow these warnings may result in property damage and serious bodily injury or death.

**IMPORTANT:** The MoJack WorkBench is intended for use with walk-behind lawn mowers and small projects only. Do not exceed 200 lbs.

# Warranty and Returns

---

## LIMITED WARRANTY

For two years for residential use and one year for commercial use MoJack warrants the product against failure due to defect in material or workmanship when product is used properly. MoJack will replace any defective part at no cost. This warranty does not cover any product that has been altered or adjusted, or any product that has been misused or abused. THIS IS THE CUSTOMER'S SOLE AND EXCLUSIVE REMEDY. MOJACK DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. MOJACK SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES OR PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF THE IMPLIED WARRANTIES OR THE REMEDIES FOR BREACH OF THE IMPLIED WARRANTIES, SO THESE EXCLUSIONS MAY NOT APPLY TO YOU. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

### What does this warranty cover?

This warranty covers against a failure due to a defect in material or workmanship within two years of purchase for residential use and within one year of purchase for commercial use.

### What does this warranty NOT cover?

This warranty does not cover any MoJack which has been altered or adjusted in any way from its original model. It will not cover any MoJack which has been damaged due to misuse, abuse, accident or negligence. This warranty does not cover incidental or consequential damages.

### What is the period of coverage?

Two-year warranty for residential use, one-year for commercial use from date of purchase for the original owner.

### What will MoJack do to correct problems?

We will replace any defective part (within the coverage period) at no charge.

### How can I get service?

In order to be eligible for service under this warranty you MUST register your MoJack within thirty (30) days of purchasing. You must keep your receipt as proof of date of sale. You can register your new MoJack on our website at [www.themojack.com](http://www.themojack.com) or by calling our toll-free number 1-877-575-3173.

### How do I contact MoJack about a warranty issue?

You can contact us from our website at [www.themojack.com](http://www.themojack.com) or by calling our toll-free number 1-877-575-3173.

### Do I have other rights under State Law?

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

### What is the return policy?

Within thirty (30) days of the date that you receive your MoJack. Please contact MoJack for return policies and procedures at our toll-free number 1-877-575-3173 or by email at [info@themojack.com](mailto:info@themojack.com).

### How do I make a return?

Contact us within the return period. We will issue you a Return Merchandise Authorization (RMA) to place on the outside of the box. All merchandise must be shipped back in its original packaging. We will make arrangements for the MoJack to be picked up by a national carrier.

### In what form will I receive my refund?

This is at our discretion. If receiving a refund, please allow four weeks for the credit to process to your account. Return service fees will be deducted from the amount of the refund.

### Are shipping charges refundable?

No.

### Does MoJack have a return service fee policy?

Yes. Returns and refunds impose an extra workload on our parts. Rather than pass this cost on to the customer through higher product prices, we are consistent with others within our industry by requiring nominal service fees in the event of returns. The service fee is 20%.


### How do I contact MoJack?

You can call our toll-free number 1-877-575-3173 or by email at [info@themojack.com](mailto:info@themojack.com).



## Parts List

Item No.	Qty.	Description
①	1	Left Sled
②	1	Right Sled
③	2	WorkBench Insert
④	2	Sled Insert




## Hardware List

Item No.	Qty.	Description
⑤	2	Clevis Pin
⑥	2	Hair Pin
⑦	2	Cap Screw – M12-1.75 x 65
⑧	2	Nylock Nut – M12-1.75




⑤ Clevis Pin



⑥ Hair Pin



⑦ Cap Screw – M12-1.75 x 65




⑧ Nylock Nut – M12-1.75

# Assembly Instructions for use with MoJack EZ

## STEP 1


Remove MoJack WorkBench from package.

Inventory items to be certain all parts and hardware are present. If any parts or hardware are missing, please contact MoJack at 1-877-575-3173 or email us at [parts@themojack.com](mailto:parts@themojack.com).





## STEP 2

Slide the Left and Right Sleds (1) and (2) into the Lift Arm and secure with Push Pins that are used to secure the wheel pads of the MoJack as shown.



## STEP 3 (Optional)

Place the WorkBench Inserts (3) onto the Left and Right Sleds (1) and (2) as shown.




# Operating Instructions for use with MoJack EZ

## STEP 1


### Move push mower onto sleds

- With the carrier arm fully lowered, lift the front end of the push mower onto the sleds and then move the push mower so that the front wheels of the push mower are touching the front of the sleds.
- Secure the push mower to the sleds by attaching the Clevis Pin (5) and Hair Pin (6) as shown.



## STEP 2 (Optional)

With the WorkBench inserts secured between the sleds. Place desired object to be lifted onto the inserts.




# Operating Instructions for use with MoJack EZ

## STEP 3

### Raising the Mower

- Raise the mower by rotating the Crank Handle clockwise.


- ⚠ Do not attempt to lift more than 200 lbs.
- ⚠ The MoJack must be used on a solid level surface.
- ⚠ The mower engine must be turned off.
- ⚠ If using the WorkBench Inserts, do not install past safety sticker.



## STEP 4

### Raising Lift Arm to Locking Position


- Raise the Lift Arm until the Carrier Locking Pin drops into the Safety Hole.
- The Carrier Locking Pin automatically drops into the Safety Holes as the Carrier passes the Safety Holes on the Tower when raising.
- Note: When lowering the Lift Arm, the Carrier Locking Pin must be held out by the operator until it clears the bottom Safety Hole.



## STEP 5

### Lowering the Mower

- Pull and hold the Carrier Locking Pin out and turn the Crank Handle counterclockwise until Wheel Pads are firmly on the ground. The Carrier Locking Pin must be pulled out until it clears the bottom Safety Hole.






# Assembly Instructions for use with MoJack PRO

## STEP 1


Remove MoJack WorkBench from package.

Inventory items to be certain all parts and hardware are present. If any parts or hardware are missing, please contact MoJack at 1-877-575-3173 or email us at [parts@themojack.com](mailto:parts@themojack.com).




## STEP 2

Slide Sled Inserts (4) onto Sleds (1) and (2), and secure using Cap Screws (7) and Nylock Nuts (8) and tighten as shown.





## STEP 3

Slide the Left and Right Sleds (1) and (2) into the Lift Arm and secure with Push Pins that are used to secure the wheel pads of the MoJack as shown.



## STEP 4 (Optional)

Place the WorkBench Inserts (3) onto the Left and Right Sleds (1) and (2) as shown.




# Operating Instructions for use with MoJack PRO

## STEP 1


### Move push mower onto sleds

- With the carrier arm fully lowered, lift the front end of the push mower onto the sleds and then move the push mower so that the front wheels of the push mower are touching the front of the sleds.
- Secure the push mower to the sleds by attaching the Clevis Pin (5) and Hair Pin (6) as shown.



## STEP 2 (Optional)

With the WorkBench inserts secured between the sleds. Place desired object to be lifted onto the inserts.




# Operating Instructions for use with MoJack PRO

## STEP 3

### Raising the Mower

- Raise the mower by rotating the Winch Handle clockwise.


- ⚠ Do not attempt to lift more than 200 lbs.
- ⚠ The MoJack must be used on a solid level surface.
- ⚠ The mower engine must be turned off.
- ⚠ If using the WorkBench Inserts, do not install past safety sticker.



## STEP 4

### Locking Carrier into the Safety Ratchet

- As the Carrier raises, the clicking sound indicates that the Safety Ratchet is functioning properly. Once the mower is at the desired working height, rotate the Winch Handle 1/2 turn counterclockwise to release the tension off of the Lifting Strap and allowing the Carrier to rest firmly on the Safety Ratchet.



## STEP 5

### Lowering the Mower

- Turn the Winch Handle 1/2 turn clockwise and squeeze the Grip Handle and Ratchet Release Handle together. Keeping the Grip and Ratchet Release Handles squeezed together, turn the Winch Handle counterclockwise until the Wheel Pads are firmly on the ground.

