

## INSTALLATION INSTRUCTIONS PURGE BULB KIT



## **WARNING**

Failure to follow these safety instructions when performing maintenance repair could result in severe personal injury or property damage.

- If you are not comfortable performing any of the functions described in these instructions, take your unit to an authorized servicing dealer
- Always stop engine, disconnect spark plug, and make sure all moving parts have come to a complete stop and allow unit to cool before servicing unit. Wear gloves to protect hands from sharp edges and hot surfaces.
- Work in a well-ventilated area, away from open flames or sparks.
- Drain fuel from tank and store in an approved container a minimum of 10 feet away from the work area.
- See operator's manual for complete maintenance schedule and procedures.



### **WARNING**

To reduce the risk of injury, read and understand the operator's manual for your unit, and this instruction sheet. Always wear eye protection that complies with ANSI Z87.1. Ensure compatibility and fit before using this accessory. Do not use this accessory if a part is damaged or missing.



#### DANGER:

Fuel is VERY flammable. Use extreme care when mixing, storing or handling, or serious personal injury may result.

#### **KIT CONTENTS:**

## **Large Purge Bulb (P005003120)**

Replaces:

Shindaiwa 12538108660, P005003110,

12538146730

**ECHO** 12538108660, P005003110,

12538146730

Stihl 4226 121 2700

Zama 0057003, 0057004, 0057034,

0057035

Stens 615-792

Fits: Zama C1M, C1Q and C1U Zama carburetors

# Remote Purge Bulb (12318139130)

Replaces:

Homelite/Jacobsen 1123

791-683974 MTD McCulloch 224242-01 Oregon 07-073 Ryan/Ryobi 683974 Stens 615-764

Stihl 4130-350-6200 Tanaka 442-25143-800 Walbro 188-512, 188-512-1

#### Small Purge Bulb (12318140630)

Replaces:

Homelite 01201, UP04802

McCulloch 225834-00 Shindaiwa 20036-81670 Stihl 4133 121 2700

Walbro 188-12, 188-12-1, 188-14, 188-

14-1

Stens 615-740

Fits: Walbro WA, WT, WY, WYJ, WYK, WYL, WYP, and WYZ carburetors that require a 3/4" OD x 9/16" HT purge

bulb.



# INSTALLATION INSTRUCTIONS PURGE BULB KIT

#### Installing New Purge Bulb (Figures1-5)

#### NOTICE:

Removal of some parts may be necessary to access purge bulb retaining screws.

Disconnect spark plug wire.

NOTE: Press purge bulb several times to purge fuel from carburetor.

- 2. Carefully remove purge bulb retaining screws (A) and retainer (B).
- 3. Remove purge bulb (D) from purge base.
- 4. Install new purge bulb (D) onto purge base.
- 5. Install retainer (B) and purge bulb retaining screws (A).
- Fill fuel tank with fuel mix and tighten fuel cap. Press purge bulb to check for leaks. There should be **NO** leaks. If leaks are found, contact your local ECHO dealer.



#### **WARNING**

If leaks are found, do not start unit or serious personal injury may occur. Remove purge bulb, reinstall, and recheck for leaks. If leaks cannot be fixed, have unit repaired by an authorized servicing dealer before using.

#### **Installing New Remote Purge Bulb (Figure 6)**

#### NOTICE:

Removal of some parts may be necessary to access purge bulb retaining screws.

1. Disconnect spark plug wire.

NOTE: Press purge bulb several times to purge fuel from carburetor.

- 2. Depress latches (C) on both sides of old purge bulb (D) and remove it from base.
- Disconnect purge line and return line from old purge bulb.

#### NOTICE:

Note orientation of purge line and return line on old purge bulb fittings (E).

- 4. Connect purge line and return line to fittings (E) on new purge bulb.
- 5. Install new purge bulb (D) onto base, ensuring that latches (C) lock securely.
- Fill fuel tank with fuel mix and tighten fuel cap. Press purge bulb to check for leaks. There should be **NO** leaks. If leaks are found, contact your local ECHO dealer.



#### WARNING

If leaks are found, do not start unit or serious personal injury may occur. Remove purge bulb, reinstall, and recheck for leaks. If leaks cannot be fixed, have unit repaired by an authorized servicing dealer before using.

# **INSTALLATION INSTRUCTIONS PURGE BULB KIT**






Figure 1




Figure 2






Figure 4




Figure 6