



**Application:**



ETS is a 24 volt snow melting controller capable of switching an outdoor heating system on/off based on temperature and precipitation. Snow melt controller applications can include snow removal in walkways, steps, driveways, garage entrances, gutters, loading platforms or other locations where ice and snow accumulation is a problem. ETS detects outdoor temperature, ground temperature, and moisture, and energizes electrical relays when snow or ice occurs. The system's heat source can be either hydronic or electric heating cables (with the use of an external relay).

- Features:**
- Electronic on/off control
  - Detects moisture and temperature, or temperature only
  - Choice of ground, gutter, or outdoor sensor
  - Several sensors can be connected to the controller
  - Selection of either temperature or temperature/moisture activation of controller

**Ordering Information:**

Code No.	Description
ETS-3551	ETS-3551 Snow melting system controller, 24V low voltage version
ETOG-550	ETOG-550, Ground sensor for detection of slab temperature and moisture, 33ft (10m) cable
ETSR5500	ETSR5500, Gutter sensor for detection of moisture, 33ft (10m) cable
ETF-744/99	ETF-744/99, Outdoor sensor for detection of temperature

## Technical Data:

## ETS-3551 Snow/Ice Melting Controller

<b>Mounting</b>	Interior wall surface
<b>Dimensions</b>	3.4" x 2.1" x 2.3" (L x W x D)
<b>Supply voltage</b>	24 Vac $\pm$ 10%
<b>Output relays</b>	1 relay: 10-A, (potential free contacts)
<b>On/Off differential</b>	0.6°F (0.3°C)
<b>Ambient temperature</b>	+32° to 122°F (0° to +50°C)
<b>Temperature range</b>	+32°F to 41°F (0° to +5°C)
<b>Detection mode</b>	1) Moisture & temperature sensing 2) Temperature only
<b>Scale Adjustment</b>	Fine tuning of temperature setup $\pm$ 9°F ( $\pm$ 5°C)



## ETOG-550, Ground Sensor

<b>Detection</b>	Moisture
<b>Mounting</b>	Flush to surface
<b>Cable length</b>	33ft (10m)
<b>Ambient temperature</b>	-4 to 158°F (-20 to 70°C)
<b>Dimensions</b>	H: 1.25", $\pm$ 2.4" (H: 32mm, $\pm$ 60mm)



## ETSR5500, Gutter Sensor


<b>Detection</b>	Moisture
<b>Mounting</b>	Gutter or downspout, used in combination with ETF-744/99
<b>Cable length</b>	33ft (10m)
<b>Ambient temperature</b>	-4° to 158°F (-20° to 70°C)
<b>Dimensions</b>	4.15" x 1.2" x 0.5" (105 x 30 x 13mm) L x W x H



## ETF-744/99, Outdoor Sensor

<b>Detection</b>	Air temperature
<b>Mounting</b>	Exterior wall
<b>Ambient temperature</b>	-4° to 158°F (-20° to 70°C)
<b>Dimensions</b>	4.15" x 1.2" x 0.5" (105 x 30 x 13mm) L x W x H

Function:



The different sensors ETOG, ETSR and ETF sensors are wired to the controller to provide the feedback for the controller

**Settable Temperature for Activation of Controller:**

The large adjustable knob sets the temperature at which the controller would start the system. This scale adjustment is adjustable from 32° to 41°F (0° to 5°C). Depending on the mode selection, once the controller senses the temperature through either the ETOG pavement sensor or ETF outdoor sensor the controller would activate.

The ETS is a stand alone snow melt controller that provides an economical method for removing the accumulation of snow or ice in unwanted areas.


**Mode Selection:**

The controller can be selected to activate based upon either both temperature and precipitation or through temperature only, via toggle switch.

**Scale Adjustment:**


Between the mode and settable temperature, there is an adjustment knob to fine tune the settable temperature. The adjustment of the temperature is  $\pm 9^{\circ}\text{F}$  ( $\pm 5^{\circ}\text{C}$ ).

Wiring Diagrams:




**Dimensions:**


**ETOG Sensor**



**ETSR Sensor**



**ETS Controller**



Danfoss can accept no responsibility for possible errors in printed materials and reserves the right to alter its products without notice. All trademarks in this material are property of the respective companies. Danfoss and Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.



**Danfoss Inc.**  
Toronto, ON  
Tel.: 905-285-2050, Fax: 905-285-2055  
[www.na.heating.danfoss.com](http://www.na.heating.danfoss.com)

**Danfoss Inc.**  
Baltimore, MD  
Tel.: 443-512-0266, Fax: 443-512-0270  
[www.na.heating.danfoss.com](http://www.na.heating.danfoss.com)